
EN9800GT (C393GP) Repair Guide

PCBA: C393GP Power flow



Power sequence

