ASUSTeK COMPUTER INC.

GT730 Standard Operation Procedure

Doc. No:
Date:Mar.16.2018
Revision:1.96

Page: 10 **Grade**:

0Rev Mo	odified napters	Modification Description	Issued Dept.	Issued by	Revised Date
1.65		Add new PCBA(YV06R2-D11)	GRTD	Xiaoming_Lu	Feb.18.2016
1.66		Add new PN(YV0951-A01)	GRTD	Xiaoming_Lu	Feb.18.2016
1.67		Add new PN(YV0950-A01)	GRTD	Xiaoming_Lu	Feb.18.2016
1.68		Add new PN(YV09A0-A02)	GRTD	Xiaoming_Lu	Apr.1.2016
1.69		Add new PCBA(YV06R0-B41)	GRTD	Xiaoming_Lu	Apr.1.2016
1.70		Add new PCBA(YV06R2-D32)	GRTD	Xiaoming_Lu	May.6.2016
1.71		Add new PCBA(YV06R2-A44)	GRTD	Xiaoming_Lu	May.6.2016
1.72		Add new PN(YV0950-Q01)	GRTD	Maico_Zhang	Jun.6.2016
1.73		Add new PN(YV0951-Q01)	GRTD	Maico_Zhang	Jun.29.2016
1.74		Add new PN(YV09Y0-A01)	GRTD	Maico_Zhang	Jul.22.2016
1.75		Add new PN(YV06R2-T12)	GRTD	Maico_Zhang	Jul.22.2016
1.76		Add new PCBA(YV09A1-A01)	GRTD	Maico_Zhang	Aug.29.2016
1.77		Add new PN(YV09A2-A01)	GRTD	Maico_Zhang	Aug.29.2016
1.78		Add new PN(YV09A0-Q03)	GRTD	Maico_Zhang	Sep.19.2016
1.79		Add new PCBA(YV09Y0-A11)	GRTD	Maico_Zhang	Sep.19.2016
1.80		Add new PCBA(YV06R2-D42)	GRTD	Maico_Zhang	Oct.18.2016
1.81		Add new PN(YV06R2-D52)	GRTD	Maico_Zhang	Nov.9.2016
1.82		Add new PCBA(YV0950-A11)	GRTD	Maico_Zhang	Nov.30.2016
1.83		Add new PCBA(YV09Y0-A21)	GRTD	Maico_Zhang	Jan.6.2017
1.86		Add new PCBA(YV09A2-A12)	GRTD	Maico_Zhang	Jan.16.2017
1.87		Add new PCBA(YV09A0-A13)	GRTD	Maico_Zhang	Feb.17.2017
1.88		Add new PCBA(YV09A1-A13)	GRTD	Maico_Zhang	Mar.3.2017
1.89		Add new PCBA(YV0950-Q11)	GRTD	Maico_Zhang	Mar.3.2017
1.90		Add new PN(YV06R2-T54)	GRTD	Maico_Zhang	Mar.3.2017
1.91		Add new PCBA(YV09Y0-A31)		Maico_Zhang	Apr.20.2017
1.94		Add new PCBA(YV09A2-A23)	GRTD	Maico_Zhang	Aug.30.2017
1.95		Add new PCBA(YV0B80-A01)	GRTD	Maico_Zhang	Sep.21.2017
1.96		Add new PCBA(YV0950-A22)	GRTD	Maico_Zhang	Mar.16.2018

Authorize by	Review by	Originator By	Maico
-----------------	-----------	------------------	-------

Form No: T2-009-01 Rev.01

ASUSTeK COMPUTER
INC

GT730

Standard Operation Procedure Rev.: 1.96 Page: 1

Doc. No:
Date:Mar.16.2018

1.Objectives

Create test procedure.

2.Scope

Model: GT730

PN: YV06R2(D11) YV0951(A01) YV0950(A01) YV09A0(A02) YV06R0(B41) YV06R2(D32) YV06R2(A44) YV0950(Q01) YV0951(Q01) YV09Y0(A01) YV06R2(T12) YV09A1(A01) YV09A2(A01) YV09A0(Q03) YV09Y0(A11) YV06R2(D42) YV06R2(D52) YV0950(A11) YV09Y0(A21) YV09A2(A12) YV09A0(A13) YV0950(Q11) YV09A1(A13) YV06R2(T54) YV09Y0(A31) YV09A2(A23) YV0B80(A01) YV0950(A22)

3.Test Item

3.1 Diagnostic test in Linux system

4.Relevant Document

None.

5.Definition: 1. If the model name contains P, please test HDCP function.

Ex: EAH***/HTDP/512M/A

2. If you test HDMI already, it's unnecessary to test HDCP. The HDMI

ASUSTEK COMPUTER INC

GT730

Standard Operation Procedure | Rev.: 1.96 Page: 2

Doc. No:

Date:Mar.16.2018

contains HDCP function.

3. Please use platform (P7H55-M/USB3) to test in LINUX or Windows.

6. Operation Procedures:

6.1 Attention

- 6.1.1 To avoid damaging devices or M/B, please turn off A/C power then unplug VGA card.
- 6.1.2 While unplugging the card, do it in upright direction to avoid damaging slot & golden finger.
- 6.1.3 If any problem happens, please inform test supervisor. Base on ATX power specification, +5V standby voltage is existed while AC power is connecting. For safety reason, please turn off main power during break time or idling test.
- 6.1.4 Some test items should be tested under Windows environment. (Please install windows 7 test environment by yourself).

6.2 Fixture connect

- 6.2.1 Install Intel P7 CPU & CPU Fan.
- 6.2.2 Install DDR3 Memory to DIMM1~4.
- 6.2.3 Plug USB Mouse and PS/2 Keyboard into MB.
- 6.2.4 Plug VGA Card GT730 into PCIEX16.
- 6.2.5 Connect power con of VGA card & Power supply via bundled power cable.
- 6.2.6 Connect SATA HDD with SATA CON.



- 6.2.7 Plug 4PIN 12V (1200W) power cable into CON12V.
- 6.2.8 Plug ATX Power (1200W) on Power Connector.

ASUSTEK COMPUTER INC


GT730 Date:Mar.16.2018 Standard Operation Procedure Rev.: 1.96 Page: 3

Doc. No:
Date:Mar.16.2018



6.3 Diagnostic test in linux system

6.3.1Please connect LCD monitor & card's D-SUB CON via a D-SUB cable.



- 6.3.2 Press Power Switch then turn on power button.
- 6.3.3 Press "Del" to enter CMOS setup menu while boot screen is displaying.

EXIT -> Load Setup Defaults. Advanced Power Exit Options Exit system setup Exit & Save Changes after saving the Exit & Discard Changes changes. Discard Changes F10 key can be used Load Setup Defaults for this operation. Select Screen Select Item Go to Sub-screen General Help Save and Exit (C)Copyright 1985-2002, American Megatrends,

6.3.4 System will reboot, select linux to run test program.

Path:GT730s\ yv06r2d1.sh

Path:GT730w\yv0950a0.sh or yv0951a0.sh or yv0950a1.sh or yv0b80a0.sh or vv0950a2.sh

Path:GT730x\ yv09a0a0.sh or yv09a1a0.sh or yv09a0a1.sh or yv09a1a1.sh

Path:GT730k\ yv06r0b4.sh

 $Path:GT730s \setminus yv06r2d3.sh\ or\ yv06r2d2.sh\ or\ yv06r2a4.sh\ or\ yv06r2d4.sh$

Path:GT730y\ yv0950q0.sh or yv0950q1.sh

Path:GT730z\ yv0951q0.sh

ASUSTEK COMPUTER INC

GT730

Standard Operation Procedure | Rev.: 1.96 Page: 4

Doc. No:

Date:Mar.16.2018

Path:GT730a1\ yv09y0a0.sh or yv09y0a1.sh or yv09y0a2.sh or yv09y0a3.sh

Path:GT730a2\ yv06r2t1.sh

Path:GT730a3\ yv09a2a0.sh or yv09a2a1.sh or yv09a2a2.sh

Path:GT730a4\ yv09a0q0.sh Path:GT730a5\ yv06r2d5.sh Path:GT730a6\ yv06r2t5.sh

Run the test program refer to the prompt.

6.3.5 Memory test

If you want to test memory, please run ./mats -e xx or ./mats -c xx

Where,-c xx----- only xx% of frame buffer is detected.

Path:GT730\

6.3.6 BIOS flash

Please use the following command to flash bios and notice the size of character.

Path:GT730\

Command:./nvflash xxx.rom -4 -5 -6 -A -y

Notice:

If you can not flash bios because of the bios locked, please use ./nvflash.exe /r or ./nvflash -r to unlock bios. And then, please use ./nvflash.exe /w or ./nvflash -w to lock bios after updating latest bios.

6.3.7 If test OK, NTF test.

7 Appendix

NO#	Equipment Description	ASUS Part#	Supplier	Quantity	Remarks
1	SAMSUNG 2232MW			1	
2	USB MOUSE			1	
3	PS/2 KEYBOARD			1	

ASUSTeK COMPUTER INC

GT730 Standard Operation Procedure Rev.: 1.96 Page: 5

Doc. No:

Date:Mar.16.2018

4	ATX POWER SUPPLY(1200W)			1	
5	Intel CPU Intel(R) Core(TM)2 CPU		local	1	E1100
6	Heat sink + FAN	22-240000160	local	1	
7	DDR3 1333 2G	20-TT2605618	local	4	
8	SATA HDD			1	
9	SATA HDD Cable	14-000107070		1	
10	PCIEX16 VGA CARD			1	
11	D-SUB extend cable (Buying a local D-SUB cable by yourself)			1	
13	HDMI extend cable (Buying a local HDMI cable by yourself)			1	
15	DVI-HDMI	04G460002400 /04G460002450		1	
17	P7H55-M/USB3	80-MIBBKA-G0*	ASUS	1	