## ENGTS250 (C365PI) Repair Guide

PCBA: C365PI

**Power flow** 





