







Layout quideline

1-Position the controller (U703) such that LGate(pin4) is the closet to gate of the MOSFRTA. You can place the gate resistors R721 and R722 next to the gate of the MOSFRTA. Nake the gate drive traces[RW MUDGL LUD and W MUDGL MUD as short that the state of the state





AMD Commerce Valley Drive East Markham, Ontario le: Thursday, June 10, 2010 et 16 of 23

Doc No. 105-C224XX-00A

Title MVDD

