

SYSFAN_TACH1

SYSFAN_TACH2

STRIX_SYSFAN_MCU

L

H(Default)

Mode


NORMAL


STRIX


SYSFANTACH_SELECT_MCU


H(Default)













STRIX_SYSFAN_MCU	Mode
L	NORMAL
H(Default)	STRIX
SYSFANTACH_SELECT_MCU	Mode
L	SYSFAN_TACH1
H(Default)	SYSFAN_TACH2



