ENGT220 (C680P) Repair Guide

PCBA: C680P

Power flow

Power sequence





