#### 7-1. Components on the Rear Case



#### 7-2. Pre-requisite



### 7-3. Parts which must be changed after repair

BOM A code	Image	Remarks
SVC BACK GLASS OUT [GH81-14351A]	H.	Replace for
SVC BACK GLASS IN [GH81-14352A]		Back Glass repair

#### 7-4. Disassembly

- .. Dioaccomisi,
  - 1) Put the device in the chamber for 10~20 minutes under 65~75  $^{\circ}\mathrm{C}$  .
  - 2) Detach the Back Glass.



Unscrew 12 Point and disassemble SIM Tray1, 2 from device





- **\*** Caution
- 1) Be care of scratch
- Disassemble Upper Rear.
  (Use disassemble hole left side of Rear to detach it)



Caution

2

- 1) Be care of scratch
- 4 Finally Disassemble Rear of bottom side.



(Use disassemble hole left side of Rear to detach it)

- Caution
- 1) Be care of Rear damage

- Caution
- 1) Be care of Rear and connector damage

5

Unscrew PBA 3 points.



6

Detach Battery connect and the other connectors. (7 Points, except for Front Camera connector)



- **\*** Caution
- 1) Be careful not to damage the PBA
  - 7
    - Detach main PBA from Front.

- **\*** Caution
- 1) Be care of connector/cable damage
  - Detach other components.






- Caution
- 1) Be care of PBA damage

- Caution
- 1) Be care of several kinds of damage


#### 7-5. Aassembly

Attach components on Front.
(RCV module, Sensor FPCB, Motor) and then Press RCV.





2 Attach PBA assy In Front Assy. (PBA+ Front)



PCB 15° angle

- Caution
- 1) Be care of FPCB damage and tilt
- 2) Be care of press power/time
- Attach Battery connect and the other connectors. (7 Points)
  Attach Front Camera on PBA.



- Caution
- 1) Be care of chip damage nearby screw point

Screw PBA 3 points.
(Torque:1.2 Kgf·cm±7%)



- Caution
- 1) Be care of connector damage.

- Caution
- 1) Be careful not to damage the PBA





9

Press Back Glass.(1N for 1minute)

10

Do water resistance test(WRT)





- Caution
- 1) Be care of scratch.


- Caution
- 1) Be care of scratch.


11

If fail WRT doing debugging(sealing or etc)

12

If connector problem, disassemble & remove gasket





- **\*** Caution
- 1) Be care of scratch.

- Caution
- 1) Be care of PBA damage

