7-1. Speaker module Repair

7-1-1. Notice


- It is necessary to calibrate the speaker for all cases of replacing the speakers.
- Target models : Galaxy A(A3/5/7/8), E(E5/7) Series

7-1-2. You need:

- Mobile device
- Laptop or Note PC
- Anyway Jig
- UART Serial Cable
- IF Test Cable (Different by models)



7-1-4. How to Calibrate Speaker




IMEI & S/N read

Enter


Exit



- Speaker Calibration will start within 30 seconds after Booting complete.
- X LCD must be turned on in order to test properly.



8 Confirm whether the Speaker Calibration is done successfully.



7-2. Pre-requisite



7-3. Parts which must be changed after repair

BOM Discription	Picture	Remarks
A/S- TAPE_BACK_GLASS_SVC [GH81-13535A]		Replace whne repair all cases
TAPE DOBLE FACE-OCTA BTM [GH02-11593A]		
TAPE DOBLE FACE-OCTA TOP [GH02-11588A]		
A/S- TAPE_HR_BRACKET_SVC [GH81-13534A]		Replace when repair Front Part
A/S-Touch key top Tape [GH81-13587A]		

7-4. Disassembly



5





6




- 1) Loosen 1 Screws in PBA Ass'y
- 2) Disassemble the coaxial Cable Head.
- 3) Open OCTA, Home Key, Sub PBA Connetor

1) Take Main PBA out from bottom to top.

* Be careful not to damage.

7



8



- 1) Detach Mega Cam and Front Cam on PBA
 - * Be careful not to damage.

1) Detach Rcv, Motor, Speaker and Battery

9



10



- 1) Detach OCTA using detaching JIG
- * Confirm OCTA connector position disassembly

1) Lift OCTA up about 2cm

* Do not disassemble completely

11







- 1) Disassmle Rear case then take out OCTA connector
- * Do not disassemble OCTA before dissable Rear
- 1) Detach OCTA and Home Key Connector and Coaxial Cable from PBA
- 2) Separate PBA from Brocket.
 - * Be careful not to damage.

7-5. assembly



2




- Assemble the Home key
 Assemble SUB PBA and Screw 1 Point

1) Assemble OCTA on Bracket using OCTA Attach JIG

3



4




- 1) Assemble Battery, Motor, RCV
- 2) Press Battery using Battery Press JIG

- 1) Assemble Mega CAM and Front Cam.
- * Do not Touch camera window.

5



6



1) Connect Sub PBA

1) Push battery contact pin, then assemble main PBA

7



8



- 1) Screw 1 Screws in PBA Ass'y
- 2) Connect the coaxial Cable Head OCTA, Home Key, Sub PBA Connetor
- 1) Assemble Rear to Bracket assy

