

Wireless Device **SM-A300F**

SERVICE Manual

Wireless Device

____ oo o

CONTENTS

- Safety Precautions
- Specification 2.
- 3. Product Function
- 4. Exploded View and Parts list
- 5. MAIN Electrical Parts List
- 6. Level 1 Repair
- 7. Level 2 Repair
- 8. Level 3 Repair
- Reference data

Notice: All functionality, features, specifications, and other product information provided in this document. including but not limited to, benefits, design, pricing, components, performance, availability, and capabiliti -es of the product are subject to change without notice. Samsung reserves the right to alter this doc -ument or the product described herein at anytime, without obligation to provide notification of such changes.

SAMSUNG ELECTRONICS

