#### 6-1. S/W Update

#### 6-1-1. Preparation

S/W Update program: Fenrir 5.17.xxxx

- ☐ Mobile Phone
- □ Data Cable

#### Settings





Data Cable(B type): GH39-01710D Data Cable(C type): GH39-02003A

#### 6-1-2. How to use 'Fenrir' S/W update program.

1) Launch Fenrir by clicking on the icon on the desktop









- SVH (Fenrir\_Home): It uses Home binary which does not have user data area in the memory when flashed to a device. (Keep user data)
- SVC (Fenrir\_Factory) : It uses Factory binary which erases all user data in the memory when flashed to a device. (Clear user data)
- SVA (Fenrir\_All): It uses Factory and Home binaries. you can download Home and Factory binary
  in a PC(but requires double HDD storage and NW traffic)

- 2) Input ID & password
- XYou need to reset the ID information in case of PC change and format and repair, hard disk change




3) Ensure device has sufficient charge (at least 20%) to start firmware update.




4) Connect the device to PC via data cable.


5) Upon USB connection, you will be presented with below screen.



6) Once device is detected, you will be presented with below screen. To update S/W, select "S/W Update" or to exit select "SVC Connection". If you select "SVC Connection", only Fenrir connection history (record) will be stored in the FUS server to support warranty validation. (This is known as "Service Connection" history)




7) Once Fenrir starts, application will display the below screen. And select the Start button & Agree button.




8) The status circle increases as the update installs.

The update process takes approximately 5-10 minutes to complete.

Do not disconnect the device from USB during processing.



9) Once complete, application will present the below screen indicating update complete. Click Ok and detach device from USB.




**\*\* Please refer to the user guide for Fenrir uploaded on GSPN for more detailed information.** 

### 6-2. IMEI writing

### 6-2-1. Preparation

- New IMEI writing Program has been released.
- Supported Model: Models which CAB files are uploaded on HHPsvc INI File category, instead of ini file.
- Refer to below IMEI writing procedure.


#### - H/W



#### - S/W

0/11	
① Library Install	To use Daseul, library files should be installed. Refer to SVC guide "(SP-04) USB writing guide_rev2.0"
②Launcher	DASEUL_SVC_Launcher_v3.0.12 or higher -Uploaded on HHPsvc Notice
③ Runtime File	1. DASEUL_IMEI_ALL_Runtime_3.1.421.0_r00638.CAB or higher -Uploaded on HHPsvc Notice 2. Make 'ModelName' folder at the same position with launcher & Runtime file.  DASEUL_IMEI_ALL_Runtime_3.1.281.0_r00405.CAB  ADASEUL_Launcher_v4.0.0.exe  SM-G955U_VZW(SIM)_IMEI_Ver_3.1.278.2.CAB
4 Model File	Copy Model File under the 'Model Name' folder

### 6-2-2. IMEI writing Process




SMD F/T
PBA F/T
Calibration
CAL 2nd

Final 2nd


IMEI
WLAN
GPS
B T


r00161 | GT-N7000\_COMMON(CSC16G)\_IMEI\_Ver\_3.1.99.8.CAB





Extract & Run


Close

















15. ① Click Start  $\rightarrow$  ②Input IMEI writing ID and Password & OTP  $\rightarrow$  ③Input Ticket No





- 16. Connect the phone to Anyway JIG
- When you connect the phone, the phone should be turned off.
  After connecting the phone, the phone will be booted automatically.



Please refer to the user guide for IMEI Writing on GSPN for more detailed information.