






MT6589 Phone DDR2








Charger



Audio




Digital




AMOI N828

WCDMA DIGITAL MOBILE PHONE
Page3




MAIN MIC

HANDSET RECEIVER




Earphone MICPHONE





Earphone RECEIVER


Audio Jack



USB BOARD IF








[illegible]

300W CAMERA

Capacitive Touch Panel




WCDMA DIGITAL MOBILE PHONE
Page 8

SIM1




SIM2

SD CARD



AMOI N828

WCDMA DIGITAL MOBILE PHONE
Page 9




AMOI N828


WCDMA DIGITAL MOBILE PHONE

Page 10


M-SENSOR




ALS & PS Sensor




G-Sensor




Gyro-Sensor



Power Key



Volume Up



Volume Down

