


Model: Apple 1466 does not start fault maintenance



Multiple corrosions were found after disassembly



After cleaning up the corrosion,





The measured ground values are normal, and the power is started






Go through the R8141 flying root line







Then power on, the current is normal, and the machine is turned on directly for repair.



