Proofreading- Before

Table Top Photo Studio Light Tent Kit w/Tripod Installation Guide

To begin setting up your Table Top Photo Studio Light Tent Kit start by opening your package and ensure that the kit includes the following:

* (1) Photo studio tent
* (4) Non-reflective background (red/black/blue/white)
* (2) Light stands
* (1) Tripod

~ Components may vary based on your purchase order number

This installation guide with be covered in two parts. Part A will guide you through setting up your photo studio tent, Part B will guide you through setting up your light stands and tripod.

Part A) Setting up the Photo Studio Tent

1. Start by folding the single paneled side up to create the left side of your tent.

2. Then by using the double-paneled side, fold it upwards and attach it to the velcro linings along the left side and bottom panel to create the right side and back panel of your tent.

3. Attach your choice of background to the velcro lining along the back panel of the tent.

4. With the remaining panel, located along the right side of your tent, fold it over the top of your tent to create the roof.

5. Turn the tent upside down so that the bottom is covered by your background.

Part B) Setting up the Lights and Tripod

CAUTION: VERY HOT. DO NOT TOUCH THE HEAD OF LIGHT STANDS WITHIN ONE HOUR OF USE.

1. Start by unscrewing the clasp on the bottom of the light stands to release the legs.

2. Adjust the legs until you have them at the desired height, retighten the clasp to lock it in this position.

3. With the proper height locked in, plug the lights into a regular outlet.

4. Unscrew the clasp located at the top of the tripods neck to adjust the legs of your tripod.

*** Lights may vary based upon kit purchased*

*** Tripod may vary based upon kit purchased*

Julius Studio Portable Lightbulb Replacement Guide (L02,L022)

Part C) How to Replace the Lightbulb

WARNING: Unplug the light stand at least an hour before changing the lightbulb to allow the lightbulb to cool avoid burning the skin.

1. Unscrew the front cover counterclockwise to remove the covering.

2. With the covering removed carefully unscrew the lightbulb counterclockwise and remove the lightbulb.

3. Place your replacement lightbulb in the exposed socket and screw it clockwise until it is secure.

4. Repeat Step 1 is with a clockwise motion to replace the covering.

Proofreading- After