

HP CLJ Printer Resets - Transfer and Fuser Kit

HP CLJ 4500

Service mode:

- Hold ITEMS and (+) buttons at power up until the three lights remain solid
- Release, then press MENU (right side) then SELECT
- Printer should display SERVICE MODE
- Scroll until printer reads "TRANSFER COUNT" or "FUSER COUNT"
- Set all digits to zero

HP CLJ 4550

 Scroll MENU button to resets menu then press SELECT button on either "RESET FUSER LIFE COUNT" or "RESET TRANSFER LIFE COUNT"

HP CLJ 8500 CLJ 8550

- Scroll MENU button to resets menu
- Press SELECT button on either "RESET FUSER LIFE COUNT" or "RESET TRANSFER LIFE COUNT"

HP CLJ 4600 / CLJ 4650 CLJ 5500 / CLJ 5550

- With printer at ready state, scroll until "CONFIGURE DEVICE" (✓)
- To "RESETS" (✓)
- To "RESET SUPPLIES" (✓)
- Highlight either "NEW FUSER KIT" or "NEW TRANSFER KIT"
- Press (✓) then to "YES" (✓)

HP M5225 / M5525 / M750 / M775

- Scroll to "ADMINISTRATION" Menu
- Scroll down to MANAGE SUPPLIES
- Scroll to "RESET SUPPLIES"
- Select either NEW FUSER KIT or NEW TRANSFER KIT

HP CLJ 4700 / CP4005 / 4730MFP / CM4730MFP / CP4025 / CP4525 / CM4540MFP / M651 / M680MFP / M855 / M880MFP

This series has the fuser and transfer belt designed to automatically reset the consumable counters *Please Note*:

- Printers must be tuned off when changing either part
- There is no way to reset either fuser or transfer count other than replacing the component
- Do not replace fuser and transfer belt at the same time. Replace one then perform POR

HP CLJ 9500

With printer at ready state:

- Scroll until "CONFIGURE DEVICE" (✓)
- To "RESETS" (✓)
- To "RESET SUPPLIES" (✓)
- Highlight either "NEW FUSER KIT" or "NEW TRANSFER KIT"
 Press (✓) then to "YES" (✓)

