

## Control panel calibration HP LaserJet M3027/M3035 MFP, 4345MFP, M4345MFP, CM4730MFP, M5035MFP, CM6030/CM6040MFP, M9040/M9050MFP, 9250C Digital Sender

If the touch screen on the control panel is unresponsive or failing to in specific areas, follow these steps to calibrate it:

- 1. Turn the product Off
- 2. Press and hold the number key (#) and the Clear key (©) while turning the product on. A dot will display in the upper left corner of the screen
- 3. Release the # and C keys
- 4. Touch the dot with a blunt object, such as a pencil eraser, and another dot will display in the lower right corner
- 5. Touch that dot and wait for the product to continue the startup sequence
- 6. If after performing a control panel calibration the issue persists, replace the control panel

