

CALUMET 8 x 10 VIEW CAMERA

PARIS UST

PART NUMBER		•	PART NUMBER	
04043	Carrier complete assembly (drawing) includes the following replacement parts	04032	Front standard complete assembly (drawing) includes the following REPLACEMENT PARTS	
04037	Bellows assembly	04033	Front standard slide assembly	
1005	#5-40 x 3/8 PH. FL. HD. screw	04035		
1007	#2 x 1/2 \$L FL HD. wood screw		Front tilt lock assembly	
1014	#2-56 x 3/16 PH. FIL. HD. screw	04642		
50102	Lens board carrier	1036		
50129	Carrier drive strip	2000		
50150	Lens board relainer	50114	Front standard	
50157	Shoulder screw	50128		
50160	Light seal	50174		
50161	Light seal	50175	Compression Spring	
50162	Light seal	50176		
		70042	Calumet medallion	
04041	Base, complete assembly (drawing)			
	includes the following replacement parts	04032	SIDE AND FRONT ASSEMBLY (DRAWING) Front standard complete assembly	
04028	Tripod lock assembly	0.4007	Rear frame assembly	
04030	Extension slide lock assembly	04038	O 44 Elle bolder	
04031	Hinge lock assembly	04039		
04065		04040	Focusing slide assembly	
1001	#10-24 x 3/8 PH. PAN HD. nickel plate screw	04041	Base assembly	
1019	#5-40 x 3/16 SL_ FIL. HD. screw		Carrier assembly	
2002	.195 x .274 x .03 flat washer	1003	·	
50104	Front base	1004	#5-40 x 3/8 PH, FIL, HD, screw	
50106	Rear base		#4 x 3/4 SL_ FL_ HD. wood screw	
50123		1010	#8-32 x 3/8 PH, FL, HD, screw	
- 50124	Extension frame guide (left)	1027	#6-32 x 3/16 SL_ binding head screw	
2137	Tripod lock	2001	17/64 x 1 x 1/6 flat washer	
141	Tripod block guide (right)	50116	Lens board (order AO-LB66)	
142		10585	Z Tension washer	
50143		106209		
50144				
		0403	Rear frame complete assembly (drawing)	
50145	Extension traine going stop		includes the following replacement parts	
50146				
50151	Storage pin tock screw		6 Handle assembly	
		0402		
04040	Focusing slide complete assembly (drawing)	0404	5 Spirit level assembly (right)	
	includes the following replacement parts	0404		
04024	Right lock guide assembly	101:	3 #10-24 x .285 Heli coil insert	
04025		. 1024	#2-56 x 1/8 PH. FIL. HD. screw	
04023		102:		
04034		200		
		5011	Rear bellows frame	
04044		5014		
1002	#10-32 x 3/4 PH, FIL. HD, screw	5015	4 Mounting bracket (left)	
1011		5019		
1015		10588		
1022	#6-32 x 3/16 SOC. HD. set screw		3 Focusing cloth clip	
1026		10900	A 1 committee out and an	
1045		04036	Film holder complete assembly (drawing)	
2004	260 x ,750 x ,010 flat washer	- 100.	includes the following replacement parts	
2011			- • • • • • • • • • • • • • • • • • • •	
4003		0404		
4005		101	4 #2-66 x 3/16 PH, FIL. HD. screw	
50120		101	5 #4-40 x 3/16 PH. RD. HD. screw	
50122		200		
50133		400	8 1/4 dia_x 1/2 lg. roll pin	
50135		600		
50138		5011		
50139		5013		
50140		5013		
		5013		
50147		5014		
50159	I only anger	5015		
70189		5018 5018		
_2190	Lock nut	5018	6 Light soal	
· '91				
		50152	a muleu urbunu ulasa isulu a DCs, Ulilyi	
39	Friction wheel spring	6032		



CARRIER
ASSEMBLY
8 x 10 VIEW
CAMERA




CALUMET PHOTOGRAPHIC INC. 890 SUPREME DR. BENSENVILLE, IL 60106 TELEPHONE: 312-860-7447 TWX 910-222-0271

~1013 GnserD 50192 50149

Ò4029

REAR
FRAME
ASSEMBLY
8 x 10 VIEW
CAMERA



04/20/94 \$

10:00

