# PRODUCT NO.232

# ASAHI PENTAX SV



### **EXPLODED ILLUSTRATIONS**




Fig.I

-2- 232




Fig.2




Fig. 3




Fig.4

232 -5-




Fig.5

232




Fig.6




Fig.7

-8- 232

# LIST OF SERVICE PARTS

Product No. 232

### **ASAHI PENTAX SV**

Note: The parts with numbers starting with '0' are assembled parts; the \*marked parts are included in the '0' starting assembled parts; and these marked with 'o' are same as the parts for Product No. 230-2.

PART NO	).	DESCRIPTION QUA	NTITY
0A01		Body proper assembly (A01, E118)	1
0A02		Back cover assembly (A02, A09, A10, A13, A14, A25, A27, A32, A33, A34, A36, A37, A67, A69)	1
0A03		Top cover assembly (A03, A17, A40, A45, A46, A47, LW13)	1
A04	0 🔻	Bottom cover	1
0A05	0	Front cover assembly (A05, A15, A16, A22, A23, A24, A29, A35, B51, B52, B53, B56, B57, B60, small screw FM 1.4x2)	1
A06	0	Sprocket cover	1
A07	0	Light seal	1
A08	0	Cassette receptacle	1
A09 *	0	Cassette holder	1
A10 *	0	Hinge	1
0A11	0	Pressure plate assembly (All, A12, A26)	1
A12 *	0	Pressure plate spring	1
A13 *	0	Key housing	1
A14 *	0	Back cover key	1
A15 *	0	Helicoid seat	1
A16 *	o	Helicoid seat retainer screw	1
A17 *	0	Shutter button seat	1
A18	0	Shutter button	1
A19	0	Shutter button shaft	1

A20	О	Tripod socket	]
A21	О	Strap hook	1
A22 *	0	Plug seat	1
A23 *	0	Outer pole	1
A24 *	O	Inner pole	1
A25 *	O	Pressure plate retainer stud A	2
A26 *	O	Pressure plate rivet	2
A27 *	0	Key housing column	2
A28	O	Key housing retainer plate	1
A29 *	o	Helicoid seat stopper	1
A30	О	Body covering, left	1
A31	0	Body covering, right	1
A32 *	o	Key housing covering	1
A33 *	О	Back cover covering	1
A34 *	O	Cassette holder rivet	2
A35 *	O	Earth	1
A36 *	О	Pressure plate retainer stud B	3
A37 *	O	Hinge rivet	3
A39	o	Front cover adjust washer	4
		(t = 0.05, 0.1, 0.15  and  0.2)	
A40 *	O	Indicator window	1
A41	О	Light seal	2
A42	J	Light seal	1
A43	О	Strap hook screw	2
A45 *		Release button	1
A46 *		Release button seat	1
A47 *		Release button spring	1
A48		Self-timer box stopper	1
A49		Guide plate	1
A50		Adjust plate	1
A51		Guide screw	1
A52		Coupler lever	1

-10- 232

0A53	(A53, A54, A56, A57, A61, LW13)	1
A54 *	Intermediate lever A	1
0A55	Intermediate lever B assembly (A55, A60)	1
A56 *	Actuator lever	1
A57 *	Intermediate lever shaft A	1
A58	Intermediate lever shaft B	1
A59	Intermediate lever spring hanger	1
A60 *	Intermediate lever stud	1
A61 *	Actuator lever shaft	1
A62	Intermediate lever spring	1
A64	Light seal B	1
A65	Light seal C	1
A67 *	Light seal plate B	1
A69 *	Light seal rivet	2
В01 о	Prism seat	1
0B02	Mirror housing assembly (B02, B21, B76, R304)	1
В03 о	Ground glass frame	1
B05 o	Ground glass mask	1
В06 о	Prism retainer plate	1
В07 о		1
0B08 o	Magnifier retainer assembly (B08, B78)	1
0B09 o	Prism side protector assembly (B09, B33)	2
0B10 o	Mirror seat assembly (BIO, B11, B12, B15, B42,	1
	B48, B49, B50)	
B11 * o	Mirror hinge	1
B12 * o	Mirror retainer plate	1
B13 o	Mirror seat rest screw	1
B14 o	Mirror seat rest	1
B15 * o	Mirror seat lug	1
B16 o	Mirror check lever	1

232 -11-

B17	0	Mirror check lever screw	1
0B18	0 =	Mirror actuator lever, top, assembly (B18, B39, B51)	1
0B19	0	Mirror actuator lever, bottom, assembly (B19,	1
		B38, B58, B70)	1
0B20	0	Curtain actuator lever assembly (B20, B40)	1
B21	0	Light seal	1
B22	0	Light seal	1
B23	0	FP lever A	1
B24	* 0	FP lever B	1
0B25	0	Sync seat assembly (B25, B23, B24, B26, B64, B65, B66, B73, B74, B77)	1
B26	* 0	Sync seat insulator	1
0B27	0	Actuator lever assembly (B27, B28, B59, B67, B68, B84)	1
B28	* 0	Bottom actuator lever	1
B29	* 0	2nd dia lever checker plate	1
0B30	0	X lever assembly (B30, B32, B73, B75, B77, B80)	1
B31	0	X lever insulator	1
B32	* 0	X lever retainer plate	1
B33	* 0	Protector plate pin	2
B35	0	Mirror actuator lever shaft	1
B36	0	Mirror actuator lever retainer screw	1
B37	* 0	2nd dia lever checker plate rivet	2
B38	* 0	Mirror actuator lever spring hanger A	1
B39	* 0	Mirror actuator lever spring hanger B	1
B40	* 0	Curtain actuator lever stay	1
B41	0	Actuator lever spring hanger	1
B42	* 0	Mirror seat lug stud	1
B43	0	Curtain actuator lever retainer screw	1
B44	0	Mirror seat spring	1
B45		Prism retainer spring	2

-12- 232

B46	o Mirror check lever spring	g l
B47	o Bottom actuator lever spring	1
B48 *	o Mirror seat lug rivet	2
B49 *	o Mirror retainer plate rivet	2
B50 *	o Mirror hinge shaft	1
B51 *	o 1st dia lever pin	2
B52 *	o Dia lever support	1
B53 *	o 1st dia lever	1
OB54	o 2nd dia lever assembly (B54, B29, B37, B69)	1
B55	o 2nd dia lever retainer screw	1
B56 *	o 1st dia lever shaft	1
B57 *	o 1st dia lever spring	1
B58 *	o Mirror actuator lever, bottom, stud	1
B59 *	o 2nd dia lever adjust screw	1
B60 *	o Supporter column	2
B61	o Light seal	1
B62	o X lever retainer screw	2
B63	o Focus adjust screw	3
B64 *	o Contact A	2
B65 *	o Contact B	2
B66 *	o Sync lever rivet	6
B67 *	o Actuator lever collar	1
B68 *	o Actuator lever shaft	1
B69 *	o Dia lever spring hanger A	1
B70 *	o Dia lever spring hanger B	1
B71	o Mirror housing retainer screw	2
B72	o Dia lever spring	1
B73 *	o Cord B	2
B74 •	o Tube A	1
B75 *	o Tube B	1
B76 *	o Actuator lever column	1
B77 *	o Lug plate	2

232 -13-

B78 *	O	Magnifier cusion	1
B79	0	Ground glass holder	2
B80 *	0	X lever rivet	1
B81	0	Mirror hinge screw	3
B83	0	Mirror checker spring	1
B84 *	O	Actuator lever coupler spring	1
B85	0	Actuator lever spring	1
B86	0	Mirror shock absorber	1
0C01	0	Top mec plate assembly (C01, C41, C43, C79, E20, E22, E26, E27, E28, E81, E120)	1
0C02	0	D	1
0002	Ü	C47)	•
C01		Rapid wind lever	1
C04	0	Non-return arm	1
C0S *	O	Lever seat lug	1
C06 *		Counter advance lug	1
0C07		Advance lug actuator assembly (C07, C06, C65, C66, C77)	1
C08 *		Retainer lug	1
C09 *		Retainer lug spring	1
0C10	O	Lever stopper assembly (CIO, C44)	1
Cll	0	Stopper	1
C12		Counter dial	1
C13	O	Top take-up spool brim	1
C14	0	Bottom take-up spool brim	1
CI5	0	Coupler lever	1
0C16	0	Coupler lever seat assembly (C16, C48)	1
0C17	0	Pin adjust plate assembly (C17, C51, C76. set screw tapered 1.7x2)	1
C18	o	Half moon washer	1
C19 *	0	Spring	1

4- 232

C20		Top 1st gear	1
0C21	О	Top 2nd gear assembly (C21, C22)	1
C22 *	О	Top 3rd gear	1
C23 *	О	Top main gear	1
C24	О	Bottom main gear	1
C25	О	Bottom 1st gear	1
C26	О	Bottom 2nd gear	1
0C27	О	Bottom 3rd gear assembly (C27, C30)	1
OC28		Transport gear assembly (C28, C83)	1
C29	О	Sprocket	1
C30 *	О	Sprocket shaft	1
OC31	0	Wind-up shaft assembly (C31, C23, C32, C57, C75)	1
C32 *	О	Wind-up shaft bearing	1
C33	О	Take-up spool shaft	1
OC34		Rapid wind lever shaft assembly (C34, C60, C85, C88, LW10)	1
OC35		Wind-up lever seat assembly (C35, COS, C19, C49, C59, C74, C81)No. 1-5	1
C36		Actuator plate retainer screw	1
C37 *		Counter dial window	1
C38		Lever seat collar	1
C39		Cover ring assembly (C39, C37)	1
C40	О	R button	1
C41 *	О	Top 1st gear column	1
C42	o	Stopper column	1
C43 *	o	Non-return arm seat	1
C44 *	О	Spring hanger column	1
C45 *	o	Bottom 2nd gear shaft	1
C46 *	o	Bottom 1st gear shaft	1
C47 *	o	Coupler lever collar	2
C48 *	o	Coupler lever shaft	1
C49 *	О	Lever seat rivet	1

232 -15-

C50 Counter advance stud	1
C51 * o Coupler lever pin	1
C52 o R lever retainer screw	1
C53 * Retainer lug screw	1
C54 Counter retainer screw	1
C55 o Bottom 2nd gear screw	1
C56 o Sprocket screw	1
C57 * o Wind-up shaft spring	1
C58 o Take-up spool spring	1
C59 * o Lever seat lug spring	1
C60 * Counter spring	1
C61 o Non-return arm spring	1
G62 o R lever spring	1
C63 o Sprocket seat spring	1
C64 o Spring washer	2
C65 * Advance lug spring	1
C66 * Advance lug rivet	1
G68 o Stopper washer A	2
C69 o Stopper washer B	1
C70 o R lever	1
C7l o Slow speed spring	1
C72 o Bottom mec plate retainer screw	4
C73 o Rapid wind lever retainer screw	2
C74 * Spring retainer screw	1
C75 * o Top main gear retainer screw	1
C76 * o Pin adjust plate stud	1
C77 * Advance lug spring hanger	1
C78 o Bottom 2nd gear spring	1
C79 * o Gear column pin	1
C80 o Coupler lever retainer screw	1
C81 * o Lug spring retainer screw	1
C82 * Actuator stopper	1

-16-

232

C83 *	Counter dial stopper A	1
C84 *	Counter dial stopper B	1
C85 *	Counter shaft	1
0C86	Counter housing assembly (C86, C08, C09, C53,	1
	C82, C84, small screw FM 1.4 x 1.8)	
C87 o	Light seal	1
C88 *	Counter shaft bearing, bottom	1
C89 *	Reset lever	1
0C90	Reset lever assembly (C90, C89)	1
C91	Reset lever spring	1
C92 o	Stopper nut	1
C93	Reset lever spring hanger	1
D01 *	Hoof spring	1
D02 *	Cocking wheel	1
D03 *	Reminder dial stud	1
D04	Shaft bearing	1
D05	Rewind shaft	1
0D06	Rewind knob assembly (D06, D01, D07, D10, D11, D12, D13, D15>	1
D07 *	Rewind cover ring	1
0D08	ASA dial assembly (D08, D02, D03, D09, D16, D18)	1
D09 *	Dial retainer nut	1
D10 *	Crank	1
D11 * o	Nipple	1
D12 *	Crank shaft	1
D13 * o	Crank pin	1
D14 *	Shaft spring	1
D15 *	Retainer ring	1
D16 * o	Dial seat spring	1
0D17	Nut assembly (D17, D14)	1
D18 *	ASA dial	1

232 -17-

E01		O	Top shaft plate	1
EO2		O	1st curtain shaft plate	1
E03	*	O	1st curtain edger	1
E04	*	О	2nd curtain edger	1
E05		O	Release plate	1
0E06		0	Bulb lever assembly (E06A, E06B, E71, E72, B78, E87, set screw flat 1.4x2.5)	1
E06	A	* o	Top bulb lever	1
E061	В	* 0	Bottom bulb lever	1
E07		0	1st curtain checker arm	1
E08		О	Spill	1
E09		0	Spill receptacle plate	1
0E10		0	Pinion coupler lever assembly (El0, E75)	1
0E11		0	2nd curtain pinion assembly (Ell, E32, E49)	1
E12	*	О	1st curtain pinion	1
E13		O	Coupler pinion	1
0E14		O	Bottom selector gear assembly (E14, E44, E73)	1
0E15		0	Top selector gear assembly (E15, E43, E70, E77, E84)	1
0E16		O	Bottom idling gear assembly (E16, E19)	1
E17		О	Top idling gear	1
0E18		O	Coupler gear assembly (E18, E45, E46)	1
E19	*	О	Idling gear collar	1
E20	*	О	Idling gear shaft	1
E21		O	Spill rest	1
E22	*	О	Spill rest collar	1
E23		О	Speed dial	1
E24		О	Index ring	1
E25		О	Selector collar	1
E26	*	0	Selector gear shaft	1
E27	*	0	Bulb lever shaft	1
F28	*	0	1st curtain checker arm seat	1

-18- 232

E29	O	Shutter rod	1
E30	O	Actuator rod	1
E31 *	О	1st curtain pinion shaft	1
E32 *	o	2nd curtain pinion shaft	1
E33 *	О	1st curtain shaft	1
E34	О	Curtain roller, small	1
E35 *	O	1st curtain wind shaft, top	1
E36 *	o	1st curtain wind shaft, bottom	1
E37 *	О	Curtain roller bearing	2
0E38	O	Curtain roller, large, assembly (E38, E37)	1
E39 *	O	2nd curtain pipe	1
E40 *	O	2nd curtain wind shaft bearing, bottom	1
E41 *	o	Wind shaft bearing	2
E42	0	Curtain spring adjust lug	2
E43 *	o	Top selector gear stud	1
E44 *	o	Selector gear retainer ring	1
E45 *	o	Slow speed lever actuator stud	1
E46 *	o	Coupler gear stud	1
E47 *	o	Edger rivet	4
E48	O	Bulb lever nut	1
E49 *	O	Pinion retainer pin	2
E50	O	Idling gear retainer screw	1
E51	o	1st curtain checker arm retainer screw	2
E52	O	Pinion coupler lever retainer screw	1
E53	o	Coupler gear retainer screw	.1
E54	O	Adjust lug screw	2
E55 *	0	Pinion shaft retainer screw (Only 2 supplied with 0E64)	3
E56	O	Cam shaft spring	1
E57	0	Shutter rod spring	1
E58	О	Spill spring	1
E59 *	O	2nd curtain spring	1

232 -19-

B60	0	Adjust lug spring A	1
E61	О	1st curtain checker arm spring	1
E62	О	Bulb lever spring	1
E63	O	Pinion coupler lever spring	1
0E64	0	1st curtain assembly (E64, E03, E12, E31, E33, E35, E36, E47, E49, E55, E90, E91, E95, E96)	1
0E65	0	2nd curtain assembly (E65, E04, E39, E40, E41, E47, E59, E67, E74, E94)	1
E66	О	Coupler lever spring hanger	1
E67 *	О	Curtain pipe	1
E68	a	Speed selector disc	1
E69 *	О	Cam shaft	1
E70 *	.3	Speed selector pin	1
E71 *	0	Bulb lever collar, top	1
E72 *	о .	Bulb lever collar, bottom	1
E73 *	О	Retainer ring rivet	1
E74 *	0	2nd curtain wind shaft metal, top	1
F75 *	О	Pinion coupler lever pin	1
E76 *	О	Cam shaft nut	1
E77 *	0	Selector gear stopper	1
E78 *	O	Bulb coupler spring	1
E79	O	Cam shaft spring receptacle	1
E80	O	'Cocked' indicator	1
E81 *	0	'Cocked' indicator shaft	1
E82	О	'Cocked' indicator spring	1
E83	O	Click spring	1
E84 *	O	Selector gear stopper rivet	1
0E85	O	High speed cam assembly (E85, E69, E76)	1
E96	0	1st curtain checker arm stopper	1
E87 *	0	Bulb lever adjust nut	1
E88		Coupler pinion screw	1
E89	0	2nd curtain shaft plate	1

-20- 232

E90 * o	1st curtain wind shaft bearing, top	1
E91 * o	1st curtain wind shaft bearing, bottom	1
E92 o	Curtain spring adjust gear A	1
Е93 о	Curtain spring adjust gear B	1
E94 * o	2nd curtain shaft	1
E95 * o	1st curtain pipe	1
E96 * o	1st curtain spring	1
E97 * o	Bounce stopper	1
E98 o	Bounce stopper actuator lever	1
E99 o	Bounce stopper lever	1
E100 o	Bounce stopper actuator lever screw	2
E101 * o	Bounce stopper rivet	1
E102 o	Bounce stopper spring	1
E103 o	Bounce stopper lever screw	1
0E104 o	Sync gear assembly (E104, E97. E101, E111, E115)	1
E105 o	Sync gear column	
E106 * o	X contact A	
0E107 o	X contact B assembly (E107, B64, B65, B66, E106, E108, E109, E112)	1
E108 * o	X contact seat	1
E109 * o	X insulator	1
El10 o	X contact support	1
E111 * o	X contact pin	1
El12 * o	X contact column	2
E113 o	X contact retainer screw	1
El14 o	Adjust lug spring B	1
E115 * o	Insulator tube	1
E116 o	Bounce stopper lever retainer	1
E117 o	Selector shaft tube retainer screw	1
El18 * o	Shutter rod receptacle	1
E119 o	Release plate nut	1
E120 * c	Gear shaft rivet	5

232 -21-

F01	0	Slow speed cam	1
0F02	0	Cam coupler plate assembly (F02, F10)	1
F03 o	, ,	Time stopper	1
0F04	0	Bottom adjust plate assembly (F04, F12)	1
0F05		Top adjust plate assembly (F05, F06, F07, F08, F09, F14, F15, F17, F19, W2)	1
F06 *	o	Slow speed actuator lever	1
F07 *	o	Slow speed lever	1
F08 *	0	Slow speed Jever collar	1
F09 *	0	Lever support nut (Only 1 supplied with 0F05)	2
F10 *	o	Cam coupler plate stud	1
F11 o	)	Cam coupler plate nut	1
F12 *	o	Slow speed rod	1
F13 o	)	Slow speed rod receptacle	1
F14 *	o	Lever support	1
F15 *	0	Slow speed lever seat	1
F16	0	Slow speed spring	1
F17 *	o	Slow speed actuator lever stud	1
F18 o	)	Adjust plate screw	1
F19 *	0	Slow speed lever retainer screw	1
F20	0 5	slsw speed cam retainer screw	2
0G00	0	Slow speed governor assembly (G01—G19)	1
AF12	0	Mirror	1
AF17	0	Pentaprism	1
AF18	0	Ground glass	1
0AF20	0	Magnifier front element assembly (AF20, 1AF21)	1
AF21 *	О	Magnifier rear element	1
. AF22	0	Fresnel lens	1

-22- 232

0H01	Self-timer box assembly (H01, H03, H04, H05, H06, H07, H08, H10, H45)	1
0H02	Self-timer box cover assembly (H02, H09)	1
Н03 •	Spring	1
H04 *	Self-timer box lug	1
H05 *	Self-timer box lug shaft	1
H06 *	Spring hanger	2
H07 *	Lug stopper	1
H08 *	Lug spring	1
H09 *	Cover stud	1
H10 *	Hook	1
H45 *	Hook retainer rivet	1
0H00	Self-timer governor assembly (H11-H44, H46)	1

232 -23-

# LIST OF STANDARD PARTS

Product No. 232

## **ASAHI PENTAX SV**

### **Small Screws**

Index No.	Name	_	Surface Treatment	Place of Use	Quantity
1	Flat medium	1.2x1.6	Nickel plated	G02, G13	2
			Black	E112, B77	2
	387		Black	G04. G14	2
2	"	1.4x1.2	Black	D01, D06	2
3	"	1.4x1.4	Black	F03. C02	2
24	"	1.4x1.8	Black	C82. C86	1
4	"	1.4x2	Black	A49, A50	2
				C82, C86	1
				A01. G01	2
				B52, B60	2
				B02. B22	2
5	"	1.4x3	Black	F04, F05	1
7	"	1.7x1.8	Black	B02, B47	1
				A01, A07	2
8	"	1.7x2	Black	A01, H12	2
				A01, A06	2
				A01, A53	1
9	<b>3</b> 1	1.7x2.5	Black	A01, A48	2
				A01, A89	1
				A01, E108	1
				AO1, E83	2
				A01, D04	2
				A01, C02	1
				B02, B25	2
				B01, B08	2

-24-

232

Index No.	Name	_	Surface Treatment	Place of Use Qu	iantity
11	Flat medium	1.7x3	Black	A01, B02	2
				A01, A08	1
				C16, C47	2
12	"	1.7x3.5	Black	C11, C42	1
13	"	1.7x5	Black	B01, B02	3
14	"	2 x 3	Black	C17, C24	1
15	"	2x4.5	Black	A01, C10	2
25	Round flat medium	1.4x2	Black	D02, H02	3
16	Saucer medium	1.7x2.2	Chrome plated	A04, A20	2
				A01, A28	2
17	"	1.7x3.5	Black	A01, C32	3
				A01, A20	2
				A01, A10	3
				C32, C34	3
18	"	2x3.5	Chrome plated	A01, A03	2
				A01, A04	2
19	Round saucer medium	1.7x3	Chrome plated	A01, A03	2
				A01, A05	4
20	Set flat	1.4x2.5	Nickel plated	E06A, E06B	1
21	"	1.7x4	Nickel plated	C01, B09, AF17	2
22	"	1.7x4.5	Nickel plated	A01, C11	1
26	Set tapered	1.4x1.6	Black	C39, C86	3
23	"	1.7x2	Nickel plated	A01, D04	2
				C17, C24	2
				E24, E26	3
				E23, E68	3

232 -25-

Washers (Note: Asterisk \* donote quantity which is subject to change.)

Code	Material	Thickness (mm)	Place of Use Qu	antity
W2	Steel	0.03, 0.05. 0.1	0H00	2*
			F09, F14	1*
	Brass	0.4	E10	1
W3	Steel	0.3	A51	2
		0.1	E18	1
			E99	1
	Phosphor-bronze	0.2	E98	2
W5	Steel	0.05, 0.1, 0.2	B02. B54, B55	1
			A01, A05	4*
W8	Phosphor-bronze	0.1	B02, B35	1
<b>W</b> 9	Brass	0.4	C70	1
W10	Steel	0.05	C26	1
W11	Phosphor-bronze	0.1. 0.15, 0.2, 0.5	A27	2*
			F12	1*
			E26	1*
W12	Phosphor-bron2e	0.05. 0.07, 0.1 I	B18, B35	1*
	1=1		B19. B35	1*
W13	Steel	0.3	A27	2
W14	Phosphor-bronze	0.15	A57	1
		0.1	E105	1
W16	Steel	0.05. Oil C35	C38	1
W17	Bakelite	0.4	C13, C31	1
	Steel	0.2	C14, C24	3
W18	Steel	0.1	D02. D09	1
W21	Steel	0.05. 0.1	C48	1
W22	Phosphor-bronze	0.7. 0.8	C30	1
W25	Phosphor-bronze	0.05. 0.1	D04	1*

-26- 232

### Lock Washers

Code	Material	Thickness (mm)	Place of Use	Quantity
LW10		0.2	C41	1
			C85	1
			B76	1
LW13		0.3	A45	1
			A57	1
			A58	1
			E33	1
			E94	1
			E105	1
			F12	1
LW17		0.4	E50	1
" (Bl	ack)	"	A36	2

232 -27-