

ZV-E10 II — FOCUS set it on a stand-in, and nothing moves it after

SET ONCE — IT RIDES IN CAMERA SET 1 / 2

 Focus	AF/MF › Focus Mode › Manual Focus
 Focus	Peaking Display › On
 Setup	Operation Customize › Custom Key/Dial Set. › Custom Button 1 = AF On Center Button = Focus Magnifier
 Setup	Touch Operation › Shooting Screen › Off
 Shooting	Shooting Option › Product Showcase: Off
 Shooting	Shooting Mode › Camera Set. Memory › 1 PAL 2 NTSC

Assign the two buttons with the switch on **MOVIE** — custom keys are stored per shooting mode. Movie has no AF-S, so MF is the only state that cannot refocus itself; AF On still works from inside it.

EVERY TAKE

1. **Frame first.**
2. Hold **C1** on the stand-in.
Let it settle. Release —
focus is frozen.
3. Press the **center button**,
magnify, check.

Never zoom after focusing. The kit PZ lens is not parfocal, so the zoom drags focus with it.

Focus again after any power cycle. The zoom retracts and does not come back where it was.

A lens with an AF/MF switch stays on AF. The lens overrides the body and would kill AF On.