


Lab - Implement MST

Topology



Objectives

Part 1: Build the Network and Configure Basic Device Settings and Interface Addressing

Part 2: Implement and Observe MST

Part 3: Configure, Tune and Verify Basic MST Operation

Background / Scenario

Cisco's Per VLAN Spanning Tree (PVST+) provides a significant step up from standard spanning tree in terms of flexibility. PVST+ allows each VLAN to have its own independent spanning tree, thereby making better use of available links in the network. A drawback to PVST+ is that there is an instance of PVST+ running for each VLAN in the network, regardless of whether there are different spanning-tree topologies required. This presents the potential for overwhelming the switch CPU and memory. Additionally, Cisco switches support a finite number of PVST instances. If more VLANs are created than there are PVST+ instances supported on a particular switch, some of the VLANs will not have any STP running, and therefore not have any switching loop protection. PVST+ and Rapid PVST+ are simply unusable in that kind of environment. Lastly, PVST+ and Rapid PVST+ are Cisco-proprietary protocols and generally unusable in mixed vendor environments.

Cisco was involved in the early development of Multiple Spanning Tree. MST was standardized as IEEE 802.1s in 2002 and merged into 802.1Q in 2005. MST is an open protocol derived from RSTP, sharing all its rapid convergence properties, and in fact, the only standardized spanning-tree protocol for VLAN-based networks supported by multiple vendors. MST is a compromise between common spanning-tree and per-VLAN spanning tree. An MST instance represents a unique spanning-tree topology. Multiple MST instances can be created to account for each of the required spanning-tree topologies in a network, and an arbitrary number of VLANs can be mapped to a single MST instance.

In this lab, you will set up two instances of MST, one for VLANs 2 and 3 and the other for VLANs 4 and 5. All other VLANs will be mapped to the default MST instance (also referred to as IST or Internal Spanning Tree).

Note: This lab is an exercise in deploying and verifying MST and does not reflect networking best practices.

Note: The switches used with CCNP hands-on labs are Cisco 3650 with Cisco IOS XE release 16.9.4 (universalk9 image) and Cisco 2960+ with IOS release 15.2 (lanbase image). Other routers and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and the output produced might vary from what is shown in the labs.

Note: Ensure that the switches have been erased and have no startup configurations. If you are unsure contact your instructor.

Required Resources

- 2 Switches (Cisco 3650 with Cisco IOS XE release 16.9.4 universal image or comparable)
- 1 Switch (Cisco 2960+ with Cisco IOS release 15.2 lanbase image or comparable)
- 1 PC (Windows with a terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet cables as shown in the topology

Instructions

Part 1: Build the Network and Configure Basic Device Settings and Interface Addressing

In Part 1, you will set up the network topology and configure basic settings.

Step 1: Cable the network as shown in the topology.

Attach the devices as shown in the topology diagram, and cable as necessary.

Step 2: Configure basic settings for each switch.

a. Console into each switch, enter global configuration mode, and apply the basic settings. The startup configurations for each device are provided below.

Switch D1

```
hostname D1
banner motd # D1, Multiple Spanning Tree #
spanning-tree mode rapid-pvst
line con 0
exec-timeout 0 0
logging synchronous
exit
interface range g1/0/1-24, g1/1/1-4, g0/0
shutdown
exit
interface range g1/0/1, g1/0/5-6
switchport mode trunk
no shutdown
exit
vlan 2
name SecondVLAN
```

```
exit
  vlan 3
    name ThirdVLAN
    exit
  vlan 4
    name FourthVLAN
    exit
  vlan 5
    name FifthVLAN
    exit
Switch D2
  hostname D2
  banner motd # D2, Multiple Spanning Tree #
   spanning-tree mode rapid-pvst
   line con 0
    exec-timeout 0 0
   logging synchronous
   interface range g1/0/1-24, g1/1/1-4, g0/0
    shutdown
    exit
   interface range g1/0/1, g1/0/5-6
    switchport mode trunk
   no shutdown
    exit
  vlan 2
    name SecondVLAN
    exit
  vlan 3
   name ThirdVLAN
    exit
  vlan 4
   name FourthVLAN
    exit
  vlan 5
    name FifthVLAN
    exit
Switch A1
   hostname A1
  banner motd # A1, Multiple Spanning Tree #
   spanning-tree mode rapid-pvst
   line con 0
    exec-timeout 0 0
    logging synchronous
```

```
interface range f0/1-24, g0/1-2
 shutdown
 exit
interface range f0/1-4
 switchport mode trunk
no shutdown
interface f0/23
 no shutdown
 exit
vlan 2
 name SecondVLAN
 exit
vlan 3
 name ThirdVLAN
 exit
vlan 4
 name FourthVLAN
 exit
vlan 5
 name FifthVLAN
 exit
```

- b. Set the clock on each switch to UTC time.
- c. Save the running configuration to startup-config.

Note: Outputs and Spanning Tree topologies highlighted in this lab may be different than what you observe using your own equipment. It is critically important for you to understand how Spanning Tree makes its decisions, and how those decisions impact the operational topology of the network.

Part 2: Implement and Observe MST

Step 1: Configure MST on D1 and D2.

In this step we will configure MST on D1 and D2 only. We will do this so we can observe their interaction with each other as well as their interaction with A1.

a. On D1 and D2, issue the command spanning-tree mode mst.

```
D1(config) # spanning-tree mode mst
```

b. At this point, with no MST-specific configuration, MST Instance 0 is operational for all VLANs. Issue the command **show spanning-tree** and you will see in the output that the spanning tree information is about MST 0. Issue the command **show spanning-tree mst** and you will see the MST-specific STP information that is specific to MST 0 only. Take note of the information displayed for interfaces g1/0/5 and g1/0/6 because they are connected to a switch that is not running MST. Their type is listed as P2p Bound (PVST).

```
D1# show spanning-tree
```

```
MST0
Spanning tree enabled protocol mstp
```

Root ID Priority 32768 d8b1.9028.af80 Address This bridge is the root Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec Bridge ID Priority 32768 (priority 32768 sys-id-ext 0) Address d8b1.9028.af80 Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec Interface Prio.Nbr Type Role Sts Cost Gi1/0/1 128.1 P2p Desg FWD 20000 Desg FWD 200000 128.5 P2p Bound(PVST) Gi1/0/5 Desg FWD 200000 128.6 P2p Bound(PVST) Gi1/0/6

D1# show spanning-tree mst

##### MST0 Bridge Root	vlans mapped: 1-4094 address d8b1.9028.af80 priority 32768 (32768 this switch for the CIST	sysid 0)
Operational Configured	hello time 2 , forward delay 15, max age 20, txhold hello time 2 , forward delay 15, max age 20, max ho	
Interface	Role Sts Cost Prio.Nbr Type	
Gi1/0/1 Gi1/0/5	Desg FWD 20000 128.1 P2p Desg FWD 200000 128.5 P2p	Bound (PVST)
Gi1/0/6	Desg FWD 200000 128.6 P2p	Bound (PVST)

c. The basic behavior of MST is the same as spanning tree, where a root bridge must be selected, then root ports, and finally best paths to the root bridge from all non-root bridges. In the current network, we can see that D1 has been elected the root bridge. The bridge priority defaults to 32768, so the election is based on D1 having a lower base MAC address. The switch elected as root may be different in your lab topology, but the rules for election remain the same. Issue the command **show spanning-tree root** on switch A1. Switch A1 is running five instances of spanning tree.

A1# show spanning-tree root

		Root	Hello	Max Fwd	
Vlan	Root ID	Cost	Time	Age Dly	Root Port
VLAN0001	32768 d8b1.9028.af80	19	2	20 15	Fa0/1
VLAN0002	32768 d8b1.9028.af80	19	2	20 15	Fa0/1
VLAN0003	32768 d8b1.9028.af80	19	2	20 15	Fa0/1
VLAN0004	32768 d8b1.9028.af80	19	2	20 15	Fa0/1
VLAN0005	32768 d8b1.9028.af80	19	2	20 15	Fa0/1

d. Issue the **show spanning-tree root** command on D2 and the output will be different. This is because with MST, only one instance of the spanning-tree algorithm runs, regardless of the number of VLANs mapped to it.

D2# show spanning-tree root

			Hello			
MST Instance	Root ID	Cost	Time	Age	Dly	Root Port
MST0	32768 d8b1.9028.af80	0	2	20	15	Gi1/0/1

e. Configure A1 to use MST.

A1(config) # spanning-tree mode mst

Part 3: Configure, Tune and Verify Basic MST Operation

In the last part, you configured all three switches to run MST. In this part, you will further configure, tune, and verify MST to support the unique topological requirements.

Step 1: Create and verify an MST configuration.

MST allows network engineers to reduce the load of the spanning-tree protocol while still providing unique spanning-tree topologies for groups of VLANs. MST configuration must be completed by hand on each switch individually.

Complete the following tasks on switch D1:

a. Enter MST configuration mode using the command spanning-tree mst configuration.

```
D1(config) # spanning-tree mst configuration
```

b. Configure an MST region name. Our example will be CCNPv8.

```
D1(config-mst) # name CCNPv8
```

c. Configure an MST configuration revision number. Our example will be 1.

```
D1(config-mst) # revision 1
```

d. Configure instance 1 to include VLAN 2.

```
D1(config-mst) # instance 1 vlan 2
```

e. Configure instance 2 to include VLAN 4.

```
D1(config-mst) # instance 2 vlan 4
```

f. Commit the configuration by typing exit and returning to global configuration mode.

```
D1(config-mst)# exit
D1(config)# end
```

g. Issue the command **show spanning-tree mst** to verify the configuration is in place.

Note: While in spanning-tree mst configuration mode, you can use the **show current** and **show pending** commands to view current and pending configuration settings.

D1# show spanning-tree mst

```
##### MSTO vlans mapped: 1,3,5-4094

Bridge address d8b1.9028.af80 priority 32768 (32768 sysid 0)

Root this switch for the CIST

Operational hello time 2 , forward delay 15, max age 20, txholdcount 6

Configured hello time 2 , forward delay 15, max age 20, max hops 20

Interface Role Sts Cost Prio.Nbr Type
```

Gi1/0/1 Gi1/0/5 Gi1/0/6	Desg		128.1 P2p 128.5 P2p 128.6 P2p
Bridge	vlans mapped: 2 address d8b1.9028.af80 this switch for MST1	priority	32769 (32768 sysid 1)
Interface	Role	Sts Cost	Prio.Nbr Type
Gi1/0/1 Gi1/0/5 Gi1/0/6	Desg	FWD 20000 FWD 200000	128.1 P2p 128.5 P2p 128.6 P2p
Bridge	vlans mapped: 4 address d8b1.9028.af80 this switch for MST2	priority	32770 (32768 sysid 2)
Interface		Sts Cost	Prio.Nbr Type
Gi1/0/1 Gi1/0/5 Gi1/0/6	Desg Desg	FWD 20000	128.1 P2p 128.5 P2p

h. This configuration does not propagate to other switches. Each switch exchanges digest information summarizing the VLAN-to-Instance mappings it has configured. If a switch receives a BPDU with a different digest, it assumes that the sender is in a different MST region. The output below is what A1 shows in the topology used to create this lab. Notice that the ports connected to D1 are classified as P2p Bound (RSTP).

A1# show spanning-tree mst

```
##### MSTO
          vlans mapped: 1-4094
           address f078.1647.4580 priority 32768 (32768 sysid 0)
Bridge
Root
           address d8b1.9028.af80 priority
                                         32768 (32768 sysid 0)
           port Fa0/3
                              path cost
                                         20000
Regional Root address d8b1.905d.c300 priority
                                         32768 (32768 sysid 0)
                              internal cost 200000 rem hops 19
Operational hello time 2 , forward delay 15, max age 20, txholdcount 6
Configured
          hello time 2 , forward delay 15, max age 20, max hops 20
Interface
             Role Sts Cost
                            Prio.Nbr Type
Altn BLK 200000 128.1 P2p Bound(RSTP)
             Altn BLK 200000 128.2 P2p Bound(RSTP)
Fa0/2
Fa0/3
            Root FWD 200000 128.3 P2p
Fa0/4
            Altn BLK 200000
                            128.4
                                    P2p
Fa0/23
            Desg FWD 2000000 128.23 P2p
```

Al# show spanning-tree mst configuration digest

Name []

```
Revision 0 Instances configured 1
```

Digest 0xAC36177F50283CD4B83821D8AB26DE62
Pre-std Digest 0xBB3B6C15EF8D089BB55ED10D24DF44DE

And here is the digest from D1:

D1# show spanning-tree mst configuration digest

```
Name [CCNPv8]
```

Revision 1 Instances configured 3

Digest 0xB41829F9030A054FB74EF7A8587FF58D Pre-std Digest 0x6C5B0D56DA63408ED96AA5F1C5356F98

As you can see here, the digest values are different.

 Configure MST on D1, change the revision number to 2 and add VLAN 3 to instance 1 and VLAN 5 to instance 2.

```
D1(config) # spanning-tree mst configuration
D1(config-mst) # show current
Current MST configuration
    [CCNPv8]
Name
Revision 1 Instances configured 3
Instance Vlans mapped
_____
      1,3,5-4094
1
D1(config-mst) # revision 2
D1(config-mst) # instance 1 vlan 3
D1(config-mst) # instance 2 vlan 5
D1 (config-mst) # show pending
Pending MST configuration
      [CCNPv8]
Revision 2 Instances configured 3
Instance Vlans mapped
      1,6-4094
       2-3
D1(config-mst)# exit
D1(config)# end
```

j. Now configure D2 and A1 with the same configuration settings (name CCNPv8, revision2, instance 1 vlans 2-3, instance 2 vlans 4-5). After completing the configuration on D2 and A1, the output of **show spanning-tree mst** on A1 should be similar to the following output. D1 in this case is the root for all 3 instances.

```
A1# show spanning-tree mst
```

##### MSTO	vlans ma	apped: 1,6-4	094		
Bridge	address	f078.1647.458	0 priority	У	32768 (32768 sysid 0)
Root	address	d8b1.9028.af8	<pre>0 priority</pre>	У	32768 (32768 sysid 0)
	port	Fa0/1	path cos	st	0
Regional Root	address	d8b1.9028.af8	0 priority	У	32768 (32768 sysid 0)
			internal	l cost	200000 rem hops 19
Operational	hello t	ime 2 , forwar	d delay 15,	, max a	ge 20, txholdcount 6
Configured	hello t	ime 2 , forwar	d delay 15,	, max a	ge 20, max hops 20
Interface	Role	Sts Cost	Prio.Nbr 7	Type	
Fa0/1	Root	FWD 200000	128.1 H	P2p	
Fa0/2	Altn	BLK 200000	128.2 H	P2p	
Fa0/3	Altn	BLK 200000	128.3 H	P2p	
Fa0/4	Altn	BLK 200000	128.4 H	P2p	
Fa0/23	Desg	FWD 2000000	128.23 H	P2p	
##### MST1	vlans ma	apped: 2-3			
Bridge	address	f078.1647.458	0 priority	У	32769 (32768 sysid 1)
Root	address	d8b1.9028.af8	0 priority	У	32769 (32768 sysid 1)
	port	Fa0/1	cost		200000 rem hops 19
Interface	Role	Sts Cost	Prio.Nbr 7	Туре	
Fa0/1	Root	FWD 200000	128.1 H	P2p	
Fa0/2	Altn	BLK 200000	128.2 I	P2p	
Fa0/3	Altn	BLK 200000	128.3 I	P2p	
Fa0/4	Altn	BLK 200000	128.4 I	P2p	
Fa0/23	Desg	FWD 2000000	128.23 I	P2p	
##### MST2		apped: 4-5			
Bridge	address	f078.1647.458	0 priority	У	32770 (32768 sysid 2)
Root	address	d8b1.9028.af8	0 priority	У	32770 (32768 sysid 2)
	port	Fa0/1	cost		200000 rem hops 19
		Sts Cost			
Fa0/1		FWD 200000			
		BLK 200000		-	
Fa0/3		BLK 200000		_	
Fa0/4		BLK 200000		_	
Fa0/23	Desg	FWD 2000000	128.23 H	P2p	

Step 2: Controlling the Root Bridge.

Just like with PVST+ and Rapid PVST+, the current root bridge was elected based on the lowest Bridge ID (consisting of the Priority, extended system ID equal to the VLAN ID, and base MAC address values).

With the priority and extended system IDs being identical, the root bridge's MAC is numerically smaller than the local bridge's MAC. The result is that in a completely un-configured network, one single switch will be elected as the root bridge. The resulting choice of switch may or may not be desirable.

With PVST+ or Rapid PVST+, root bridge selection is done for each VLAN. With MST, the root bridge is based on instances.

There are two basic ways to manipulate the configuration to control the location of the root bridge:

- The spanning-tree mst instance-id priority value command can be used to manually set a priority value
- The **spanning-tree mst** *instance-id* **root** { **primary** | **secondary** } command can be used to automatically set a priority value.

The difference between the two is the **priority** command will set a specific number (multiple of 4096) as the priority, while the **root primary** command will set the local bridge's priority to 24,576 (if the local bridge MAC is lower than the current root bridge's MAC) or 4096 lower than the current root's priority (if the local bridge MAC is higher than the current root bridge's MAC).

The logic behind this operation is straight-forward. The **root primary** command tries to lower the priority only as much as is needed to win the root election, while leaving priorities between 24576 and the default 32768 for use by secondary bridges. The command always takes the entire Bridge ID into account when computing the resulting priority value.

The **spanning-tree mst** *instance-id* **secondary** command will statically set the local bridge's priority to 28,672. In an otherwise unconfigured network where all switch priorities default to 32,768, the **root primary** command will set the priority on the switch to 24,576 (two increments lower than the default priority) while the **root secondary** command will set the priority on the secondary root to the 28,672 (one increment lower than the default priority).

a. Modify D1 and D2 so that D1 is elected the primary root bridge for MST Instance 1 and D2 is elected the primary root bridge for MST Instance 2. D1 should be elected as the secondary root bridge for MST Instance 2, and D2 should be elected as the secondary root bridge for MST Instance 1. You will need to make configuration changes on both D1 and D2. The commands used at D1:

```
D1(config) # spanning-tree mst 1 root primary
D1(config) # spanning-tree mst 2 root secondary
```

b. After you have configured both D1 and D2, go to A1 and issue the command **show spanning-tree root**. In this output, you will see the root bridges differentiated.

A1# show spanning-tree root

		Root	Hello	Max Fwo	d
MST Instance	Root ID	Cost	Time	Age Dly	Root Port
MST0	24576 d8b1.9028.af80	0	2	20 15	5 Fa0/1
MST1	24577 d8b1.9028.af80	200000	2	20 15	Fa0/1
MST2	24578 d8b1.905d.c300	200000	2	20 15	Fa0/3

From the above output, you can see that the root port for VLAN 1 is F0/1 and the root port for VLAN 2 is F0/3. A1 is the root bridge for MST Instance 0 in this example.

Step 3: Adjust port cost values to impact root and designated port selection.

As the network is implemented right now, there are two direct paths between switch A1 and the root bridge for each MST. Path and port costs are evaluated to determine the shortest path to the root bridge. In the case where there are multiple equal cost paths to the root bridge, additional attributes must be evaluated. In our case, the lower interface number (for example, F0/1) is chosen as the Root Port, and the higher interface number (for example, F0/2) is put into a spanning tree Blocking state.

You can see which ports are blocked with the **show spanning-tree** *vlan-id* command or the **show spanning-tree blockedports** command. For now, examine VLAN 1 on D1.

a. On A1, issue the commands show spanning-tree vlan 1 and show spanning-tree blockedports.

A1# show spanning-tree mst 1

```
##### MST1
           vlans mapped:
                        2-3
         address f078.1647.4580 priority 32769 (32768 sysid 1) address d8b1.9028.af80 priority 24577 (24576 sysid 1)
Bridge
Root
          port Fa0/1
                                         200000 rem hops 19
                             cost
Interface
            Role Sts Cost Prio.Nbr Type
____________
Fa0/1
             Root FWD 200000 128.1 P2p
            Altn BLK 200000 128.2 P2p
Fa0/2
Fa0/3
            Altn BLK 200000 128.3 P2p
Fa0/4
            Altn BLK 200000 128.4 P2p
           Desg FWD 2000000 128.23 P2p
Fa0/23
```

A1# show spanning-tree blockedports

Name	Blocked Interfaces List	
MST0	Fa0/2, Fa0/3, Fa0/4	
MST1	Fa0/2, Fa0/3, Fa0/4	
MST2	Fa0/1, Fa0/2, Fa0/4	

Number of blocked ports (segments) in the system: 9

As you can see, MST 1 has its Root Port on F0/1 and F0/2, F0/3, and F0/4 are Alternate Blocking Ports.

To manipulate which port becomes the Root Port on non-root bridges, change the port cost (a value between 1 and 200,000,000) or port priority value (a value between 0 and 240 in increments of 16). Remember that this change could have an impact on downstream switches as well.

Note: The changes you are about to implement are considered topology changes and could have a significant impact on the overall structure of the spanning tree in your switch network. <u>Do not make these changes in a production network without careful planning and prior coordination.</u>

b. On A1, shutdown interfaces F0/1 and F0/2, assign a new port cost of 1000 to F0/2 using the **spanning-tree mst 1 cost** *value* command, and then issue the **no shutdown** command on the ports.

```
A1# conf t
```

```
Enter configuration commands, one per line. End with CNTL/Z. Al(config) # interface range f0/1-2
Al(config-if-range) # shutdown
Al(config-if-range) # exit
Al(config) # interface f0/2
Al(config-if) # spanning-tree mst 1 cost 1000
Al(config-if) # exit
Al(config) # interface range f0/1-2
Al(config-if-range) # no shutdown
Al(config-if-range) # exit
```

c. Now verify that this impacts root port selection on A1 using the **show spanning-tree vlan 1** and **show spanning-tree blockedports** commands.

A1# show spanning-tree mst 1

#### MST1	vlans ma	apped	d: 2-3							
Bridge	address	f078	3.1647.4580) priorit	ΞY	32769	(32768	sysid	1)	
Root	address	d8b1	L.9028.af80) priorit	ΞY	24577	(24576	sysid	1)	
	port	Fa0,	/2	cost		1000	ren	n hops	19	
Interface	Role	Sts	Cost	Prio.Nbr	Type					
Fa0/1	Altn	BLK	200000	128.1	P2p					
Fa0/2	Root	FWD	1000	128.2	P2p					
Fa0/3	Desg	FWD	200000	128.3	P2p					
Fa0/4	Desg	FWD	200000	128.4	P2p					
Fa0/23	Desg	FWD	2000000	128.23	P2p					

A1# show spanning-tree blockedports

Name	Blocked	d Inter	faces List
MST0	Fa0/2,	Fa0/3,	Fa0/4
MST1	Fa0/1		
MST2	Fa0/1,	Fa0/2,	Fa0/4

Number of blocked ports (segments) in the system: 7

From the output, you can see that the root port selected by A1 for VLAN 1 is now interface F0/2, and the port (and root) cost is now 1000.

Step 4: Adjust port priority values to impact root port selection.

The next method to impact root port selection is configured on the root bridge itself. In our current network topology, A1 has two connections to the root bridge for MST Instance 2, switch D2. The root port has been selected, in this case based on the lowest port ID. Port ID is made up of two values, labeled as Prio (Priority) and Nbr (Number).

Note: The port number is not necessarily equal to the interface ID. A switch may use any port number for STP purposes as long as they are unique for each port on the switch.

The port priority can be any value between 0 and 240, in increments of 16 (older switches may allow setting the priority in different increments).

a. On A1, issue the command show spanning-tree mst 2 and take note of the port ID values listed.

A1# show spanning-tree mst 2

```
##### MST2
             vlans mapped:
             address f078.1647.4580 priority
Bridge
                                                  32770 (32768 sysid 2)
Root
             address d8b1.905d.c300 priority
                                                  24578 (24576 sysid 2)
                                                  200000
                                                            rem hops 19
             port
                   Fa0/3
                                    cost
Interface
                Role Sts Cost
                                 Prio.Nbr Type
```

Fa0/1	Altn	BLK	200000	128.1	P2p
Fa0/2	Altn	BLK	200000	128.2	P2p
Fa0/3	Root	FWD	200000	128.3	P2p
Fa0/4	Altn	BLK	200000	128.4	P2p
Fa0/23	Desg	FWD	2000000	128.23	P2p

As expected with two equal-cost paths to the root bridge, the lower port ID was selected as the root port.

b. Modify the port priority of D2 interface G1/0/6 so that it becomes the preferred port by issuing the **spanning-tree mst 2 port-priority** *value* interface configuration command. Use a value of 64.

```
D2# config t

Enter configuration commands, one per line. End with CNTL/Z.
D2(config)# interface range g1/0/5-6
D2(config-if-range)# shutdown
D2(config-if-range)# exit
D2(config)# interface g1/0/6
D2(config-if)# spanning-tree mst 2 port-priority 64
D2(config-if)# exit
D2(config-if)# exit
D2(config-if-range)# no shutdown
D2(config-if-range)# exit
```

c. On A1, issue the **show spanning-tree mst 2** command and you will see that Fa0/4 is now the selected root port. This selection is based on the lower priority value of D2 interface G1/0/6. Notice that the lower priority value does not appear in any A1 output.

A1# show spanning-tree mst 2

```
##### MST2
           vlans mapped:
                       4-5
           address f078.1647.4580 priority
Bridge
                                         32770 (32768 sysid 2)
Root
           address d8b1.905d.c300 priority
                                         24578 (24576 sysid 2)
           port
                 Fa0/4
                              cost
                                         200000 rem hops 19
Interface
             Role Sts Cost
                            Prio.Nbr Type
Fa0/1
             Altn BLK 200000
                            128.1
                                   P2p
Fa0/2
             Altn BLK 200000
                            128.2
                                   P2p
Fa0/3
             Altn BLK 200000
                            128.3
                                   P2p
Fa0/4 Root FWD 200000 128.4 P2p
             Desg FWD 2000000
Fa0/23
                           128.23
                                   P2p
```