

Scotch Tape here after leveling and aligning the pieces

- 1. Place the stencil on the wall
 - 2. Level it with bubble leveler
 - 3. Place the Blaze Art to make sure its leveled and looks good
 - 4. Tape the stencil, so you have the outline where the drills should be
 - 5. At least 2 pieces need to be drilled and hooked for stability.
- After attaching the remaining ones using Magnetic Modular System, please check for stability. For larger collages, its recommended to hook more than 2 pieces for safety.

