
ATX 4pin power header/connector



Teensy 3.x header (also compatible with Teensy 4.0)




Jumper to connect V3.3 to AREF (not used for Teensy 4.0)




Header to connect GND to AGND (not needed in practice?)




Fan headers



Thermistor sensor headers



Decoupling capacitors



Fan RPM signal diodes (incase fans have own pull-up resistors)





Equivilent series resistors for thermistors

(1% resistors, same resistance as thermistor nominal resistance)

