Remediation Solution for groundwater contamination

Miami, Florida site

Jack Lange 3/2/18

Table of Contents

Cover letter	3
Conclusions	4
Appendix 1 – Figures	5
Appendix 2 – Code	Ć
Appendix 3 – References	1 1

Jack Lange
Earth Science dept
University of Minnesota
Minneapolis, MN 55455
3/2/18
Site owner
Miami, Fl
Dear site owner,
Thank you for choosing Lange's Remediation for this project. A report detailing my proposed remediation strategy for the Miami, Florida groundwater contamination site is attached. You wil find a summary of our solution in the executive summary.
If you have any questions, please feel free to contact me.
Yours truly,
Jack Lange

Executive Summary

This proposed solution address the problems of contaminated groundwater in the northwest portion of the site as well as the low levels of contamination found throughout the site. In order to isolate the contaminated groundwater under your property I propose the installation of a pumping well and a recharge pond on the property. The pond and well will be placed parallel to the natural groundwater flow in the area. The pumping well will draw water from the aquifer and deposit the water in the recharge pond, which will return the water to the aquifer. The water that returns to the aquifer will again be captured by the well, and in this way the contaminated groundwater under your property will be isolated from the surrounding aquifer.

Water that is pumped by the well can be treated on site to remove contaminants before it is returned to the ground. This process will clean up the low levels of contamination that is found through the site.

A groundwater model was used to determine the optimal placement of the well and the recharge pond. In order for the well to capture only water from the recharge pond, rather than the surrounding aquifer, and for the well to capture all of the groundwater under the site, I recommend placing the well south east of the shed and the pond between the tank and the shed.

Analysis

The installation of a pumping well and a recharge pond on the property is recommended to address the issue of contaminated groundwater at the site. The natural groundwater flow in the area of the site is 11.5 square feet per day towards the east. In order to prevent the contamination that is present under the site from spreading, the water underneath the site must be contained and treated. A simple and effective method for containing groundwater in a field of uniform flow is by using a recharge point placed upstream in the flow field, and a discharged point placed downstream, in line with the flow field. Water that is removed from the aquifer at the discharge point can be returned to the aquifer at the recharge point, and the captured again at the discharge point. If the distance between the recharge and discharge points is controlled, and the discharge/recharge rates are equal then the discharge point will capture all of the water from the recharge point, and only the water from the recharge point. A mathematical formulation for this solution can be found in 8.8.4 of *Analytical Groundwater Mechanics*.

An analytical model was used to determine the optimal arrangement of a discharge well and a recharge point. The optimal arrangement at this site is one which requires the lowest pumping rate to isolate all of the water under the site. The code for the model is located in appendix 2. The optimal location for the discharge point is (200,57) and the recharge point is (-9,57). The coordinates correspond to the coordinate system provided with the project map. In this arrangement, a pumping rate of 15000 cubic feet per day will ensure that contaminated water stays contained at the site, as show in figure 1.

The simplest and most cost effective option for the discharge point is an infiltration pond. An infiltration pond with radius 19 feet will fit at the discharge point and will allow the appropriate infiltration rate.

Appendix 1 – Figures




Figure 1: Streamlines for the case of pumping 14000 cubic feet per day from a well located at (200,57) and depositing the water into an infiltration pond of radius 19 feet, located at (-9,57). The property is enclosed by streamlines originating at the infiltration pond and terminating at the pumping well indicating that groundwater will not escape from the site.




Figure 2: Head contours for the case of pumping 14000 cubic feet per day from a well located at (200,57) and depositing the water into an infiltration pond of radius 19 feet, located at (-9,57).

Appendix 2 – Methods

The suggested solution was obtained using the analytic element groundwater modeling technique. The complex potential used to describe this modeling problem included the uniform flow term, an infiltration pond, and a well. The constant term in the potential was determined based on the far field condition that head is 1.8 feet above sea level 1000 feet east of the origin. A contouring routine was used to evaluate the solution and the resulting figures are shown in appendix 1. The code for the model and the contouring routines are available in appendix 3.

Several pond-well arrangements were tried manually. The size of the pond was varied, as well as the location of the pond and the pump. The arrangement which required the least pumping to contain all of the groundwater at the site was chosen and discussed in the conclusion.

Appendix 3 - Code

```
Runfile.m
                        z1= 200 + i*57; %pump out location
                        z2=-9+i*57; %pond location
                         Qx0 = 11.5; %ft/day
                        rp = 19;%pond radius ft
                        K = 58.6; %ft/day
                        Q = 14000; %ft^3 per day
                        N = Q/(rp*rp*3.1415); %infiltration rate, feet per day
                        rw = .3; %well radius, feet
                         %constant calculation, at x=1000 \text{ re(omega)} = 1.8*1.8*K*0.5
                        C = 1.8*1.8*K*.5 -real(Omega_total(1000,Qx0,Q,z1,z2,rw,rp,N));
ContourMe_flow_net_site(-200,400,800,-
                        200,400,800,@(z)Omega total(z,Qx0,Q,z1,z2,rw,rp,N),100);
                         %ContourMe R int(-200,1000,200,-200,400,200,
                        @(z) Omega to phi UNC (Omega total(z,Qx0,Q,z1,z2,rw,rp,N)+C,K),25);
ContourMe_flow_net_site.m
                         function [Grid] = ContourMe flow net site(xfrom, xto, Nx, yfrom, yto, Ny,
                         func, nint)
                        Grid = zeros(Ny,Nx);
                        X = linspace(xfrom, xto, Nx);
                        Y = linspace(yfrom, yto, Ny);
                         for row = 1:Ny
                             for col = 1:Nx
                                 Grid(row,col) = func( complex( X(col), Y(row) ) );
                        end
                        Bmax=max(imag(Grid));
                        Bmin=min(imag(Grid));
                        Cmax=max(Bmax);
                        Cmin=min(Bmin);
                        D=Cmax-Cmin;
                        del=D/nint;
                        Bmax=max(real(Grid));
                        Bmin=min(real(Grid));
                        Cmax=max(Bmax);
                        Cmin=min(Bmin);
                        D=Cmax-Cmin;
                        nintr=round(D/del);
                        figure;
                        hold on
                        contour(X, Y, real(Grid), nintr, 'r');
                        contour(X, Y, imag(Grid), nint, 'b');
                        legend('Equipotentials','Streamlines')
                        axis square
                        axis equal
                        %Burris boundary
                        x=[-54,234,234,210,210,-45,-45,-54,-54];
                        y=[190,190,37,-62,-86,-86,25,98,190];
                        plot(x,real(y),'k', 'LineWidth', 4)
                        hold on
                         %Injection FTWR ehse
                        x= [112, 213, 213,112,112];
                         y = [190, 190, 89, 89, 190];
```

```
plot(x,real(y),'k', 'LineWidth', 2)
                         hold on
                         %Office-Shed
                        x = [27, 176, 176, 27, 27];
                        y= [88,88,68,68,88];
                        plot(x,real(y),'k', 'LineWidth', 2)
                        hold on
                         %Burris WHSE
                         x = [25, 56, 56, 159, 159, 187, 187, 56, 56, 25, 25];
                        y= [37,37,44,44,-2,-2,-61,-61,-38,-38,37];
                        plot(x,real(y),'k', 'LineWidth', 2)
                        hold on
                         %Tank farm
                        x = [-52, -48, -10, -6, -6, -14, -30.5, -30.5, -42.5, -42.5, -52, -52];
                        y= [175,179,179,175,97,90,90,47,47,90,97,175];
                        plot(x,real(y),'k', 'LineWidth', 2)
                        hold on
                         %South SW drain
                        x=[31,36,36,31,31];
                        y = [30, 30, -25, -25, 30];
                        plot(x,real(y),'k', 'LineWidth', 2)
                        hold on
                         %Norht SW drain
                        x = [44,70,70,44,44];
                        y= [142,142,135,135,142];
                        plot(x,real(y),'k', 'LineWidth', 2)
                        hold on
                         %hold on
                         %contour(X, Y,real(Grid),nintr);
%contour(X, Y,imag(Grid),nint);
                         %axis equal
                         function [Grid] = ContourMe R int(xfrom, xto, Nx, yfrom, yto, Ny, func, nint)
ContourMe_R_int.m
                         Grid = zeros(Ny, Nx);
                        X = linspace(xfrom, xto, Nx);
                         Y = linspace(yfrom, yto, Ny);
                         for row = 1:Ny
                             for col = 1:Nx
                                 Grid(row,col) = func( complex( X(col), Y(row) ) );
                         end
                         contour(X, Y, real(Grid), nint);
                         axis equal
                        hold on
                         colorbar
                         %Burris boundary
                        x=[-54,234,234,210,210,-45,-45,-54,-54];
                        y=[190,190,37,-62,-86,-86,25,98,190];
                        plot(x,real(y),'k', 'LineWidth', 4)
                         hold on
                         %Injection FTWR ehse
                        x=[112, 213, 213, 112, 112];
                        y= [190,190,89,89,190];
                        plot(x,real(y),'k', 'LineWidth', 2)
                        hold on
                         %Office-Shed
                         x=[27,176,176,27,27];
                        y= [88,88,68,68,88];
                        plot(x,real(y),'k', 'LineWidth', 2)
                         hold on
                         %Burris WHSE
                        x = [25, 56, 56, 159, 159, 187, 187, 56, 56, 25, 25];
                        y= [37,37,44,44,-2,-2,-61,-61,-38,-38,37];
                        plot(x,real(y),'k', 'LineWidth', 2)
```

```
hold on
                          %Tank farm
                          x = [-52, -48, -10, -6, -6, -14, -30.5, -30.5, -42.5, -42.5, -52, -52];
                          y= [175,179,179,175,97,90,90,47,47,90,97,175];
                          plot(x,real(y),'k', 'LineWidth', 2)
                          hold on
                          %South SW drain
                          x = [31, 36, 36, 31, 31];
                          y=[30,30,-25,-25,30];
                          plot(x,real(y),'k', 'LineWidth', 2)
                          hold on
                          %Norht SW drain
                          x = [44,70,70,44,44];
                          y= [142,142,135,135,142];
                          plot(x,real(y),'k', 'LineWidth', 2)
                          hold on
Omega_pond.m
                          function [ Omega ] = Omega pond(z,z0,rp,Q, N)
                          rsq=(z-z0)*conj(z-z0);
                          if rsq>rp^2
                              Omega=-(Q/(2*pi))*log((z-z0)/rp);
                              Omega=-(1/4)*N*((z-z0)*(conj(z)-conj(z0))-rp*rp);
Omega_Uniformflow.m
                          function [ Omega ] = Omega Uniformflow (Qx0,z)
                          Omega = -Qx0*z;
                          end
                          function [ Omega ] = Omega_well(z,z0,rw,Q)
Omega_well.m
                          rsq=(z-z0)*conj(z-z0);
                          if rsq>rw^2
                              Omega=Q/(2*pi)*log(z-z0);
                              Omega = 0;
                          end
Omega_to_phi_UNC.m
                          function [ phi ] = Omega to phi UNC (Omega, K)
                          phi = sqrt(2*real(Omega)/K);
                          end
                          function [ Omega ] = Omega total(z, Qx0,Q, z1,z2,rw,rp,N)
Omega_total.m
                           \label{eq:constraints}  \mbox{Omega=Omega Uniformflow}(\mbox{Qx$\overline{0}$},z) \ + \mbox{Omega well}(z,z1,rw,Q) \ + \mbox{Omega pond}(z,z2,rp,Q,r) 
                          N);
                          end
```

Appendix 3 - References

1. Strack, Otto D. L. Analytical Groundwater Mechanics. Cambridge University Press, 2017.