Week 1 – Number Systems

Section 1.1-1.3

Analog vs Digital


Section 1.1 – 1.2

Analog vs Digital

Analog: system can take on a "continuous" set of values



• Digital: system can take on fixed or "discrete" set of values





Digital Logic

• Computer systems are built on "Boolean" or digital logic

All values in the system are either '1' or '0'

• Because the system uses Boolean logic, certain properties can be established for each "layer" in the computer.

Layers of Abstraction in Computing

Algorithms

Programming Languages

Operating Systems

Instruction Set Architecture


Microarchitecture

Register Transfers

Logic Gates

Transistor Circuits


Layers of Abstraction in Computing




Copyright ©2016 Pearson Education, All Rights Reserved


All <u>information</u> in a computing system must have some representation

Each representation can "appear" difference but represents the same underlying information



AAA













Binary and Encodings

All information in a computer is stored as digital 1's and 0's

Various encoding schemes and number systems to represent information

ASCII Encoding Table

k 🔀

z#108 •

```
61 141 @#97:
   62 142 4#98;
   63 143 4#99;
99
   64 144 d <mark>d</mark>
100
   65 145 e e
101
   66 146 f f
102
   67 147 @#103; g
103
   68 150 h h
104
   69 151 i <u>i</u>
105
   6A 152 j
106
```

107

6B 153

100 GC 154


Number Systems

Section 1.3

Bases and Number Systems

• All number systems have a base, digit, and exponent representation

$$digit * base^{exp}$$



Expanded Representation

• All numbers are formed by summing each digit, base, and exponent

$$10524 = 1 * 10^4 + 0 * 10^3 + 5 * 10^2 + 2 * 10^1 + 4 * 10^0$$

- For any number, you should be able to identify the digit, position, and base.
 - Example: 47,586

Num. 4 7 5 8 6 Pos. $10^4 10^3 10^2 10^1 10^0$

Example

- Write out the following values in an expanded form some each digit, base, and exponent summed together.
 - Hint: don't forget the 0's

• 54,087

• 1001

Example

- Write out the following values in an expanded form some each digit, base, and exponent summed together.
 - Hint: don't forget the 0's

• 54,087=5 *
$$10^4 + 4 * 10^3 + 0 * 10^2 + 8 * 10^1 + 7 * 10^0$$

•
$$1001=1*10^3+0*10^2+0*10^1+1*10^0$$

Base-10 and Other Systems

• Our decimal system is a Base-10 system. However other bases are possible. The Babylonians used base 60.

•
$$45_{10} = 63_7 = 6 * 7^1 + 3 * 7^0$$

•
$$525_{10} = 1350_7 = 1 * 7^3 + 3 * 7^2 + 5 * 7^1 + 0 * 7^0$$

Binary and Computing Systems

• Computer systems are built on a binary system of 1' and 0' values. Foundation of digital/Boolean logic.

- Only allowable digits in binary are {0,1}
- Binary is a Base-2 system. Later we will focus on Hexadecimal (base-16) and octal (base-8).
- Should memorize all base-2 powers up to 2^12
 - 2^0 = 0, 2^1 = 2, 2^2=4...etc.

Binary to Decimal Conversion

- Goal is to find a base-2 representation of a base-10 number.
 - $135_{10} = ?*2^3 + ?*2^2 + ?*2^1 + ?*2^0$
- The sequence of *bits* {0,1} is our binary representation of that decimal number.
 - $13_{10} = 1 * 2^3 + 1 * 2^2 + 0 * 2^1 + 1 * 2^0 = 1101_2$
- Need sufficient number of "bits" to represent the decimal number.
 - N-bits allows representation of 2^N-1decimal value
 - 3-bits => 7; 4-bits => 15...etc.

Decimal to Binary: Subtraction Method

Various methods from converting to decimal to binary

Subtraction method:

- 1. Select a number of bits (N) for your value. Keep running tally of your number.
- 2. Select the highest binary position that is just less than the number
- If number > 2^position, then subtract 2^position from the number. Mark a 1.
 Otherwise Mark a 0
- 4. Repeat (2) until running tally is 0.

Example Binary to Decimal Conversion: Subtraction Method

Bits:	1	0	1	0	1
Pos.	4	3	2	1	0
Value.	16	8	4	2	1

Bits:	0	1	1	0	1
Pos.	4	3	2	1	0
Value.	16	8	4	2	1

Bits:	1	1	0	1	1
Pos.	4	3	2	1	0
Value.	16	8	4	2	1

Decimal to Binary: Addition Method

• Another method called the "addition" method is possible. Most prefer "subtraction" but use what you want.

Addition method:

- 1. Select a number of bits (N) for your value. Keep running tally called *sum*.
- 2. Select the highest binary position that is just less than the number
- 3. If 2^pos > sum, mark 0. Else, mark 1 and add 2^pos to sum
- 4. Repeat (2) until sum is desired value.

Example Binary to Decimal Conversion: Addition Method

30					
Bits:	1	1	1	1	0
Pos.	4	3	2	1	0
Value.	16	8	4	2	1

Bits:	1	0	0	0	1
Pos.	4	3	2	1	0
Value.	16	8	4	2	1

Bits:	0	0	1	1	0
Pos.	4	3	2	1	0
Value.	16	8	4	2	1

Practice

• Convert the following decimal values into binary:

• 25₁₀

• 11₁₀

• 718₁₀

Practice

• Convert the following decimal values into binary:

•
$$25_{10} = 11001_2$$


•
$$11_{10} = 1011_2$$

•
$$718_{10} = 10\ 1100\ 1110_2$$

MSB and LSB

• In a binary representation there are two "special" bits called the *most significant bit (MSB)* and the *least significant bit* (LSB).

 Not there either is more/less important, just that this bit carries the largest/smallest value



Binary to Decimal Conversion

18 = 16 + 2

• Reverse process from Decimal to Binary. Sum the values of each position.

23 = 16 + 4 + 2 +1						
Bits:	1	0	1	1	1	
Pos.	4	3	2	1	0	
Value.	16	8	4	2	1	

Bits: 1 0 0 1 0					
Bits:	1	0	0	1	0
Pos.	4	3	2	1	0
Value.	16	8	4	2	1

4 = 4							
Bits:	0	0	1	0	0	ľ	
Pos.	4	3	2	1	0		
Value.	16	8	4	2	1		

Example Binary to Decimal

• With a friend, convert the following values from binary into decimal

- 01 0101₂
- 10 1111₂
- 1 0111 0111₂

Example Binary to Decimal

• With a friend, convert the following values from binary into decimal

•
$$01\ 0101_2 = 16 + 4 + 1 = 21_{10}$$

• 1 0111 0111₂ = 256 + 64 + 32 + 16 + 4 + 2 + 1 =
$$375_{10}$$

Base-8 and Base-16 Systems

• Other representations of binary systems are possible. Some may be

familiar to you.

A problem has been detected and Windows has been shut down to prevent damage to your computer.

The problem seems to be caused by the following file: kbdhid.sys

MANUALLY_INITIATED_CRASH

If this is the first time you've seen this stop error screen, restart your computer. If this screen appears again, follow these steps:

Check to make sure any new hardware or software is properly installed. If this is a new installation, ask your hardware or software manufacturer for any Windows updates you might need.

If problems continue, disable or remove any newly installed hardware or software. Disable BIOS memory options such as caching or shadowing. If you need to use safe mode to remove or disable components, restart your computer, press F8 to select Advanced Startup Options, and then select Safe Mode.

Technical Information:

*** kbdhid.sys - Address 0x94efd1aa base at 0x94efb000 DateStamp 0x4a5bc705

Base-16 Hexadecimal

• Takes binary representation of a number and groups into four bits

• Re-encodes each four bits as a number or letter [0-9,A-F].

Allows for easier expression of large binary values

Hexadecimal / Binary Table

Decimal	Hex	Binary
0	0x0	0000
1	0x1	0001
2	0x2	0010
3	0x3	0011
4	0x4	0100
5	0x5	0101
6	0x6	0110
7	0x7	0111

Decimal	Hex	Binary
8	0x8	1000
9	0x9	1001
10	0xA	1010
11	0xB	1011
12	0xC	1100
13	0xD	1101
14	0xE	1110
15	0xF	1111

Binary to Hexadecimal Example

• To "convert" a binary value to hex, simple group the bits and replace with hex digit

- 1101 1100 1111 0001 => 0xDCF1
- 0001 1010 0110 0011 => 0x1A63

Hexadecimal to Binary Example

Opposite process, however leave space for 0's!!

• 0x24AF3 => 0010 0100 1010 1111 0011

• $0x24AF3 \neq 0010\ 0100\ 1010\ 1111\ 11$

Base – 8 Octal

• Another representation you may encounter is *Octal*. Similar to hex but groups bits into three's.

Decimal	Hex	Binary	Octal
0	0x0	0000	0
1	0x1	0001	1
2	0x2	0010	2
3	0x3	0011	3
4	0x4	0100	4
5	0x5	0101	5
6	0x6	0110	6
7	0x7	0111	7

Decimal	Hex	Binary	Octal
8	0x8	1000	10
9	0x9	1001	11
10	0xA	1010	12
11	0xB	1011	13
12	0xC	1100	14
13	0xD	1101	15
14	0xE	1110	16
15	0xF	1111	17

Never encountered personally, but exists somewhere

Definitions and Rules

- Each digit of a binary value is a bit. One byte is 8-bits.
- Length/size of binary values determined by *bit-width*. 3-bit value, 7-bit value...etc.
 - 00010 is five bits; 010 is three bits
- An n-bit value can represent $[0:2^n-1]$ values
- Computing systems have various word sizes based upon the largest register bit width. (Modern systems are 64-bit words).