

Fabric Calculation Sheet Explanation

We use an Excel worksheet to efficiently process orders by converting raw window measurements into optimized groups for cutting fabric into roller blinds.

A		B		C		D		E		F		G		H		I		J		K		L		M		N		O		P		Q		R		S		T		U																					
LOCATION		Window size (in Millimeters)				AFTER DEDUCTIONS				CONTROL				ROLLS				AFTER DEDUCTIONS				CHAIN				CONTROL				ROLLS				LOCATION				Width				Drop				TOTAL FABRIC REQUIRED				Chain				CONTROLS				ROLLS			
		Width		Drop		Chain size		Width		Drop				ROLLS		Location		Width		Drop		Chain		CONTROL		ROLLS								TOTAL FABRIC REQUIRED		Chain		CONTROLS		ROLLS																					
1		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
2		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
3		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
4		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
5		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
6		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
7		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
8		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
9		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
10		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
11		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
12		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
13		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
14		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			
15		1500mm		30		250		30		250				0		0		30		250		1500mm		0		0																																			

This is the fabric calculation section of the sheet, designed to accommodate an unlimited number of blinds for each job. To build an effective inventory management system for the website, it's crucial to understand how we calculate the fabric needed for each order. This ensures the system can accurately allocate the required fabric, update stock levels in real time, and determine how much additional stock is needed to prevent shortages. By doing so, we can avoid delays in fulfilling future orders.

We receive blinds orders in the following form as an example.

Number	Location	Width	Drop	Group	Fixing	Control	Control Colour	Chain	Roll	Fabric	Colour	Bottom Rail Type	Bottom Rail Colour	Sub-Total	Discount (%)	Cost
1	Bed 1	1450	1452	1	Recess	Left	White	Metal	Front	Avoca	Grey	D30/Square	Anodised	\$ 79.80	5%	\$ 75.81
2	Bed 2	1540	1550	1	Recess	Right	White	Metal	Front	Avoca	Grey	D30/Square	Anodised	\$ 88.20	5%	\$ 83.79
3	Bed 3	1091	1023	1	Recess	Right	White	Metal	Front	Avoca	Grey	D30/Square	Anodised	\$ 63.00	5%	\$ 59.85
4	Laundry	1300	1500	1	Face	Left	White	Metal	Front	Avoca	Grey	D30/Square	Anodised	\$ 82.95	5%	\$ 78.80
5	Living A	2300	1500	1	Face	Left	White	Metal	Front	Avoca	Grey	D30/Square	Anodised	\$ 135.45	5%	\$ 128.68
6	Living B	500	1500	1	Face	Left	White	Metal	Front	Avoca	Grey	D30/Square	Anodised	\$ 60.90	5%	\$ 57.86
7	Dining	200	1650	1	Face	Right	White	Metal	Front	Avoca	Grey	D30/Square	Anodised	\$ 60.90	5%	\$ 57.86
8	Sliding A	1200	1650	1	Face	Left	White	Metal	Front	Avoca	Grey	D30/Square	Anodised	\$ 75.60	5%	\$ 71.82
9	Sliding B	1200	1650	1	Face	Left	White	Metal	Front	Avoca	Grey	D30/Square	Anodised	\$ 75.60	5%	\$ 71.82
10	Study	400	1000	1	Recess	Left	White	Metal	Front	Avoca	Grey	D30/Square	Anodised	\$ 56.70	5%	\$ 53.87
11	Bed 4	1700	1800	1	Face	Right	White	Metal	Front	Avoca	Grey	D30/Square	Anodised	\$ 102.90	5%	\$ 97.76
12	Bath	500	800	1	Face	Left	White	Metal	Front	Avoca	Grey	D30/Square	Anodised	\$ 56.70	5%	\$ 53.87

This is our order sheet. We receive orders in this format.

Number	Location	Width	Drop
1	Bed 1	1450	1452
2	Bed 2	1540	1550
3	Bed 3	1091	1023
4	Laundry	1300	1500
5	Living A	2300	1500
6	Living B	500	1500
7	Dining	200	1650
8	Sliding A	1200	1650
9	Sliding B	1200	1650
10	Study	400	1000
11	Bed 4	1700	1800
12	Bath	500	800

These four columns show the blind number, the name or location of the blind, and the width and drop of the window. These are the raw measurements provided to us.

Group	Fixing	Control	Control Colour	Chain
1	Recess	Left	White	Metal
1	Recess	Right	White	Metal
1	Recess	Right	White	Metal
1	Face	Left	White	Metal
1	Face	Left	White	Metal
1	Face	Left	White	Metal
1	Face	Right	White	Metal
1	Face	Left	White	Metal
1	Face	Left	White	Metal
1	Recess	Left	White	Metal
1	Face	Right	White	Metal
1	Face	Left	White	Metal

These five columns display the selected fabric group. By referring to the price lists, you can see how the fabric group determines the cost of the blind. The fixing type either recess or face indicates whether the blind will be mounted inside the window frame or on its surface. The control position, left or right, is important as it specifies the side where the customer wants the chain. Additionally, we offer several colour options for control mechanisms and chain colours.

[illegible]

Our inventory management system should be able to calculate how much fabric is required for each customer order and allocate that fabric from our inventory. If there isn't enough fabric available, we must be notified immediately. After the job is completed, the amount of fabric used, for example 9 meters in the above example should be subtracted from the inventory so that we can accurately track the remaining stock for future jobs.

If you view the tabs in the excel document you will also see how the chain sizes are calculated according to the drop of the blinds.