# SP-601H

## User's Manual

## Edition 1.1

2009/08/24



#### Copyright

Copyright 2008 all rights reserved. This document is copyrighted and all rights are reserved. The information in this document is subject to change without prior notice to make improvements to the products.

This document contains proprietary information and protected by copyright. No part of this document may be reproduced, copied, or translated in any form or any means without prior written permission of the manufacturer.

All trademarks and/or registered trademarks contains in this document are property of their respective owners.

#### Disclaimer

The company shall not be liable for any incidental or consequential damages resulting from the performance or use of this product.

The company does not issue a warranty of any kind, express or implied, including without limitation implied warranties of merchantability or fitness for a particular purpose.

The company has the right to revise the manual or include changes in the specifications of the product described within it at any time without notice and without obligation to notify any person of such revision or changes.

#### **Trademark**

All trademarks are the property of their respective holders.

Any questions please visit our website at http://www.commell.com.tw.

## **Packing List:**

Hardware:

SP-601H PCI Capture Card x 1

Cable kit:

## **D-SUB 25 Cable x 1 (Optional)**



16 Channel video inputs Cable x 1



## 16 Channel audio inputs Cable x 1 (Optional)




**CD** Content:

**Drivers & User's Manual** 


## 1.0 < Product Specification>

General Specification			
Form Factor	PCI Capture Card		
Video Decode Chipset	Softlogic solo6010-16		
Accessories	1 x 16 Channel video inputs Cable		
	1 x 16 Channel audio inputs Cable (optional)		
	1 x 20-pin header to D-SUB 25 Cable (optional)		
Features	MPEG4 hardware compression Video Capture Card		
	16 Channel Video & Audio inputs		
	MAX resolution: NTSC at 704*480		
	PAL at 704*576		

## 1.1 < Component Placement>



## 1.2 < Mechanical Drawing>



### 1.3 < Connector Reference>

Connector: J5 (16 channel audio Input) Type: 20-pin (10x2) header(2.54mm) X 1

Pin	Description	Pin	Description
1	Audio Input Ch 9	2	Audio Input Ch 1
3	Audio Input Ch 10	4	Audio Input Ch 2
5	Audio Input Ch 11	6	Audio Input Ch 3
7	Audio Input Ch 12	8	Audio Input Ch 4
9	Audio Input Ch 13	10	Audio Input Ch 5
11	Audio Input Ch 14	12	Audio Input Ch 6
13	Audio Input Ch 15	14	Audio Input Ch 7
15	Audio Input Ch 16	16	Audio Input Ch 8
17	N/C	18	N/C
19	GND	20	GND

Connector: J6 (16 channel Sensor Input) Type: 20-pin (10x2) header(2.54mm) X 1


Pin	Description	Pin	Description
1	Sensor Input Ch 9	2	Sensor Input Ch 1
3	Sensor Input Ch 10	4	Sensor Input Ch 2
5	Sensor Input Ch 11	6	Sensor Input Ch 3
7	Sensor Input Ch 12	8	Sensor Input Ch 4
9	Sensor Input Ch 13	10	Sensor Input Ch 5
11	Sensor Input Ch 14	12	Sensor Input Ch 6
13	Sensor Input Ch 15	14	Sensor Input Ch 7
15	Sensor Input Ch 16	16	Sensor Input Ch 8
17	5V	18	3.3V
19	GND	20	GND

Connector: J7 (4 channel Alarm output) Type: 20-pin (10x2) header(2.54mm) X 1


Pin	Description	Pin	Description
1	N/C	2	N/C
3	N/C	4	N/C
5	N/C	6	N/C
7	Alarm Ch 1	8	N/C
9	Alarm Ch 2	10	N/C
11	Alarm Ch 3	12	N/C
13	Alarm Ch 4	14	N/C
15	N/C	16	N/C
17	5V	18	3.3V
19	GND	20	GND

### 1.4 < Driver Setting>

- 1. Copy the CD Driver folder to disk, Ex: C:\, D:\ ...
- 2. Please choose Device Manager then you can see other devices



## 3. Please choose Multimedia Controller then press advanced




### 4. Please select file location


## D:\SP-601H\WindowXP \Driver 090217




### 5. Please press continue anyway



### 6. Press Finish



### 7. Driver install succeed



## 1.5 < Application Setting & Functions>

## 1. Please select SDK location D:\SP-601H\WindowXP\SDK\bin

## then press SOLO6010App






### 2.Press General Setting

Live Display Mode select

- 5. Memory to Overlay, 60 field/sec or
- 6. Memory to Overlay, 30 frame/sec

VGA Card select Intel Onboard VGA




### 3.Main Function

### 1. Live & HW player

The live display and hardware player can be tested using this function

Load file
video → xxx.MR4
audio → xxx.RG7




### 2. SW player

The recorded MPEG4 file can be played back using this

function



### Record setting



### Contact Information

Any advice or comment about our products and service, or anything we can help you please don't hesitate to contact with us. We will do our best to support you for your products, projects and business.

## Taiwan Commate Computer Inc.

Address 8F, No. 94, Sec. 1, Shin Tai Wu Rd., Shi Chih

Taipei Hsien, Taiwan

TEL +886-2-26963909

FAX +886-2-26963911

Website <a href="http://www.commell.com.tw">http://www.commell.com.tw</a>.

E-Mail info@commell.com.tw (General Information)

tech@commell.com.tw (Technical Support)

Commell is the trademark of Taiwan Commate Computer INC.

