

HTTP API Version 1.2 STARDOT NetCamLIVE2 Series



Table of Contents

Revision Log
Video Stream and Syntax
Network
Video
Camera
Date Time
Network Protocol
Account

Restart



Revision Log

Date	Revision Version	Session Number	Change Description
2014-15-Apr	1.0		Initial Release
2014-08-Dec	1.1		Add RTSP Port
			Add event notification over HTTP including motion detection and wire input alarm.
			Add Alarm Parameter
			Add Dual H.264 720P + VGA Device Information
			Add alarm-flag into http stream
			Add motionblock192
			Add GOP Parameter
2015-21-Sep	1.2		*added all return information
			Add HTTP API Version
			Add Video Encoder Options
			Add HTTP audio multipart
			Add DateTime OSD format/position/color Add Text OSD position/color



Note: For commands to be set, a reboot of the camera is required after changing a setting using an API command

Login

Where login is required, add the username and password just before the IP address as follows. This is not shown in the instructions for each api call; it assumes you are logged in.

http://admin:admin@192.168.86.24/vb.htm?textenable1=1

From inside the camera you can use the loopback address, with the answer going into a file:

wget http://admin:admin@127.0.0.1/vb.htm?textenable1

File vb.htm?textenable1 =

OK textenable1=1

Video Stream and Syntax

- HTTP authentication method Digest or Basic.
- Video Stream:
 - HTTP Stream
 - HTTP mainstream http://<ip:http_port>/video0.m4v
 Response: HTTP multipart video frames

Example: http://192.168.0.110/video0.m4v

■ HTTP substream http://<ip:http_port>/video1.m4v Example: http://192.168.0.110/video1.m4v

HTTP Headers Video Multipart:

Name	Value
Content-Type	video/h264
	video/mpeg4
	image/jpeg



X-Tag	serial no	
X-Alarm	1:Motion 2:Input1 4:Input2	
X-Framerate	frame rate	
X-Resolution	resolution	
X-Time	time, second	
X-PTS	time, microsecond	

Audio Multipart:

Name	Value		
Content-Type	Audio/x-wav		
X-Codec	U-LAW PCM A-LAW		
X-Bitrate	Audio bit rate		
X-AChannels	1 : mono, 2: stereo		
X-SampleRate	Audio sample rate, 8000 16000 22050 44100		
X-Tag	Serial no		
X-Time	time, second		
X-PTS	time, microsecond		

RTSP Stream

RTSP mainstream rtsp://<ip>/video0.sdp Example: rtsp://192.168.0.110/video0.sdp

RTSP substream rtsp://<ip>/video1.sdp Example: rtsp://192.168.0.110/video1.sdp

Get snapshot:

Snapshot of mainstream:

Syntax: http://<IP>/ipcam/jpeg

Response: JPEG

Example: http://192.168.0.110/ipcam/jpeg

Snapshot of substream:

Syntax: http://<ip:http_port>/ipcam/jpegcif

Response: JPEG

Example: http://192.168.0.110/ipcam/jpegcif

Set Parameter

Syntax: http://<ip:http_port>/vb.htm?parameter=value

Response: OK parameter

Example: http://192.168.0.110/vb.htm?wantype=1

OK wantype

Get Parameter value

Syntax: http://<ip:http_port>/vb.htm?parameter

Response: OK parameter=value

Example: http://192.168.0.110/vb.htm?wantype

OK wantype=1

• Set multi-parameters in a single request

Syntax: http://<ip:http port>/vb.htm?prmt=value1&prmt=value2&prmt=value3...

Response: OK prmt1 OK prmt2 OK prmt3



Example:

http://192.168.0.110/vb.htm?wantype=1&netip=192.168.0.110&netmask=255.255.255.0&gateway=192.1

OK wantype OK netip OK netmask OK gateway

Get multi-parameters value in a single request

Syntax: http://<ipcam:http_port>/vb.htm?prmt1&prmt2&prmt3... Response: OK prmt1=value1 OK prmt2=value2 OK prmt3=value3

Example: http://192.168.0.110/vb.htm?videocodec&videocodeccombo&videocodecres
OK videocodec=0 OK videocodeccombo=0 OK videocodecres=3

Event notification over HTTP including motion detection and wire input alarm.

Syntax: http://<ip:http_port>/event.cgi

Response: IPCam keeps sending continuous HTTP multipart contents every 2 seconds.

Name	Value	Description
md	0: off	Event motion detection is triggered or not.
	1: on	
input1	0: off	Event input 1 is triggered or not.
	1: on	
input2	0: off	Event input 2 is triggered or not.
	1: on	

Example: http://192.168.0.110/event.cgi

Get device information.

Syntax: http://<ip:http_port>/vb.htm?DeviceInfo Example: http://192.168.0.110/vb.htm?DeviceInfo

OK DeviceInfo=modeIname="SQ Series" mac=00165508B71E ver="P129 VER 1.0.19-09-B772 (2015/05/13 15:05:06) PS(Startdot)" 5MP=0 AIO=1 ALI=3 AUO=0 PTZ=0 LED=0 uboot_desc="ALI=3"

AUO=0 LVO=3 PTZ=0 IRR=1" CPU=800M

Get HTTP API Version

Syntax: http://<ipcam:http_port>/vb.htm?HttpApiVer



Network

GUI Item	SDK Parameter	Value	Remark
WAN Type	wantype	1: Static IP 2: DHCP	
Hostname	dhcphostname		
MTU (DHCP)	mtu2		
IP Address	netip		Only works for manual IP. DHCP undefined.
Subnet Mask	netmask		
Default gateway IP	gateway		
MTU (Static IP)	mtu1		
Primary DNS Server	dnsip		Get Value = http://192.168.86.24/vb.htm?dnsip Return: OK dnsip=8.8.8.8
Secondary DNS Server	dnsip2		Return: OK dnsip

Video

GUI Item	SDK Parameter	Value	Remark
N/A	VideoEncoderO pt	Main,C=H264,R=1920x1080,F=30;Sub,C=H264,R=640x480, F=30;Sub,C=H264,R=480x270,F=30;Sub,C=H264,R=352x24 0,F=30 Main,C=H264,R=1280x1024,F=30;Sub,C=H264,R=640x480, F=30;Sub,C	List of supported main/sub stream combinations. Ended with \r\n\r\n. C: Codec R: Resolution F: Max FPS

GUI Item	SDK Parameter	Value	Remark
		10.00	



Camera	title	Upto 11 characters	
Video Source	videosource	0: 5MP	
		1: 1080P	
Stream 1	•		
Resolution	VideoResolution1	5MP: 2560x1920 3MP: 2048x1536 1080P: 1920x1080 SXGA: 1280x1024 720P: 1280x720 VGA: 640x480	Depends on Video Source.
		SIF: 352x240	
Framerate	framerate1	1-30	
GOP	VideoGop1	8-40	
Rate Control	ratecontrol1	1: VBR 2: CBR	
Bit Rate	bitrate1	Unit: Kbps	
Stream2			
Resolution	VideoResolution2	VGA: 640x480 270P: 480x270 SIF: 352x240	
Framerate	framerate2	1-30	
GOP	VideoGop2	8-40	
Rate Control	ratecontrol2	1: VBR 2: CBR	
Bit Rate	bitrate2	Unit: Kbps	
Date	datestampenable1	0: Disable 1: Enable	
Date Format	dateformat	0: YYYY-MM-DD 1: MM-DD-YYYY 2: DD-MM-YYYY	
Time	timestampenable1	0: Disable 1: Enable	
Time Format	timeformat	0: 12 Hours 1: 24 Hours	
Date Time Color	datefontcolor	aqua black blue brown dodgerblue gray green khaki lightgreen magenta orange pink red slateblue white yellow	
Date Position	dateposition	0: Bottom-Left 1: Bottom-Right 2: Bottom-Center 3: Top-Left 4: Top-Center 5: Top-Right	
Text	EnableTextForRa w	Same syntaxt as textenable1	Note: Used for phenology raw image upload with overlay disabled. Does not save to config (doesn't wear out flash memory)
Text	textenable1	0: Overlay off 1: Overlay on	Get Value = http://192.168.86.24/vb.h



			tm?textenable1 Return: OK textenable1=1 Set Value = http://192.168.86.24/vb.h tm?textenable1=1
T. (0.)			Return: OK textenable1
Text Color	textfontcolor1	aqua black blue brown dodgerblue gray green khaki lightgreen magenta orange pink red slateblue white yellow	
Text Position	textposition1	0: Bottom-Left 1: Bottom-Right 2: Bottom-Center 3: Top-Left 4: Top-Center 5: Top-Right	
Text Content	overlaytext1	Upto 20 characters	
Mirror	mirctrl	0: OFF 1: HORIZONTAL 2: VERTICAL 3: BOTH	

Example:

http://192.168.1.221/vb.htm?VideoResolution1=SXGA&framerate1=24&bitrate1=6144&datestamp enable1=1



Camera

GUI Item	SDK Parameter	Value	Remark
Brightness	brightness	0-255	
Contrast	contrast	0-255	
Saturation	saturation	0-255	
Sharpness	sharpness	0-255	
Hue	hue	0-255	
Back Light	blc	0: OFF	
Compensation		1: ON	
Color Mode	colormode	0: Auto	
		1: day mode	
		2: night mode	
Privacy Mask	privacymaskenable	0: OFF	
		1: ON	
	privacymask	x,y,width,height,	
		ex: 20,50,40,40	

Date Time

GUI Item	SDK Parameter	Value	Remark
Synchroize with	ntpenable	0: Disable	
Time Servers		1: Enable	
SNTP Server	sntpip	FQDN or IP of NTP Server	
Time Zone	timezone	0: +0 -60: -1	+
		60: +1 -120: -2	
		120: +2 -180: -3	
		180: +3 -240: -4	
		240: +4 -300: -5	
		300: +5 -360: -6	
		360: +6 -420: -7	
		420: +7 -480: -8	
		480: +8 -540: -9	
		540: +9 -600: -10	
		600: +10 -660: -11	
		660: +11 -720: -12	
		720: +12	
	newdate	yyyy/mm/dd	Set Date/Time with
		Example: 2212/07/04	assigned value to
	newtime	hh:mm:ss	IPCam
		Example: 13:10:30	
Local Time	gettime		Return format
			"yyyy-mm-dd
			hh:mm:ss"



Network Protocol

GUI Item	SDK Parameter	Value	Remark
HTTP Port	httpport	1-65535	
RTSP Port	rtspport	1-65535	
Sync With NVR	SyncWithNvr	0: Disable 1: Enable	If this option is set to be "0" that the IP Camera will not accept other HTTP API command anymore until you enable this option from web GUI.

Account

GUI Item	SDK Parameter	Value	Remark
Admin	adminid	Upto 30 characters	
Username			
Password	adminpwd	Upto 16 characters	
Operator	operatorid	Upto 30 characters	
username			
Password	operatorpwd	Upto 16 characters	
Viewer	viewerid	Upto 30 characters	
Username			
Password	viewerpwd	Upto 16 characters	

Restart

GUI Item	SDK Parameter		Remark
Restart	ipcamrestartcmd	Restart IPCam Please send this command later that you send the last setting command.	



PTZ

GUI Item	SDK Parameter	Value	Remark
Protocol	ptzprotocol	0: OFF	
		1: PelcoP	
		2: PelcoD	
Device ID	ptzaddr	0-3	
Baud Rate	ptzbaud	0: 1200	
		1: 2400	
		2: 4800	
		3: 9600 4: 19200	
PTZ Speed	ptzspeed	0-23	
1 12 Opeed	ptzpreset=#	# >= 1 (Location #)	Assign PTZ
	presetname=xxx	Xxx give preset a name	preset location
	ipncptz=14	7000 give process a righte	proceriocation
	ptzpreset=#	# >= 1 (Location #)	Locate to a
	ipncptz=17	,	preset location.
	ptzpreset=#	# >= 1 (Location #)	Clear a PTZ
	ipncptz=15	, ,	preset location
	ptzpresets	Without value	List all preset
			location
	ipncptz	16	Clear all preset
			location
	ipncptz	0: STOP	Move PTZ
		1: LEFT	
		2: RIGHT	
		3: UP	
		4: DOWN 5: IRISDEC	
		6: IRISINC	
		7: ZOOMDEC	
		8: ZOOMINC	
		9: FOCUSDEC	
		10: FOCUSINC	
		21: LEFT UP	
		22: LEFT DOWN	
		23: RIGHT UP	
		24: RIGHT DOWN	
		Function for SpeedDome	
		41: OSD menu Show/Hidden	
		42: OSD menu left	
		43: OSD menu right	
		44: OSD menu up	
		45: OSD menu down	
		46: Auto Focus	
		47: Focus plus	
		48: Focus minus 49: Focus Stop	
		49. FUCUS SIUP	

Example:



Preset location #1 - http://192.168.1.221/vb.htm?ptzpreset=1&ipncptz=14
Locate to location #1 - http://192.168.1.221/vb.htm?ptzpreset=1&ipncptz=15
Clear preset location #1 - http://192.168.1.221/vb.htm?ptzpreset=1&ipncptz=15

List all preset location http://192.168.1.221/vb.htm?ptzpreset
OK ptzpresets=
1,xxxx
2,yyyy
3,zzzz



Alarm

GUI Item	SDK Parameter	Value	Remark
External	extalarm	0: Disable	
Triggers		1: Enable	
Input1	exttrigger1input	0: Disable	
		1: Enable	
Input2	exttrigger2input	0: Disable	
		1: Enable	
Output1	exttrigger1output	0: Disable	
		1: Enable	

Motion Detection

GUI Item	SDK Parameter	Value	Remark
Motion Detection	motionenable	0: Disable 1: Enable	
(Sensitivity Mode – Radio Button)	motioncenable	Drop Down Menu Customized Threshold	
Sensitivity	motionsensitivi ty	0: Low 1: Medium 2: High	
Customized Threshold	motioncvalue	0-100	
(Detecting Block)	motionblock19 2	Hex format row by low Example: FFFF,8001,8001,8001,8001,8001,8001,8001,	

This electronic transmission (and any attached document) is intended exclusively for the person or entity to whom it is addressed and may contain confidential and/or privileged material. Any disclosure, copying, distribution or other action based upon the information by persons or entities other than the intended recipient is prohibited. If you receive this message in error, please contact the sender and delete the material from any and all computers. StarDot Technologies does not warrant a proper and complete transmission of this information, nor does it accept liability of any delays.