

- Apply Kapton Tape at least ¼ inch wide and at least
 ½ inch long at location shown by yellow rectangle
- Tape must completely cover leads of C2
- Tape must not touch holes for J5, J6, MH2, or MH5