	1	2	3	4	5	6	7	8	9	10
А	GND	NP	NP	GND	GND	GND	GND	GND	GND	GND
В	5V0	HV0	HV1	HV2	GND	GND	GND	GND	GND	3V3
С	SCL	NP	NP	GND	GND	GND	GND	R3B	T17A	T17B
D	SDA	VIO	3V3	GND	NP	GND	GND	R5A	R5B	NP
Е	GND	GND	GND	GND	GND	GND	GND	R6A	R6C	NP
F	GND	GND	GND	GND	NP	R2A	GND	R6E	R6I	NP
G	UDP	GND	GND	GND	R3A	R2B	GND	R7A	R9A	R8A
Н	UDM	GND	GND	GND	R10B	R6D	R6G	R10A	R8B	VIO
J	GND	NP	GND	GND	R6B	R6F	R6H	R6J	R7B	GND