

Tao

File Create View Plot

Data...	Ctrl+D	Browse...	Run
Variables...	Alt+V		
Global Variables...	Ctrl+G		
Lattice Elements...	Ctrl+E	Setup	Run
Lattice...	Ctrl+L		
		Debug	

Show/Hide Console      View History...

```
[INFO] tao_init:
Note: global%rf_on = False --> RF Cavities will be turned off in lattices

Tao>show data

Name                                Using for Optimization
orbit.x[0:99]                         Using:
orbit.y[0:99]                         Using:
phase.a[0:99]                          Using:
phase.b[0:99]                          Using:
eta.x[0:99]                           Using:
eta.y[0:99]                           Using:
beta.a[0:99]                          Using:
beta.b[0:99]                          Using:
cbar.11[0:99]                          Using:
cbar.12[0:99]                          Using:
cbar.21[0:99]                          Using:
cbar.22[0:99]                          Using:
k.11b[0:99]                           Using:
k.12a[0:99]                           Using:
k.12b[0:99]                           Using:
k.22a[0:99]                           Using:

Tao>
```

Global Variables

svd_cutoff	9.999997473788e-06
unstable_penalty	0.0010000000474975
merit_stop_value	-1.0
dmerit_stop_value	0.0
random_sigma_cutoff	-1.0
delta_e_chrom	0.0001
n_opti_cycles	20
n_opti_loops	1
phase_units	radians
bunch_to_plot	1
random_seed	0
n_top10_merit	10
srdt_gen_n_slices	10
srdt_sxt_n_slices	20
srdt_use_cache	<input checked="" type="checkbox"/>
random_engine	pseudo
random_gauss_converter	exact
track_type	single
optimizer	lm
print_command	lpr

Set Global Variables