Address Select (0-7)Cannot use D4 and D10 as they are used by the Ethernet shield +5٧ J1 Conn_01x02_Female J12 PT_Conn_01x06 U1 PT_Ethernet_Shield J2 <u>2</u> Conn_01x02_Female <u>1</u> £ ≥ S RESET 13 DO/RX 14 D1/TX 15 D2 16 D3 17 D4 18 D5 19 D6 20 D7 21 D8 22 D9 23 D10 24 D11 25 D12 26 D13 J3 <u>2</u> Conn_01x02_Female <u>1</u> AREF 28 GND R1 R A0 GND A1 8 9 10 A3 A4 11 +50 GND D1 D2 LED A5 12 GND 3 4 5 5 Conn_01x08_Female +5V J5 PT_Conn_01x06 GND GND GND GND GND GND J11 Conn_01x04_Female GND +5٧ J13 PT_Conn_01x06 GND