## **Beams**

### Giacomo Boffi

http://intranet.dica.polimi.it/people/boffi-giacomo

Dipartimento di Ingegneria Civile Ambientale e Territoriale Politecnico di Milano

October 31, 2017

Beams

Giacomo Boffi

ntroduction

General Principle:

Analysis of Beams

Design of Beam

## Definition:

- ▶ a prevalent dimension (the span),
- ▶ loads act perpendicular to the prevalent dimension, so no axial forces but shear and bending moment,
- ▶ the cross section dimensions are the depth (parallel to loading) and the width.

We restrict our attention to rectilinear beams but curvilinear beams are possible as well.

# Definition:

- ► a prevalent dimension (the span),
- ▶ loads act perpendicular to the prevalent dimension, so no axial forces but shear and bending moment,
- ▶ the cross section dimensions are the depth (parallel to loading) and the width.

We restrict our attention to rectilinear beams but curvilinear beams are possible as well.

### Historical remarks:

- Galileo Galilei,
- ► Coulomb,
- ▶ De Saint Venant.

Introduction

Beams in Buildings
Basic Stress Distributions

Analysis of Beams

Design of Beams

Beams are almost always present in a building.

When beams form the principal structural system they are arranged in a systematic manner, usually following a hierarchical arrangement.

Decking or planks have limited span so it is typical to support them, at regular intervals with orthogonal beams, forming a two-level system.

Analysis of Beam

Design of Beams

Beams are almost always present in a building. When beams form the principal structural system they are arranged in a systematic manner, usually following a hierarchical arrangement.

Decking or planks have limited span so it is typical to support them, at regular intervals with orthogonal beams, forming a two-level system.

It is common (especially in steel structures) to support these deck-supporting beams on larger, orthogonal beams forming a three-level system.

Beams are almost always present in a building. When beams form the principal structural system they are arranged in a systematic manner, usually following a hierarchical arrangement. Decking or planks have limited span so it is typical to support them, at regular

It is common (especially in steel structures) to support these deck-supporting beams on larger, orthogonal beams forming a three-level system.

intervals with orthogonal beams, forming a two-level system.

The loads on the beams are progressively increasing, as well as the lengths of the beams and this leads in turn to an increase in the size of the beams in a three level system, from the secondary beams to the primary ones.

The stresses in a beam depend on the bending moment value and on shape of the cross section.

- ► The bending moment depends on the value of the loading, on the span of the beam and on the support conditions.
- ▶ In general, the larger the section the lower the stresses, but also the shape and its orientation w/r to loading direction is important, in particular an increase of the depth leads to an important decrease of the maximum stresses.

#### Introduction

General Principles

Beams in Buildings

Basic Stress Distributions

### Analysis of Beam

Design of Beams

At any cross section the resultant of the stresses must equal the shear force and the bending moment.

- ► The shear force, that acts in the direction of the depth of the section, is equilibrated by tangential stresses.
- ► The bending moment, that acts perpendicular to the cross section, is equilibrated by normal stresses.

## Basic Stress Distributions

#### Beams


Giacomo Boffi

Introduction

Beams in Buildings
Basic Stress Distributions

Analysis of Beams

Design of Beams



- ▶ The moment cause the beam to bow, in our figure top fibers are shorted and bottom fibers are elongated.
- ▶ There are fibers whose length is not varied, these fibers cross the section on a line called the neutral axis.
- ▶ The amount of length variation depends linearly on the distance y from the neutral axis.
- ▶ The stresses, for a linear elastic material, depends on the amount of length variation(a.k.a. deformation) and are hence linearly varying, with positive and negative extremes on the borders of the cross section.

The stresses are proportional from the distance v from the neutral axis, are proportional to the bending moment and are inversely proportional to a property of the dimensions and shape of the cross section, that we call moment of inertia and denote with the symbol J. (nb dimensional analysis)

$$\sigma = My/J$$

## Example

Simply supported beam,  $L=8 \,\mathrm{m}$ ,  $p=60 \,\frac{\mathrm{kN}}{\mathrm{m}}$ ,  $M_{\mathrm{max}}=\frac{pL^2}{8}=480 \,\mathrm{kNm}$ .

For a rectangular section it is  $J = bd^3/12$  and  $y_{\text{max}} = b/2$ .

The maximum stress is  $\sigma_{\rm max} = \frac{\frac{PL^2}{8} \times \frac{d}{2}}{bd^3/12}$  and with  $b = 0.3 \, {\rm m}$ ,  $d = 0.6 \, {\rm m}$  it is  $\sigma_{\text{max}} = 26\,666\,667\,\frac{\text{N}}{\text{m}^2} = 26.67\,\text{MPa}$ 

For a rectangular section it is

$$J = \frac{bd^3}{12}, \quad \sigma_{\text{max}} = \frac{Md/2}{bd^3/12} = \frac{M}{bd^2/6} = M/W$$

where  $W = bd^2/6$  is the section modulus.

It is clear that if the double the amount of material in a beam by doubling the width b the maximum stress is halved, if we double the depth d the stress is reduced to one quarter.

## Example

Simply supported beam,  $L = 7.2 \,\mathrm{m}$ ,  $P = 20 \,\mathrm{kN}$  applied ad midspan,  $M_{\text{max}} = PL/4 = 36 \text{ kN m} = 36 \text{ MN mm}.$ 

Rectangular section,  $b = 120 \,\mathrm{mm}$  and  $d = 200 \,\mathrm{mm}$ ,  $J = 80 \times 10^6 \,\mathrm{mm}^4$  and  $W = 800 \times 10^3 \, \mathrm{mm}^3$ , eventually  $\sigma_{\mathrm{max}} = 45 \, \mathrm{MPa}$ .

# Bending Stresses

In general we have to perform our computation in two steps

- 1. find the position of the neutral axis,
- 2. find the moment of inertia with respect to the neutral axis.

To find the position of the neutral axis

- 1. draw an axis parallel to the neutral one at a(n unknown) distance  $y_G$  from it,
- 2. the distance from the neutral axis, in terms of the distance of the temporary axis, is  $y-y_{G}$ ,
- 3. the stress is  $\sigma = (y y_G)k$ ,
- 4. the stress resultant is  $N = \int_A \sigma \, dA = k \int_A (y y_G) \, dA = k \int_A y \, dA k y_G A$
- 5. we have N = 0 hence

$$y_G = \frac{S_x}{A}$$
 where  $S_x = \int_A y \, dA$ 

Similarly  $x_G = S_y/A$  with  $S_y = \int_A x \, dA$ .

To find the position of the neutral axis

- 1. draw an axis parallel to the neutral one at a(n unknown) distance  $y_G$  from it,
- 2. the distance from the neutral axis, in terms of the distance of the temporary axis, is  $y-y_G$ ,
- 3. the stress is  $\sigma = (y y_G)k$ ,
- 4. the stress resultant is  $N = \int_A \sigma \, dA = k \int_A (y y_G) \, dA = k \int_A y \, dA k y_G A$
- 5. we have N = 0 hence

$$y_G = \frac{S_x}{A}$$
 where  $S_x = \int_A y \, dA$ 

Similarly  $x_G = S_y/A$  with  $S_y = \int_A x \, dA$ .

We have found the position of the *centroid* of the cross section w/r to two arbitrary axes.

Analysis of Beams

Lateral Buckling Shear Stresses

Bearing Stresse

Forsion

ear Center

incipal Stresses

esign of Beams

The moment of the stresses about the neutral axes, if now we measure the distances from it, is  $M=\int_A y\sigma\ dA=k\int_A y^2\ dA=k\ J_x$  by the definition of moment of inertia, so that we can solve for  $k=M/J_x$  and eventually we can write

$$\sigma = \frac{M}{J_x} y.$$

Analysis of Beams
Bending Stresses

Lateral Buckling Shear Stresses

Torsion

Deflections

Principal Stresses

esign of Beams

The moment of the stresses about the neutral axes, if now we measure the distances from it, is  $M=\int_A y\sigma\ dA=k\int_A y^2\ dA=k\ J_x$  by the definition of moment of inertia, so that we can solve for  $k=M/J_x$  and eventually we can write

 $\sigma = \frac{M}{J_x} y.$ 

The expression above coincides with the expression that was shown earlier  $\mbox{\ensuremath{w/o}}$  an explanation.

The moments of inertia of many simple figures are tabulated, with respect to their own centroids. We can use these known results along with parallel axis theorem.

### Theorem

The moment of inertia J of an area A, with respect to a axis parallel to an axis passing for its centroid is equal to the sum of the centroidal moment of inertia J' plus the moment of transport  $\Delta^2 A$ 

$$J=J'+\Delta^2A$$

where  $\Delta$  is the distance between the two axes.

# Computing moments of inertia

6<sub>m</sub>m

6<sub>m</sub>m

30mm

Giacomo Boffi

Bending Stresses

 $\frac{J_2}{mm^4} = \frac{30 \times 6^3}{12} + 180 \times (33 - 15)^2 = (540 + 14580) = 15120$ 

 $y_G = \frac{180 \times 48}{180 \times 2} \text{mm} = 24 \text{mm}$ 

 $A = (6 \times 30 + 6 \times 30) \text{mm}^2 = 360 \text{mm}^2$ 

 $S_x = (180 \times 15 + 180 \times 33) \text{mm}^3 = (180 \times 48) \text{mm}^3$ 

 $J = J_1 + J_2 = 43200 \text{mm}^4$ .  $W_t = J/12 \text{mm} = 3600 \text{mm}^3$ 

 $W_b = J/24 \text{mm} = 1800 \text{mm}^3$ 

 $\frac{J_1}{\text{mm}^4} = \frac{30^3 \times 6}{12} + 180 \times (15 - 24)^2 = (13500 + 14580) = 28080^{\text{Stresses}}$ 

# Computing moments of inertia

#### Beams

Giacomo Boffi

Introduction

General Principles

analysis of Beams


Bending Stresses Lateral Buckling

Shear Stresses

Forsion Shear Center

Principal Stresses

Design of Beams



$$A = (20 \times 35 - 16 \times 25) \text{mm}^2 = 300 \text{mm}^2$$

$$S_x = 10 \text{mm}, \quad y_G = 17.5 \text{mm}$$

$$\frac{J_1}{\text{mm}^4} = \frac{35^3 \times 20}{12} = 71458.33$$

$$\frac{J_2}{\text{mm}^4} = \frac{25 \times 16^3}{12} = 20833.33$$

$$J = J_1 - J_2 = 50625.00 \text{mm}^4.$$

$$W = J/17.5 \text{mm} = 2892.86 \text{mm}^3$$

# Rectangle

#### Beams

Giacomo Boffi

Introduction

------

Bending Stresses


Lateral Buckling Shear Stresses

Bearing Stresses
Torsion
Shear Center

flections

.,.

Design of Beams



Sides 
$$a, b$$
  
Centroid  $x_G = a/2, y_G = b/2$ 

Area 
$$A = ab$$
,

Moment of Inertia 
$$J = \frac{ab}{12}$$

# Triangle

#### Beams

Giacomo Boffi

Introduction

Bending Stresses

Lateral Buckling Shear Stresses

Torsion Shear Center

flections

Design of Beams

y  $\circ$  G  $\circ$  G

For a right triangle.

Sides 
$$a, b$$
Centroid  $x_G = a/3, \quad y_G = b/3$ 
Area  $A = ab/2,$ 
Moment of Inertia  $J = \frac{ab^3}{36}$ 

## Oval

#### Beams

Giacomo Boffi

Introduction

General Principle

Analysis of Beams

Bending Stresses

Lateral Buckling

Shear Stresses

Torsion
Shear Center

Deflections

Design of Beams

When  $a \equiv b \equiv D \equiv 2R$  the oval is a circle.

Axes

Centre of Mass

a, b

 $x_G=y_G=0$ 

Area  $A = \frac{\pi ab}{4} = \pi R^2$ ,

Moment of Inertia  $J = \pi \frac{ab^3}{64} = \pi \frac{R^2}{4}$ 

## Lateral Buckling

Beams

Giacomo Boffi

Introduction

General Principles

Analysis of Beams
Bending Stresses

Lateral Buckling

Shear Stresse

Bearing Stress

orsion

hear Center

Deflections

Principal Stresses

--!--- -f D-----

esign of Beams

As was the case with trusses, one side of a beam is subjected to compression and it's subjected to the possibility of a lateral sway.

Possible remedies:

- ► lateral bracing
- $\,\blacktriangleright\,$  stiffening the compressed part in the lateral direction

Bending Stresses Lateral Buckling

Shear Stresses

Bearing Stresses

Torsion

Deflections

Principal Stresses

Design of Beams

- ► On the left, a "beam" composed of three equal, separate sheets, each one behaves the same,
- ▶ on the right, the sheets have been glued and the top sheet is shortened while the bottom one is elongated.

This behavior is possible only if the sheets exchange tangential stresses at their interfaces.

These tangential stresses are the shear stresses.

E.g., for a rectangular beam the resultants of compressive and tensile stresses lie at d/6 from the borders, so their arm is a = 2d/3 and we have

$$T = C = M/a = 1.5M/d.$$

Consider now a slice of beam cut between  $x_1$  and  $x_2 = x_1 + \delta$  and separated in two halves at the neutral axis, the bottom part is subjected to two forces  $T_1 = 1.5 M_1/d$  and  $T_2 = 1.5 M_2/d$ , we have an unbalanced force

$$U=1.5\frac{M(x_1+\delta)-M(x_1)}{d}.$$

For  $\delta \to dx$  it is

$$dU = 1.5 dM/d = 1.5 V dx/d,$$

the area available for equilibrating the unbalanced force using tangential stresses is dA = b dx so eventually

$$\tau = dU/dA = 1.5V/(bd).$$

Shear Streege

The procedure can be generalized, we know that  $\sigma = My/J$  so the resultant for an area  $A^*$  is

$$F = \frac{M}{J} \int_{A^*} y \, dA = \frac{M}{J} S^*$$

where  $S^*$  is the first moment of the area  $A^*$  w/r to the neutral axis. The variation of F over dx,  $dF = S^*V dx/J$ , is the unbalanced force to equilibrate over an area dA = b dx so that

$$\tau = \frac{V S^*}{b J}.$$

For the T section we have previously studied, consider a maximum shear  $V=4800\,\mathrm{N}$  and consider that the flange and the web have been glued together  $(b = 6 \, \text{mm}).$ 

We have to compute  $S^*$  for the flange

$$S^* = \int_{30}^{36} 30y \, dy = 5940 \, \text{mm}^3$$

and compute au

$$au = rac{V \ S^*}{b \ J} = rac{4800 imes 5940}{6 imes 43200} {\sf MPa} = 110 {\sf MPa}.$$

Your glue must resist to a tangential stress of 110MPa.

#### ntroduction

General Principles

## Analysis of Beam Bending Stresses

Lateral Buckling

Forsion

Deflections

incipal Stresses

esign of Beams

Just a few formulas, $E$ is the Young modulus of the material for the cantilever,
the concentrated load is at the free end, in the other cases the concentrated load
is at midspan — the deflections are measured at the same points.

	Cantilever	Supported	Fixed Ends
P	<u>PL<sup>3</sup></u> 3EJ	<u>PL<sup>3</sup></u> 48 <i>EJ</i>	$\frac{PL^3}{192EJ}$
W	<u>wL⁴</u> 8 <i>EJ</i>	<u>5wL⁴</u> 384 <i>EJ</i>	<u>wL⁴</u> 384 <i>EJ</i>

Note how much the displacements depend on the beam span, note also that different end conditions influence very much the deflections.

Analysis of Beams

Bending Stresses

ateral Buckling

Bearing Stresses

Torsion

Deflections

ncipal Stresses

esign of Beams

A simply supported beam,  $L=6\mathrm{m}$ , has a live load  $w=3\mathrm{kN}\,\mathrm{m}^{-1}$ . The section is rectangular,  $b=0.2\mathrm{m}$  and  $d=0.4\mathrm{m}$ , the Young modulus is  $E=12\mathrm{GPa}$ . Compute the midspan displacement.

Bearing Stresses

Deflections

 $\Lambda \approx 4 \, \text{mm}$ 

Compute the midspan displacement.

A simply supported beam, L = 6m, has a live load  $w = 3kN m^{-1}$ . The section is rectangular, b = 0.2m and d = 0.4m, the Young modulus is E = 12GPa.

Beams

Giacomo Boffi

Analysis of Beams

General Principles

Timber

Reinforced Concrete: Principles

Reinforced Concrete:

Approaches

#### Beams

Giacomo Boffi

ntroduction

Analysis of Beams

D : (D

General Principles

Timber

Limber

Steel

Reinforced Concrete: Principles

teinforced Concrete: Procedures

Approaches

► Strength and stiffness

Beams

Giacomo Boffi

Analysis of Beams

General Principles

Reinforced Concrete:

Approaches

► Strength and stiffness

► Cross-section design

#### Reams

Giacomo Boffi

General Principles

Reinforced Concrete:

- Approaches
- ► Strength and stiffness
- ► Cross-section design
- ► Material properties variation

#### Beams

Giacomo Boffi

ntroduction

General Principles

Analysis of Beams

Design of Beams

General Principles

Timber

Charl

inforced Cond inciples

Reinforced Concrete:

Reinforced Concrete: Procedures

- Approaches
- ► Strength and stiffness
- Cross-section design
- Material properties variation
- Shaping the beam

### **General Principles**

### Reams

Giacomo Boffi

General Principles

- Approaches
- ► Strength and stiffness
- ► Cross-section design
- Material properties variation
- ► Shaping the beam
- ► Position of supports

## Different Design Procedures

Beams

Giacomo Boffi

Analysis of Beams

General Principles

Timber

Reinforced Concrete: Principles

► Admissible Stress Design (ASD)

Giacomo Boffi

General Principles

Reinforced Concrete:

- Admissible Stress Design (ASD)
- ► Load and Resistance Factor Design (LRFD)

The design of a steel beam in most cases coincides with choosing a section in a catalogue of commonly available steel members.

The section you are going to choose has to satisfy two essential requirements in terms of strength and deformability.

Strength: the section must be strong enough to resist the maximum value of the bending moment,

$$f_y W \ge M_{\sf max} \quad o \quad W \ge M_{\sf max}/f_y.$$

Deformability: the maximum deflection must be less than a fraction of the beam span,  $\Delta < L/k$ .

The value of k depends on the load cases used to compute the deflection (live vs dead vs combination) and the function that the beam has to perform (support a roof, a floor, a wall, etc).

E.g., for a simply supported beam subjected to a distributed load, supporting a wall

$$\Delta = \frac{5wL^4}{384EJ} \leq \frac{L}{200} \quad \rightarrow \quad J \geq \frac{1000wL^3}{384EJ}.$$

ntroduction

sign of Beams

Timber

Steel

nforced Concrete:

einforced Concrete: ocedures

Steel is an elastic-plastic material, if the strain exceeds a certain amount the normal stress remains constant,  $\sigma = f_y$ . What happens when  $M = Wf_y$  and the load is increasing?

Steel is an elastic-plastic material, if the strain exceeds a certain amount the normal stress remains constant,  $\sigma = f_{\rm V}$ .

What happens when  $M = Wf_y$  and the load is increasing?



When the external bending moment increases, the outer fibres are further pulled-pushed and in a larger part of the section the stress is equal to  $f_y$  — the part of the section that is still elastic is, otoh, smaller and smaller and the elastic stiffness of the section is diminishing.

At some point, when in all the section  $\sigma=\pm f_y$  the elastic stiffness is equal to 0. In terms of strength we have reached the *plastic moment*, in terms of stiffness we have formed a *plastic hinge*.

Steel

When  $\sigma = \pm f_v$  we have  $T = C = f_v bd/2$  and their arm is a = d/2, hence  $M_p = f_v b d^2/4$  is the moment of plasticization, that turns the section into a plastic hinge.

For a rectangular beam  $W = bd^2/6$  and  $M_v = f_v bd^2/6$  is the maximum elastic moment.

For a rectangular section  $M_p/M_V=1.5$ , for different shapes we have different ratios. For common I shaped sections, the ratio has an average value around 1.12, for a circular bar it's about 1.7 and it's 2.0 for a diamond shaped bar.

Steel

In most cases, when dealing with wide flange beams, T beams, channels it is possible to estimate the design value of the shear strength taking into account only the web area  $A_w$ ,

$$V_{Rd}=0.6f_yA_w.$$

Giacomo Boffi

Reinforced Concrete Principles

Concrete resists very well compression, resists very poorly tension.

A plain concrete beam when loaded will tend to crack vertically in zones of (relatively) large bending moments and diagonally in zones of high shear and eventually break down for small loadings.

To avoid the crack growt and the eventual failure we dispose some tension resistent material perpendicular to the cracks' directions, usually steel bars, longitudinal steel bars to equilibrate bending moments and vertical stirrups (U-shaped bars) or diagonally bent bars to equilibrate shear forces.

# Principles of reinforcement design

Design of reinforcement, especially the longitudinal reinforcement, is a balancing act.

Beams

Giacomo Boffi

Introduction

aneral Principl

nalysis of Beams

gn of Beams

Timber

Steel
Reinforced Concrete:

Principles
Reinforced Concrete

## Principles of reinforcement design

Beams

Giacomo Boffi

Introduction

General Principles

Analysis of Beams

Design of Beams

General Principles

Steel

Reinforced Concrete: Principles

nforced Concrete:

If you provide not enough steel, the section will collapse by breackage of the reinforcement, but also providing too much steel leads to a bad design in which the failure of the beam happens when the compressed concrete is crushed. Concrete has a degree of ductility when compressed, but when its deformation is excessive it breaks suddenly.

Design of reinforcement, especially the longitudinal reinforcement, is a balancing act.

Design of Beams

Timber Steel

> Reinforced Concrete: Principles

forced Concrete:

A RC beam correctly designed has the right amount of reinforcement, so that the first vielding happens in the steel and we reach a limit state in which most of the concrete is

Design of reinforcement, especially the longitudinal reinforcement, is a balancing act.

Concrete has a degree of ductility when compressed, but when its deformation is

failure of the beam happens when the compressed concrete is crushed.

safely plasticized and the steel deformations are still under control.

In this case a possible failure of a beam is preceded by a visual increase of deflections. Further, the possibility of a plastic behavior leads to an energy dissipation that is useful to control the response to seismic excitation.

If you provide not enough steel, the section will collapse by breackage of the reinforcement, but also providing too much steel leads to a bad design in which the

excessive it breaks suddenly.

#### Introduction

General Principles


#### Design of Beams

Timber

Steel

Principles

Reinforced Concrete: Procedures



To have a correct ductility, a good design choice is to assign appropriate values to the steel and concrete deformations.

#### Introduction

General Principles

Analysis of Beam

### Design of Beams

General Principles

Timber

Steel

rinciples

Reinforced Concrete: Procedures

### Min Overall Depth (U.S. practice)

Member	Simply Supported	H+F	F+F	Cantilever
Slabs	L/20	L/24	L/28	L/10
Beams	L/16	L/18	L/21	L/8

Overall depth h is the reinforcement depth d plus the bottom concrete cover.