


# BRC ROPE TOW OPERATION 2026

When operating the BRC Rope Tow, the following **must be complied with**:

1. A Tow Supervisor must be designated, in place and monitoring the tow & users at all times. Tow Supervisors must be in place at each loading and unloading zone during all operations.
2. The Tow Operator must report the tow slope conditions upon startup by radio (icy, soft, hard, hazards) prior to the tow being used by others.
  - a. Snow report is to be placed on the whiteboard
  - b. All hazards must be marked on the slope with orange conduit
3. All tow users are to have received the *Tow Brief* prior to using the tow!!!
4. All tow users must check out of the chalet using the standard whiteboard procedures
5. All tow users must carry a whistle at all times
6. A minimum of 4 skiers and buddy system required when skiing the red / clear areas below
7. A maximum of 6 tow riders must be enforced at all times
8. All tow users are responsible for reporting hazards encountered on the slope to the Tow Supervisor as soon as possible/practical.
9. All skiing must be within the zones marked below, outside of these zones requires a trip intention form



Green areas are beginner friendly. Blue areas are considered “challenging”. Outside of marked zones requires a Trip Intention Form.

Ensure all supplied signage is set out prior to operation.

