Digital Logic Design - Vaibbhav

Group 8

Chap15 - Non-synthesizable

Chap 22 - Multiple Clock Domain

Chapter 15 Non-synthesizable Verilog Constructs and Testbenches

The chapter discusses about the inter-delay, intra-delay assignments and other non-synthesizable constructs useful during the testbenches.

- 1. For Simulation
- 2. Inter-delay & Intra-delay
 - a. Blocking Assignments with Inter-assignment Delays
 - b. Blocking Assignments with Intra-assignment Delays
 - c. Non-blocking Assignments with Inter-assignment Delays
 - d. Non-blocking Assignments with Intra-assignment Delays
- 3. Role of Testbenches
- 4. Multiple Assignments Within the begin-end
- 5. Multiple Assignments Within the fork-join
- 6. Display Tasks

Simulation - The always and initial Procedural Block

 Table 1
 Difference between initial and always block

Initial	Always
In this block assignment executes in the 0-simulation time and continues for the next specified sequence	In this block assignments continues to execute in simulation time 0 and repeats forever depending on the sensitivity list event
This block is executed only once, and the simulation stops at the end of this block	The simulation in this block continues forever. If wait construct is there, then it will be held during simulation session
It is non-synthesizable construct	It is synthesizable construct

Blocking Assignments & Non-blocking Assignments

```
initial
module test design;
                                            begin
reg clk;
                                             clk=0:
reg [7:0] a,b,c,d;
                                             a=8'h2;
always #10 clk = ~clk;
                                             b=8'h3;
always@(posedge clk)
                                             c=8'h4;
begin
 a <=b+c;
                                             d=8'h5;
 b <=a+d;
                                            end
 c <=a+b;
                                            endmodule
end
```

Inter-delay & Intra-delay

Useful during the testbenches

Blocking Assignments with Inter-assignment Delays

initial

begin

clk =0;


a=4;

b=3;

c=2;


d=5;

end



Vaveform 3 Simulation result for the Verilog blocking assignment with inter-assignment delay


Blocking Assignments with Intra-assignment Delays



Waveform 4 Simulation result for the Verilog blocking assignment with intra-assignment delay


Non-blocking Assignments with Inter-assignment Delays

always@(posedge clk)



Waveform 5 Simulation result for the Verilog non-blocking assignment with inter-assignment delay

Non-blocking Assignments with Intra-assignment Delays



Waveform 6 Simulation result for the Verilog non-blocking assignment with intra-assignment delay

end

d=5;

Role of Testbenches

To test the functional correctness

Ex: Compare behavior model with RTL code

Multiple Assignments Within the begin-end

All the blocking assignments within begin..end are executed sequentially.




Fig. 15.1 Simulation result for Example 9

Multiple Assignments Within the fork-join




Fig. 15.2 Simulation result of Example 10

What if.....

```
module test;
  reg clk;
  reg reset;
  reg a;
  reg b;
  initial begin
      a = 0; b = 1;
    clk = 0;
    reset = 1;
    forever #5 clk = ~clk;
  end
```

```
initial $monitor("a=%b, b=%b",a,b);


always @(posedge clk) begin
  fork
  a = b;
  b = a;
    join
end

endmodule
```

Display Tasks

```
a<=0: b<=0:
  c<=0: d<=0:
# 10 a<=1:
                                       b<=1:
  \frac{1}{2}$display (" time=%0t a=%0b b=%0b c=%0b y=%0b", $time, a, b, c, y);
  $strobe (" tme=%0t a=%0b b=%0b c=%0b y=%0b", $time, a, b, c, y);
#10 v <= a & b ^ c;
  $monitor (" \text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\tinte\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\tinte\tinte\text{\text{\text{\text{\text{\text{\text{\text{\tinte\tinte\tintet{\text{\text{\text{\text{\text{\text{\text{\tett}\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\tin}}}}}}}}}}}}}}}} \end{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\texi}\tintet{\text{\texi{\texi}\tinintet{\text{\text{\text{\text{\texi}\text{\text{\texi}\t
```

Display Tasks



Display Tasks

Using the waveforms is difficult and time consuming to check for the functional correctness




Fig. 15.3 Simulation result of Example 11

The **\$display** is used to print the value immediately.

The *\$strobe* is used to print the value at the current time stamp.

The **\$monitor** to display the changes in the values at the end of every time stamp.

time=10000 a=0 b=0 c=0 y=0 time=10000 a=1 b=0 c=1 y=0 time=20000 a=1 b=0 c=1 y=1

Chapter 22 Multiple Clock Domain Design

- 1. What Is Multiple Clock Domain?
- 2. What Is Clock Domain Crossing (CDC)
- 3. Metastability
- 4. Solutions
 - a. Level Synchronizers
 - b. Pulse Stretcher
 - c. Handshaking Mechanism + Pulse Synchronizers

What Is Multiple Clock Domain?

The clock sources CLK1 and CLK2 are derived from different clock source or may have the same or different frequency.




Fig. 22.1 Multiple clock domain logic

What Is Clock Domain Crossing (CDC)





Fig. 22.1 Multiple clock domain logic

Issue - Metastability

Metastability is the scenario in the design due to occurrences of multiple events close to each other, and the design has setup and hold time violations.



The Level Synchronizers




Fig. 22.6 Two-stage level synchronizer in the control path





Fig. 22.7 Timing sequence with use of the two-stage synchronizer

Constraint - Only for slow clk to fast clk



Pulse Stretcher






Fig. 22.11 Level-to-pulse conversion logic

Maybe...



Pulse Stretcher



Handshaking Mechanism




Fig. 22.12 Handshake control signal mechanism

Pulse Synchronizers / Toggle Synchronizer






Fig. 22.13 Pulse synchronizer

Handshaking Mechanism + Pulse Synchronizers





Why we need 3 registers, what if there are only 2






Fig. 22.13 Pulse synchronizer

What if there are only 2 registers & a XOR





We cannot process with metastable signal.