




## UX303LNB Repair Guide

## BLOCK DIAGRAM

## BLOCK DIAGRAM

*Non Connected Standby*


## POWER FLOW




# POWER ON SEQUENCE

AC-IN Mode

UX303JA Power On Sequence Diagram Rev.0.1



# AC POWER ON SEQUENCE



# Signal Measure Point-Bottom



# Signal Measure Point-Top

