Application Note:

Procedure for selecting the correct clock prescaler and TOP for an N bit timer:

$$f_{cpu} = CPU Frequency$$

$$Clk_{PS} = Clock\ Prescaler$$

 $f_{tim} = Desired\ Timer\ Frequency$ 

Choose  $Clk_{PS}$  such that:

$$Clk_{ps} > \frac{f_{cpu}}{(f_{tim})(2^N - 1)}$$

$$TOP = \frac{\left(\frac{f_{cpu}}{(f_{tim})}\right)}{Clk_{ps}}$$