



ASSEMBLY INSTRUCTIONS

UltraHD® 6-Foot Height Adjustable Workbench (Model No. 20296, 20141) Granite Graphite

72 in. W x 25 in. D x 28.5~42 in. H (1.82 m x 63.5 cm x 72.4 cm~1.06 m)






PARTS LIST

Please check the parts carefully according to the parts list. If you are missing any parts, please call our customer service department (please see page 5.)

service department (please see page 5.)	
(#3) Wood Top x 1 PC	(#2) Top Crossbar x 2 PCS
(#5) Leg x 3 PCS	(#1) Bottom Crossbar x 1 PC
(#6) Leveling Feet x 6 PCS	(#40) Screw E M8 x 18L 32 PCS
(#27-B) Washer x 38 PCS	(#26-B) Hand Knob x 6 PCS
(#25) Wrench x 1 PC	

UltraHD® Height Adjustable Workbench (Model No. 20296, 20141)

👬 *NOTE: We recommend using TWO people to assemble the workbench. 👖



Step 1. Assemble Top Crossbar (#2)

Open the package and make sure there are no missing parts. Set parts aside and open box for Solid Hardwood Top (#3).

Note: Leave the Solid Hardwood Top (#3) on cardboard to reduce the chance of scratching during assembly.

Attach both Top Crossbars (#2) to the Solid Hardwood Top (#3). Use 8 pcs Screw E (#40) with Washer (#27-B) and Wrench (#25) to tighten.

Do not fully tighten the screws after finish assembling Step 3.


Step 2. Adjust the Height of the Leg(#5)

- 1. Adjust the Leg (#5) to your desired height.
- 2. Insert 6 pcs of Hand Knob (#26-B) into the leg tube using Washer (#27-B).

Note: Adjust the height of the workbench before assembling the Hand Knob (#26-B). Height range is from 28.5 in. to 42 in.

Step 3. Assemble Leg (#5)

Attach the Legs (#5) as the left photo shows, line up screw holes, use 18 pcs Screw E (#40) and Washer (#27-B) to tighten the leg.




Each Leg (#5) have holes near the bottom of the frame. Make sure all the holes are facing the back of the unit.

Note: Fasten all screws after this step.

UltraHD® Height Adjustable Workbench (Model No. 20296, 20141)


🎢 *NOTE: We recommend using TWO people to assemble the workbench. 👖



#6

Step 4. Assemble Bottom Crossbar (#1)

Attach the Bottom Crossbar (#1) to the back of the Legs (#5), line up the screw holes, use 6 pcs Screw E (#40) with Washer (#27-B) and Wrench (#25) to tighten.



After installing Bottom Crossbar (#1), insert the Leveling Feet (#6) into the Legs (#5), use Wrench (#25) to tighten.

Turn the workbench onto it's feet to finish.

To Adjust the Height of the Top

Turn the workbench upside down.
Untighten the Hand Knobs and adjust the height.


UltraHD® Wood Top Care Instructions

Our tops are made with real wood, and while great care is taken to ensure consistent top color and graining, there may be natural variations between finished products. We hand select the wood for every top to ensure the material is undamaged and naturally beautiful. If the wood top is received with excessive damage or splitting, Seville Classics will guarantee replacement of the top. Variations of color, and minor scratches in the clear coat finish will not be reason for replacement.

Restore Shallow Scratches or Chips

The wood surface of this product is finished with a polyurethane coat. If the wood top becomes chipped or scratched, a polyurethane coat can be reapplied to restore a smooth texture and protect from future damage.

Please follow the manufacturer's instruction on the product for application.



CONTACT INFORMATION

If you are missing any parts, have any questions, or need additional assistance in assembly, please contact our bilingual (English and Spanish) customer service department at:



Seville Classics, Inc.

19401 Harborgate Way Torrance, CA 90501 USA

Telephone: (800) 323-5565 within USA

Fax: (310) 533-3899


Hours: 9:00am - 4:30pm (Pacific Standard Time)

E-mail: support@sevilleclassics.com

Website & Online Store: www.sevilleclassics.com

Please visit our website or call and inquire about our additional UltraHD Line

UltraHD® Line




UltraHD® Tall Storage Cabinet

Model No. 16236 (Granite)

Model No. 20143 (Graphite)

Model No. 20153 (Red)

Model No. 20133 (White)




UltraHD® Mega Storage Cabinet

Model No. 16238 (Granite)


Model No. 20148 (Graphite)

Model No. 20158 (Red)


UltraHD® Line




UltraHD® 4-Drawer Rolling Cabinet Model No. 20205 (Granite)




UltraHD® 6-Foot Height Adjustable Workbench Model No. 20292 (Granite)




UltraHD® Wall Cabinet with Open Shelf Model No. 20230 (Granite) Model No. 20140 (Graphite) Model No. 20150 (Red)



UltraHD® 2-Door Rolling Workbench Model No. 20262 (Granite) Model No. 20142 (Graphite) Model No. 20152 (Red)



UltraHD® Rolling Trash Bin Model No. 20215



UltraHD® Lighted Workcenter Model No. 20247 (Granite) Model No. 20246 (Graphite) Model No. 20157 (Red)