


# airLIFT® Electric Standing Desk Converter



Model: OFF65806

Please contact Seville Classics for help with assembly and to report any damaged or missing components.

Phone: 1 (800) 323-5565
Email: Support@SevilleClassics.com
Homepage: www.SevilleClassics.com


#### **Customer Service Information**

**Telephone**: (800) 323-5565 **Fax**: (310) 533-3899 **Hours**: 8:30 AM – 4:30 PM (PST)

Email: Support@SevilleClassics.com
Homepage: www.SevilleClassics.com

112020

#### **Parts List**



Required Tools (not included)




#### Please make sure you have all the parts on this list.

If you're missing parts, contact us for replacements at (800) 323-5565 or send an email to Support@SevilleClassics.com

#### **Use Instructions**

1. Locate controller on right side of desk.



#### **FAQS**

Q. Can I attach a monitor stand to it? What about dual monitors?

A. Yes! Be sure the desk is below it's 33 lbs. maximum weight limit.

Q. What size is the base?

A. Base measures 32.75 inches wide and 22 inches deep.

Q. Do I need to plug it in?

A. Yes! Works with any 120V outlet.

## **Specifications**

Dimensions: 35.43" W x 23.23" D x (5.9" to 19.7") H

Maximum weight on tray: 5 lbs. (2 kgs)

Maximum weight capacity overall: 33 lbs. (15 kgs)

USB Power: 2.1 amps @ 10 watts

#### **Customer Service Information**

Telephone: (800) 323-5565

Fax: (310) 533-3899

Hours: 8:30 AM – 4:30 PM (PST)

Email: Support@SevilleClassics.com

Homepage: www.SevilleClassics.com

## Safety


Failure to follow these instructions may result in property damage or




# personal injury



DO NOT place devices on desk edge.



MAKE SURE devices have cables long enough for the full-range (15 in/38 cm) of height-adjustment.




**DO NOT** route wires through desk legs.




**DO NOT** quickly lift desktop when loaded.

## **Assembly Instructions**


STEP 1. Remove AIRLIFT® DESK (A) from box and set on flat table.




Cut the plastic ties on both sides of the AIRLIFT® DESK (A).



STEP 3. Plug POWER CORD (G) into wall socket.



#### **STEP 4.** Press the UP button on the controller to lift the **AIRLIFT® DESK (A)**.







**WARNING**: DO NOT PLACE HANDS ON DESK LEGS. MOVING PARTS CAN CRUSH.




#### STEP 5.




**STEP 6.** Hook **BRACKETS (B)** over the bolts on the inner legs of the **AIRLIFT® DESK (A)**. Tighten bolts clockwise with included **ALLEN WRENCH (D)**.



## Cable Management



**ALWAYS** route your **POWER CORD (G)** through the <u>REAR</u> of the desk. **NEVER** route cables through the legs of the desk.



Stick the WIRE CLIP (E) to back of the crossbar. Use this clip to route cables from keyboards, mice and monitors through the <u>REAR</u> of the desk.

