User Guide & Instruction Manual
Version 3.0

Getting Started:
Step 1: Connect hardware to power source.
Step 2: Follow on-screen setup tutorial.
Step 3: Complete calibration protocol before operation.