	SDMA Command	ADMA Command	CPU Data Transfer	Non-DAT Transfer
SDMA System Address /Argument 2	Yes /No	No	No /Auto CMD23	No /No
Block Size	Yes	Yes	Yes	No (Protected)
Block Count	Yes	Yes	Yes	No (Protected)
Argument 1	Yes	Yes	Yes	Yes
Transfer Mode	Yes	Yes	Yes	No (Protected)
Command	Yes	Yes	Yes	Yes