SD Bus Power	SD Clock Enable	State of SDCLK
Change 0 to 1	0	Drive Low
	1	Start Clock With Specified Period Of High
Change 1 to 0	0	Drive Low
	1	Drive Low Immediately
0	Don't Care	Drive Low
1	Change 0 to 1	Start Clock With Specified Period Of High
	Change 1 to 0	Maintains Period Of High And Then Stops Clock And Drive Low