Value	DMA0
0	UARTO_RX
1	UARTO_TX
2	UART1_RX
3	UART1_TX
6	I2C0_RX
7	I2C0_TX
9	GPIO_TX
10	SPI0_RX
11	SPI0_TX
13	AUDIO_TX
14	I2C1_RX
15	I2C1_TX
16	I2S_RX
17	I2S_TX
20	DBI_TX
21	SOLO_RX
22	GPADC_RX
23	GPDAC_TX