


Canopy outline for reference


Polaris

Designed by Steve Shumate
Copyright © 2008 All Rights Reserved


All parts made from 6 mm Depron or BlueCore foam unless otherwise specified








	E	Aft Fuselage Bottom	





	Fuselage Top	F2	
Attach vertical tail base support here	е Тор	Right Fuselage Side	

		F2		
Install 0.38" foam strips here	Install 0.38" foam here	Left Fuselage Side		

