



Canopy outline for reference





Designed by Steve Shumate
Copyright © 2008 All Rights Reserved


All parts made from 6 mm Depron or BlueCore foam unless otherwise specified














	Fuselage Top		F2	
Attach vertical tail base support here	уе Тор	Install 0.38" foam here	Right Fuselage Side	loam strips here

Install 0.38" foam here	Left Fuselage Side	Install 0.38" foam here		



