

Vertical tail base side piece Sand to beveled edge












Polaris


Designed by Steve Shumate Copyright © 2008 All Rights Reserved


All parts made from 6 mm Depron or BlueCore foam unless otherwise specified
























Scale in inches



















| | 72 | | 9 | |
|-------------------------|---------------------|--------------------------------|-------------------------|--|
| Install 0.38" foam here | Right Fuselage Side | Install 0.38" foam strips here | Install 0.38" foam here | |
| | | | | |

| H2 | | | |
|--------------------|-------------------------|--|--|
| Left Fuselage Side | Install 0.38" foam here | | |







| Aileron | | |
|---------|--|--|
| | | |
| | | |
| | | |

| | nstall battery tray as shown | | Install battery tray as shown |
|----------|------------------------------|--|-------------------------------|
| <u> </u> | | | |


| | /d Fuselage Bottom | |
|--|--------------------|--|
| | | |
| | | |





Nacelle bottom Cut angle to match vertical tail leading edge Motor mount Make 1 from 1/8" ply











| | Start bending here | Left nacelle side | N1 | |
|----|--------------------------------|----------------------------|------------|--|
| | | .25" strips top and bottom | | |
| | | | | |
| J1 | Right nacelle side | Start bending here | Bevel. 62" | |
| | .25" strips top and bottom | | | |

