



To swap out the optics module, slide in the camera assembly, line it up with the holes on the side of the camera adapter, and secure it in place with 4 M3x8 flathead screws.