NPL Manual

Manual for the Calculation of Elastic-Plastic Materials Models Parameters

This Electronic Guide was produced as part of the Measurements for Materials System Programme on Design for Fatigue and Creep in Joined Systems


Introduction

Testing

Calculation of Parameters

Typical Predictions

Failure Criteria



Full contents page is available

© Crown copyright 2007 Reproduced with the permission of the Controller of HMSO and Queen's Printer for Scotland



Contents

Introduction

Overview of elastic-plastic models

Von Mises parameters

Von Mises information

Typical von Mises parameters

Drucker-Prager models

Linear Drucker-Prager parameter calculation

Associated and non-associated flow

Exponent Drucker-Prager parameter calculation

Data analysis

Equivalent data points

Effect of equivalent data point selection on parameters

Typical linear Drucker-Prager parameters

Typical exponent Drucker-Prager parameters

Cavitation model parameters

Cavitation model information

Typical cavitation model parameters

Calculation of parameters

Typical Predictions

Scarf joint

Lap joint

Tpeel joint

Butt joint

Failure Criteria

HOME

Tensile Data input

Tensile Testing

Typical tensile data

Tensile data for elastic-plastic models

Elastic and plastic behaviour

Hardening curves

Calculation of parameters

Shear Data input

Shear Testing

Typical shear data

Shear data parameters

Calculation of shear parameters

Compression Data input

Compression Testing

Typical compression data

Compression data calculations



INTRODUCTION

Finite element analysis is a computational tool that can be used for calculating forces, deformations, stresses and strains throughout a bonded structure. These predictions can be made at any point in the structure including within the adhesive layer. Furthermore, the element mesh can accurately describe the geometry of the bond line so the influence of geometrical features, such as the shape of fillets and boundaries with adherends, on joint performance can be accounted for in the analysis. This is particularly important in the design of adhesive joints because these features are usually associated with regions of stress and strain concentration likely to initiate joint failure.

Since adhesives are generally tough materials, they can sustain large strains before failure and, under these conditions, relationships between stress and strain are highly non-linear. The origin of non-linearity in a stress-strain curve for a polymeric adhesive can be explained in terms of enhanced creep brought about by an increase in molecular mobility caused by the application of stress. At moderate stresses this non-linear deformation is recoverable. At higher stresses, the molecular mobility is high enough for yielding to occur by plastic flow, which is not recoverable. Elastic-plastic materials are employed to describe deformation under large strain.

There are several models available for modelling the adhesive based on different criteria for plastic deformation. Predictions of joint performance at large strains close to joint failure depend on the model used. For the prediction of failure, stress and strain distributions in the adhesive need to be accurately calculated and a failure criterion for the adhesive needs to be established.

In its current form, this manual demonstrates the calculation of parameters for use with four different elastic-plastic material models. These four elastic plastic models are: von Mises, linear Drucker-Prager, exponent Drucker-Prager and Cavitation model.

Material Models	Data requirements	
Von Mises	tensile only	
Linear Drucker-Prager	tensile data and shear data at the same strain rate	
Exponent Drucker-Prager	tensile data and shear data at the same strain rate	
Cavitation model	tensile data, shear data and compressive data at the same strain rate	
Click <u>here</u> for an overview of the models		

BACK HOME NEXT



Material models overview

Von Mises criterion is the most simple yield criterion. It interprets yielding as a purely shear deformation process which occurs when the effective shear stress reaches a critical value. Simple equations relate the tensile yield stress, shear yield stress and compressive yield stress to a material property. Tests on adhesives under additional stress states reveal that in many cases yielding is sensitive to the hydrostatic component of stress in addition to the shear component. Therefore the von Mises criterion is not realistic for many adhesives.

The **linear Drucker-Prager** model is a simple modification of the von Mises criterion that includes some hydrostatic stress sensitivity. A parameter (μ) is introduced which characterises the sensitivity of yielding to hydrostatic stress. Two different stress states e.g. tension and shear are required to determine this parameter. The linear Drucker-Prager model is not capable of accurately describing the non-linear behaviour of an important class of tough adhesives - the rubber toughened materials.

The **exponent Drucker-Prager** is a more complex elastic-plastic model, which is better able to describe behaviour under stress states in which there is a high component of hydrostatic tension. Two different stress states e.g. tension and shear are required to determine λ the exponent Drucker-Prager hydrostatic stress sensitivity parameter.

In rubber-toughened epoxy, nucleation of cavities occurs in the rubber phase. The **Cavitation model** includes the influence of void nucleation on ductility through adaptation of the linear Drucker-Prager model. This model has been developed at NPL and is currently being used to evaluate the accuracy of predictions of deformation in various joint geometries.



TENSILE DATA INPUT

Tensile data are required for all four elastic-plastic materials models considered here.

The data obtained from tensile test measurements of bulk adhesive are nominal (or engineering) values, where stresses and strains have been calculated using the initial specimen dimensions.

Measurements of the following data are required:

- Nominal Stress (MPa)
- Nominal Axial Strain
- Nominal Transverse Strain


For more information on tensile testing please click <u>here</u>

Typical data for a rubber-toughened epoxy



Tensile Testing

Tensile tests [1] for the determination of Young's modulus (E') and Poisson's ratio (v) are carried out on standard specimens [2, 3] under constant deformation rate in a tensile test machine at relatively low strain rates e.g. 10 mm/min. For best accuracy, contacting extensometers should be used for the measurement of axial and transverse strain, ϵ_T and ϵ_t . Two extensometers mounted on opposite faces of the specimen should preferably be used for the axial strain measurement to eliminate small non-uniformity in the strain through the thickness of the specimen caused by bending. The transverse strain measurement should be made close to the axial gauge section and, if possible, between the contact points of the extensometers. The contact pressure used to attach the extensometers to the specimen should be large enough to prevent slippage but insufficient to indent the specimen surface. Strain gauges are not recommended as they locally stiffen the specimen [1].



Values for Young's modulus and Poisson's ratio are calculated from the regression slopes in the linear region of the σ_T - ϵ_T and ϵ_t - ϵ_T curves. Use of regression slopes is preferable to single point values owing to the potential scatter in the data points (particularly the ϵ_t - ϵ_T data) that is mainly due to uncertainties in the small extensions measured. Whilst elastic values can be determined over any strain range where the data appear linear, the slight curvature due to viscoelastic effects will tend to reduce the value of E as the strain range widens.

The measurement of tensile hardening curves involves use of the same tests out to larger strains. Contacting extensometers, unless they have been modified, typically have an upper strain limit of around 0.05. They may also initiate premature failure in the specimen at a point of contact. For these tests, the use of a video extensometer is therefore preferable for the measurement of axial strain. The videoextensometer gauge markings are visible on the tensile test specimen shown above. These instruments are generally unsatisfactory for the measurement of small displacements and so a contacting device is best used to measure the lateral strain for the determination of true stresses and the plastic component of Poisson's ratio.



- 1. G.D. Dean and B.C. Duncan, Preparation and Testing of Bulk Specimens of Adhesives. NPL Measurement Good Practice Guide No 17, July 1998.
- 2. ISO 3167:1993, Plastics Multipurpose test specimens.
- 3. ISO 527-2:1993, Plastics Determination of tensile properties Part 2: Test conditions for moulding and extrusion plastics.




Nominal Nominal Strain Stress (MPa) 0.0004 1.44 0.0015 4.80 0.0035 10.34 0.0053 15.73 0.0070 20.71 0.0086 24.28 0.0103 28.02 0.0120 31.59 0.0135 34.93 0.0153 37.89 0.0172 40.46 0.0189 43.13 0.0211 45.03 0.0230 46.81 0.0251 48.57 0.0274 49.68 0.0298 50.65 0.0322 51.46 0.0348 52.25 0.0373 52.90 0.0399 53.36 0.0423 53.63 0.0452 54.07 0.0476 54.46 0.0504 54.80 0.0533 54.98 0.0560 55.33 0.0588 55.84 0.0615 55.97 0.0643 56.19 0.0670 56.32 0.0699 56.44 0.0728 56.79 0.0758 56.86 0.0786 57.09 0.0812 57.17 0.0842 57.26

Tensile Data

Here are typical tensile data for a rubber-toughened epoxy. The data are shown in tabular and graphical form.

tensile stress-strain curve for a rubber toughened epoxy





Tensile Data for Elastic-Plastic Models

Elastic-plastic models in FE systems require data in the form of elastic constants to describe elastic behaviour and parameters that describe the yield, hardening and flow behaviour to describe plastic (non-linear) behaviour. Further information on <u>elastic and plastic behaviour</u> is available. Data from tensile tests are required in the form of true stresses and strains for the calculation of the elastic-plastic model parameters. The change in cross-section of the specimen during tensile tests needs to be included to calculate true stress and strains. Under tensile loading, the specimen cross-section reduces. True values can be calculated from the nominal (engineering) values, which are based on the original specimen dimensions.

The following data can be calculated:

- True stress, σ_T
- True strain, ε_T
- True transverse stress, ε_t
- Nominal Poisson's ratio, v'
- Young's Modulus, E'
- True Elastic modulus, E
- True Poisson's ratio, v
- True plastic strain, ϵ_T^P
- True transverse plastic strain, ε^P_t
- True plastic Poisson's ratio, ν^p
- Hardening curve


For more information on the calculation of these parameters please click here

Of the above data, the Young's modulus, Poisson's ratio, true stress, true plastic strain, and true plastic Poisson's ratio are required for the elastic-plastic models parameter calculations. The hardening curve is also required. This is a plot of true stress versus true plastic strain, which is sampled to reduce the number of data points and then used in tabular form within elastic-plastic materials models. More information on the hardening curve can be obtained by clicking on the link above.



Elastic-Plastic Behaviour

With elastic-plastic models, calculations of stress and strain distributions at low strains are based on linear elasticity. The onset of non-linearity is attributed to plastic deformation and occurs at a stress level regarded as the first yield stress. The subsequent increase in stress with strain is associated with the effects of strain hardening, and increases to a maximum corresponding to the flow region. In this non-linear region, the total strain is considered to be the sum of a recoverable elastic component and a plastic component, which is non-recoverable. Stress analysis calculations then involve the use of multiaxial yield criteria and a flow law. The yield criterion relates components of applied stress field to material parameters after the onset of yielding. The material parameters will depend upon the plastic strain for a strain hardening material.




The calculation of plastic strain components is achieved in plasticity theory using a flow rule, which relates increments of plastic strain to a plastic flow potential. If the flow behaviour for a particular material is such that the flow potential can be identified with the yield function then this is termed associated flow. In general, this will be an approximation and extra information is needed to characterise non-associated flow. In order to calculate some of the parameters in elastic-plastic models, it is necessary to select stress values from different tests under the same state of yielding. This requires the definition of an effective plastic strain, and equivalent stresses are then a set of stresses that characterise stress states having the same effective plastic strain.



Hardening Curve

Strain hardening data can be given in either single or multiple rate form. If a single strain rate hardening curve is used, this strain rate is assumed to be the average strain rate in the adhesive layer. The use of multiple rate hardening curves allows for regions of varying strain rate within the adhesive layer. Generally four strain hardening curves separated by a factor of 10 in strain rate are used. One is chosen with a strain rate approximately the same as the average strain rate in the joint, one higher rate curve and one lower rate curve. An extremely low rate curve is also required and is designated the zero rate curve. Analysis difficulties can occur if more hardening curves are used or if too many data points are used to characterise each curve. The plastic strain value must always increase otherwise the analysis will not run. The best approach is to sample the hardening data until a representative curve is achieved. The sampling density of the hardening curves shown in the figure has been used successfully.



The hardening curve data are required in the tabular form of yield stress with plastic strain where the first pair of numbers must correspond to the initial yield stress at zero plastic strain. If strains in the analysis exceed the maximum effective strain supplied in the hardening curve then the analysis will assume that additional extension occurs with no hardening. One means of getting around this is to extrapolate a point on the hardening curve at a significantly higher strain.



Tensile Data Calculations

Data from tensile tests are required in the form of true stresses and strains for the calculation of the elastic-plastic model parameters. These are related to nominal (engineering) values and based on the original specimen dimensions by the equations shown below.

Click here for a definition of the symbols

True Stress	$\sigma_{\mathrm{T}} = \frac{\sigma_{\mathrm{T}}^{'}}{\left(1 - \nu^{'} \varepsilon_{\mathrm{T}}^{'}\right)^{2}}$
True Strain	$\varepsilon_{\rm T} = \ln(1 + \varepsilon_{\rm T}')$
True Transverse Strain	$\varepsilon_{t} = \ln(1 + \varepsilon_{t}^{'})$
Nominal Poisson's Ratio	$v' = -\frac{\varepsilon_t}{\varepsilon_T}$
Young's Modulus	$E = \frac{\sigma_T}{\varepsilon_T^e}$
True Poisson's Ratio	$v = -\frac{\varepsilon_t}{\varepsilon_T}$
True Plastic Strain	$\varepsilon_{\mathrm{T}}^{\mathrm{P}} = \varepsilon_{\mathrm{T}} - \ln\left(1 + \frac{\sigma_{\mathrm{T}}}{\mathrm{E}}\right)$
True Transverse Plastic Strain	$\varepsilon_t^P = \varepsilon_t - \ln\left(1 - v' \frac{\sigma_T}{E}\right)$
True Plastic Poisson's Ratio	$v^P = -\frac{\varepsilon_t^P}{\varepsilon_T^P}$

BACK

HOME



The definition of each symbol is given below

$\sigma_{\mathrm{T}}^{'}$, $\epsilon_{\mathrm{T}}^{'}$, $\epsilon_{\mathrm{t}}^{'}$	nominal (engineering) values of tensile stress, axial strain and transverse strain respectively, calculated using original specimen dimensions
$\sigma_{_T}$, $\epsilon_{_T}$, $\epsilon_{_t}$	true values of tensile stress, axial strain and transverse strain respectively, these take into account the instantaneous specimen dimensions.
Ε,ν	Young's modulus and nominal Poisson's ratio respectively. Modulus and Poisson's ratio values are calculated at a point or by regression over a strain range e.g. 0.0005 to 0.0025 strain range. The Young's modulus is calculated from stress divided by strain, and at small strains the true values are equivalent to the nominal values.
ν , ϵ_{T}^{e}	true Poisson's ratio and true elastic axial strain respectively
$\sigma_{\mathrm{T}}^{\mathrm{P}}, \varepsilon_{\mathrm{T}}^{\mathrm{P}}, \nu^{\mathrm{P}}$	true axial plastic strain, true transverse plastic strain and true plastic Poisson's ratio respectively

BACK



VON MISES PARAMETERS

Von Mises parameters can be output after tensile testing as these parameters are calculated from tensile data only.

The parameters required are Young's modulus, Poisson's ratio and a hardening curve (true tensile stress vs true tensile plastic strain)

VON MISES INFORMATION

TYPICAL VON MISES PARAMETERS

Continue for calculation of Drucker-Prager and Cavitation model parameters

BACK HOME TYPICAL PREDICTIONS NEXT



VON MISES MATERIAL MODEL

The most simple yield criterion interprets yielding as a purely shear deformation process which occurs when the effective shear stress σ_e reaches a critical value. This effective stress is defined in terms of principal stress components σ_i (i = 1, 2 or 3) by

$$\sigma_{e} = \left\{ \frac{1}{2} \left[(\sigma_{1} - \sigma_{2})^{2} + (\sigma_{2} - \sigma_{3})^{2} + (\sigma_{3} - \sigma_{1})^{2} \right] \right\}^{\frac{1}{2}}$$

The von Mises criterion then relates σ_e to the yield stress in tension σ_T by

$$\sigma_e = \sigma_T$$

The tensile yield stress σ_T is now a material parameter and has a minimum value, which denotes the limit of elastic behaviour and the start of plastic deformation and will increase with tensile plastic strain. The variation of yield stress with plastic strain is called the tensile strain hardening function.

The von Mises criterion predicts that the tensile yield stress, effective shear yield stress and compressive yield stress are related by

$$\sigma_{\rm T} = \sigma_{\rm C} = \sqrt{3}\sigma_{\rm S}$$

Tests on adhesives under additional stress states such as shear and compression reveal that yielding is sensitive to the hydrostatic component of stress in addition to the shear component. The von Mises criterion is therefore not realistic for some materials.



VON MISES PARAMETERS

The von Mises materials model parameters are shown below in both a general format and also the format required by the ABAQUS finite element software

ABAQUS FORMAT

Young's modulus, E = 2970 MPa Poisson's ratio, v = 0.35

*ELASTIC, TYPE=ISO 2970., 0.35

true tensile	true tensile
plastic strain	stress (MPa)
0.0000	18.197
0.0002	24.425
0.0006	28.210
0.0012	33.578
0.0022	38.299
0.0034	42.436
0.0050	45.664
0.0080	49.321
0.0110	50.979
0.0139	52.377
0.0170	53.557
0.0206	54.412
0.0254	55.243
0.0301	56.128
0.0340	56.527
0.0389	57.455
0.0440	57.920
0.0490	58.287
0.0543	58.989
0.0580	59.213
0.0607	59.376

*PLASTIC
18.197, 0
24.425, 0.0002
28.21, 0.0006
33.578, 0.0012
38.299, 0.0022
42.436, 0.0034
45.664, 0.005
49.321, 0.008
50.979, 0.011
52.377, 0.0139
53.557, 0.017
54.412, 0.0206
55.243, 0.0254
56.128, 0.0301
56.527, 0.034
57.455, 0.0389
57.92, 0.044
58.287, 0.049
58.989, 0.0543
59.213, 0.058

59.376, 0.0607

Continue for calculation of Drucker-Prager and Cavitation model parameters

NEXT

BACK

<u>HOME</u>



SHEAR DATA INPUT

Shear data are required for the calculation of Drucker-Prager and cavitation model parameters

The following data are required from shear measurements on bulk adhesive specimens:

- Shear Stress (MPa)
- Shear Strain

For more information on shear testing please click here


Typical data for a rubber-toughened epoxy



Shear Testing

Shear tests on bulk specimens can be carried out using the notched-plate shear (Arcan) [1], [2] or notched-beam shear (Iosipescu) [2], [3] methods. These methods are similar in that they use a double-notched specimen to achieve a region of predominantly pure shear in the centre of the specimen between the notches. Of these methods, the notched-plate shear test is probably the preferred one because the loading stage is simpler to construct, extensometers can be more conveniently used for strain measurement [4] and thinner test specimens can be employed. A schematic diagram of the specimen and loading arrangement is shown.

Specimen dimensions of 12 mm for the notch separation with a radius of the notches of 1.5 mm have been used successfully. A purpose-built extensometer [4] has been used for measuring the relative displacement of two points either side of a vertical line through the centre of the specimen. The separation of these points is 3 mm. Finite element analyses of the stress and strain distributions in the specimen reveal some non-uniformity in the shear stress between the notches and a small contribution to the measured displacements from bending. These give rise to typical errors of about 7% in shear modulus and 2% in the shear flow stress.



- 1. Arcan, Z. Hashin and A. Voloshin, Experimental Mechanics, vol 18 (1978) p141.
- 2. G.D. Dean and B.C. Duncan, Preparation and Testing of Bulk Specimens of Adhesives. NPL Measurement Good Practice Guide No 17, July 1998.
- 3. D.F. Adams and D.E, Walrath, J. Composite Materials, vol 21 (1987) p494.
- 4 G. Dean, B. Duncan, R. Adams, R. Thomas and L. Vaughn, Comparison of bulk and joint specimen tests for determining the shear properties of adhesives. NPL report CMMT(B)51, April 1996.




Shear Nominal Strain Stress (MPa) 0.0010 0.838 0.0026 2.670 0.0044 4.374 0.0063 6.186 0.0082 7.997 0.0101 9.742 0.0121 11.560 0.0141 13.237 0.0163 14.961 0.0188 16.813 0.0212 18.477 0.0239 20.309 0.0266 21.965 0.0294 23.648 0.0325 25.339 0.0356 26.995 0.0393 28.760 0.0432 30.409 0.0474 32.059 0.0524 33.735 0.0579 35.318 0.0640 36.771 0.0705 38.029 0.0765 38.934 0.0834 39.732 0.0895 40.300 0.0966 40.800 0.1026 41.145 0.1087 41.422 0.1154 41.673 0.1217 41.848 0.1277 41.963 0.1344 42.126 0.1409 42.227

Shear Data

Here are typical tensile data for a rubber-toughened epoxy. The data are shown in tabular and graphical form.

Shear stress-strain curve for a rubber toughened epoxy






The following data can be calculated from shear data:

- Shear Modulus, G
- Plastic strain, ε^P_S
- Effective Shear Stress, σ_{Seff}
- Effective Shear Plastic Strain, ϵ_{Seff}^{P}

For more information on the calculation of these parameters please click <u>here</u>

The experimental shear stress and plastic strain are required for the Drucker-Prager models parameter calculations. The effective stress and plastic strain data are useful for comparison with tensile results and are also used in the calculation of some of the Cavitation model parameters. For the Cavitation model a hardening curve is derived from the shear stress and plastic strain data.





Shear Data Calculations

The required shear data are obtained from the equations below.

Shear Modulus	$G = \frac{\sigma_S}{\varepsilon_S}$
Plastic Strain	$\varepsilon_{\rm S}^{\rm P} = \varepsilon_{\rm S} - \frac{\sigma_{\rm S}}{\rm G}$
Effective Shear Stress	$\sigma_{\rm Seff} = \sqrt{3} \sigma_{\rm S}$
Effective Shear Plastic Strain	$ \varepsilon_{\text{Seff}}^{\text{P}} = \frac{\varepsilon_{\text{S}}^{\text{P}}}{\sqrt{3}} $

The definition of each symbol is given below:

 $\begin{array}{ll} \sigma_{_S} \;, \epsilon_{_S} & \text{measured values of shear stress and shear strain respectively} \\ G \;, \epsilon_{_S}^{_P} & \text{shear modulus and plastic component of shear strain respectively} \end{array}$

 σ_{Seff} , ϵ_{Seff}^{P} effective shear stress and effective plastic strain respectively under a shear stress state

The measured shear stress and strain can be corrected to give a more accurate value of stress or strain in the centre of the arcan specimen [1]

1. <u>G.D. Dean, B.E. Read and B.C. Duncan, An Evaluation of Yield Criteria for Adhesive for Finite Element Analysis, NPL Report CMMT(A)117, January 1999</u>



DRUCKER-PRAGER PARAMETERS

Tensile and shear testing and data analysis are required to obtain Drucker-Prager parameters.

The required parameters are:

Tan B	Hydrostatic stress sensitivity factor for linear Drucker-Prager
Ψ	Flow parameter for linear and exponent Drucker-Prager
а	Hydrostatic stress sensitivity factor for exponent Drucker-Prager
b	Exponent in exponent Drucker-Prager

LINEAR DRUCKER-PRAGER PARAMETER CALCULATION

EXPONENT DRUCKER-PRAGER PARAMETER CALCULATION



LINEAR DRUCKER-PRAGER MATERIAL MODEL

For the linear Drucker-Prager model the von Mises criterion is modified to include hydrostatic stress sensitivity as follows:

$$\sigma_{\rm e} = \sigma_{\rm o} - \mu \, \sigma_{\rm m} \tag{1}$$

here σ_0 is a material parameter that is related to the shear yield stress by:

$$\sigma_{\rm o} = \sqrt{3} \, \sigma_{\rm S}$$

and σ_m is the hydrostatic stress given in terms of principal stresses by:

$$\sigma_{\rm m} = \frac{1}{3} \left(\sigma_1 + \sigma_2 + \sigma_3 \right)$$

Equation (1) is identical to the linear Drucker-Prager model in the finite element system ABAQUS where the notation used is:

$$q = d + p \tan \beta$$

where $q = \sigma_e$, $p = -\sigma_m$, $tan \beta = \mu$ and $d = \sigma_o$

The parameter μ depends on the adhesive material and characterises the sensitivity of yielding to hydrostatic stress. A value for μ is determined from tests under two different stress states. Using yield stresses from shear and tensile tests:

$$\tan\beta = \mu = 3\left[\left(\sqrt{3}\,\sigma_{\rm S}/\sigma_{\rm T}\right) - 1\right]$$

It should be noted that the above yield stresses σ_T and σ_S are associated with the same effective plastic strain.

Associated and non-associated flow



Associated and non-associated flow

The calculation of plastic strain components is achieved in plasticity theory using the flow rule in which increments of plastic strain are related to

a plastic flow potential F by the equation:

$$d\epsilon_{ij}^{p} = d\lambda \frac{\partial F}{\partial \sigma_{ij}}$$

where $d\lambda$ is a factor that depends on stress state and is determined by ensuring equivalence of the plastic work done under all stress states. For some materials, the flow potential F can be identified with the yield function, in which case the flow is said to be associated and:

$$F = \sigma_e + \mu \sigma_m - \sigma_o$$

This relationship is valid if the resultant of the strain increment during flow is directed normal to the yield surface. The validity of this assumption for adhesives needs to be verified and a more general expression for F is based on non-associated flow.

Under non-associated flow, a more general expression for F is: $F = \sigma_e + \mu' \sigma_m - \sigma_o$

The flow parameter μ' is then a material parameter that must be measured:

$$\mu' = \frac{3(1-2v^p)}{2(1+v^p)}$$

where v^P is the plastic component of Poisson's ratio determined under uniaxial tension and is given by:

$$v^{p} = \frac{-\varepsilon_{t}^{p}}{\varepsilon_{T}^{p}}$$

In ABAQUS, the flow potential is:

$$F = q - p \tan \psi - d$$

where tan ψ has replaced μ '. If the calculated value of parameter μ ' is not equal to μ then flow is termed non-associated. Associated flow is obtained by setting μ ' equal to μ .

The flow behaviour of adhesives is generally non-associated. Non-associated flow results in a nonsymmetrical stiffness matrix and negative eigenvalues can occur even when the hardening data doesn't show softening. When an analysis reaches such a bifurcation point, an implicit solver may have difficulty converging. For simplicity, associated flow can be assumed by setting μ' equal to μ but the resulting loss in the accuracy of stress and strain calculations will be uncertain.

BACK

<u>HOME</u>



EXPONENT DRUCKER-PRAGER MATERIAL MODEL

Although the linear Drucker-Prager yield criterion includes some sensitivity of yielding to the hydrostatic stress, it is not able to describe behaviour with any accuracy under stress states in which there is a high component of hydrostatic tension. Such stress states are common locally in adhesive bonds because of the high constraint imposed by the adherend under forces directed normal to the interface. An alternative criterion is significantly more accurate under these conditions and is often written in the form:

$$\sigma_e^2 = \lambda \sigma_T^2 - 3(\lambda - 1)\sigma_T \sigma_m$$

where λ is a hydrostatic stress sensitivity parameter that relates stresses σ_S and σ_T under shear and uniaxial tension by the equation:

$$\lambda = \frac{3\sigma_S^2}{\sigma_T^2}$$

This criterion is implemented in ABAQUS as the exponent Drucker-Prager model with the exponent parameter, b, equal to 2. The yield criterion equation is then expressed in the form:

$$aq^2 = p + p_1$$

where

$$a = \frac{1}{3\sigma_T(\lambda - 1)}$$
 and $p_1 = a\lambda\sigma_T^2$

A hyperbolic function has been chosen for the flow potential F. The asymptote of the hyperbola coincides with the flow potential for the linear Drucker-Prager model. The relevant material parameter in the flow law is therefore $\tan \psi = \mu'$ which can be calculated using:

$$\mu' = \frac{3(1-2v^p)}{2(1+v^p)}$$

Because in ABAQUS, the flow potential assumed for this model is very similar to that used in the linear Drucker-Prager model, effective plastic strains and the associated equivalent stresses may be taken to be the same for the two models.

BACK

HOME



DATA ANALYSIS


The following data need to be calculated from tensile and shear data

$$\sigma_{T} \varepsilon_{T}^{P}$$
 $\sigma_{S} \varepsilon_{S}^{P}$

The above values obtained from tensile and shear data are used to obtain equivalent data points for calculation of Drucker-Prager parameters. When the resultant value from a tensile data point equals that from a shear data point, the plastic strain components from these two points are said to be equivalent (this is most easily seen graphically, as shown). The stresses corresponding to these two points are values that are used to calculate the model parameters.

These values are not unique, there may be other equivalent stress values for given sets of data. How these vary depends on the shape of the stress strain curves - if the yield stress data show a plateau (horizontal) region, then yield stresses do not vary much with effective plastic strain.

An example showing the effect of equivalent data point selection on parameters can be seen here.





Equivalent Data Points

The parameters μ and λ are calculated from yield stresses obtained from tests under different stress states. The yield stress values used in the calculations must correspond to the same effective plastic strain ϵ_{Seff}^{P} . Associated with an effective plastic strain is an effective stress σ_{Seff} which is defined with reference to a pure shear stress state by the relationship:

$$\sigma_{\rm eff} = \sqrt{3} \, J_{\rm 2D}^{1/2}$$

so that

$$\sigma_{\rm eff} = \sqrt{3} \, \sigma_{\rm S}$$

Effective stresses and plastic strains σ_{ij} and ϵ_{ij}^P under an arbitrary stress state are then defined such that the plastic work done by this stress state is the same as the effective plastic work so that:


$$\sigma_{ij} \; \epsilon_{ij}^{P} = \sigma_{eff} \; \epsilon_{eff}^{P}$$

In the case of shear and tensile stresses:

$$\sigma_S \; \epsilon_S^P = \sigma_{eff} \; \epsilon_{eff}^P = \sigma_T \; \epsilon_T^P$$

so from the top equation the effective plastic strain is given by:

$$\varepsilon_{\rm o}^{\rm P} = \frac{1}{\sqrt{3}} \varepsilon_{\rm S}^{\rm P}$$



BACK

<u>HOME</u>




Effect of equivalent data point selection on parameters


This graph marks the location of 9 pairs of equivalent data points. Parameter values will vary depending on which pair of data points are selected. This can be seen in the table below, which shows parameters calculated for the linear and exponent forms of the Drucker-Prager model. In this case, the parameter ψ does not change as this is related to plastic component of the Poisson's ratio, which does not vary significantly over the strain range of interest for this material (see graph) and so is taken as a constant.

	Linear		Expo	nent
Data point set	β	Ψ	а	Ψ
1	34.004	28.515	0.0124	28.515
2	37.171	28.515	0.0107	28.515
3	38.530	28.515	0.00996	28.515
4	39.204	28.515	0.00955	28.515
5	39.279	28.515	0.00938	28.515
6	39.330	28.515	0.00927	28.515
7	38.934	28.515	0.00931	28.515
8	38.958	28.515	0.00926	28.515
9	38.388	28.515	0.00939	28.515

Force-extension predictions obtained for a scarf joint using the above Drucker-Prager parameters are shown on the right. It can be seen that predictions obtained from parameter sets obtained at lower plastic strains (sets 1 and 2) are higher than those from the other data sets. Predictions from these other seven parameter sets are much more consistent. This is due to the fact that the parameters have been calculated from equivalent data points that are in the plateau regions of the tensile and shear stress strain curves.

BACK





HOME



DRUCKER-PRAGER PARAMETERS

After careful data analysis the Drucker-Prager parameters can be obtained.

<u>Typical LINEAR Drucker-Prager parameters</u> for a rubber-toughened epoxy

<u>Typical EXPONENT Drucker-Prager parameters</u> for a rubber-toughened epoxy

Continue for calculation of Cavitation model parameters

BACK HOME TYPICAL PREDICTIONS NEXT



Linear Drucker-Prager Parameters

The linear Drucker-Prager materials model parameters shown below are in the format required by the ABAQUS finite element software

*ELASTIC, TYPE=ISO

2970., 0.35

**--Linear Drucker-Prager plasticity model

**--(Beta,K,Psi)

*DRUCKER PRAGER, SHEAR CRITERION=LINEAR

39.2, 1,28.5

*DRUCKER PRAGER HARDENING, TYPE=TENSION

18.197, 0

24.425, 0.0002

28.21, 0.0006

33.578, 0.0012

38.299, 0.0022

42.436, 0.0034

45.664, 0.005

49.321, 0.008

50.979, 0.011

52.377, 0.0139

53.557, 0.017

54.412, 0.0206

55.243, 0.0254

56.128, 0.0301

56.527, 0.034

57.455, 0.0389

57.92, 0.044

58.287, 0.049

58.989, 0.0543

59.213, 0.058

59.376, 0.0607

BACK

HOME



Exponent Drucker-Prager Parameters

The exponent Drucker-Prager materials model parameters shown below are in the format required by the ABAQUS finite element software

```
*ELASTIC, TYPE=ISO
2970., 0.35
**--Exponent Drucker-Prager plasticity model
**--(a,b,"not used",Psi)
*DRUCKER PRAGER, SHEAR CRITERION=EXPONENT FORM
0.0093, 2, 0, 28.5.
*DRUCKER PRAGER HARDENING, TYPE=TENSION
18.197, 0
24.425, 0.0002
28.21, 0.0006
33.578, 0.0012
38.299, 0.0022
42.436, 0.0034
45.664, 0.005
49.321, 0.008
50.979, 0.011
52.377, 0.0139
53.557, 0.017
54.412, 0.0206
55.243, 0.0254
56.128, 0.0301
56.527, 0.034
57.455, 0.0389
57.92, 0.044
58.287, 0.049
58.989, 0.0543
59.213, 0.058
```

BACK HOME

59.376, 0.0607



COMPRESSION DATA INPUT

To calculate the cavitation model parameters the following data are required from compression measurements on bulk adhesive specimens:

- Compressive Stress (MPa)
- Compressive Strain

For more information on compression testing please click <u>here</u>

Typical data for a rubber-toughened epoxy



Compression Testing

Tests under uniaxial compression are difficult to perform because of the promotion of buckling of the specimen under high forces.

The ISO standard test ISO 604, Plastics - Determination of compressive properties can be used to produce satisfactory results. This test employs short specimens with approximate dimensions 10 mm high x 10 mm wide. The thickness should be at least 3 mm and preferably higher. The top and bottom faces of the specimen must be machined smooth and accurately parallel. These are loaded in a testing machine between platens whose faces are smooth and accurately parallel. To minimise constraints by the platen surfaces to lateral expansion of the specimen during loading, the surfaces of the platens are lubricated with oil. Extensometers are used to measure changes in the platen separation, and nominal strain values are derived from the original specimen length. At small strains, errors in strain values arise through non-uniformity of the strain along the length of the specimen by this loading method. It is possible to apply a correction to these strains using a knowledge of Young's modulus from tensile tests. However, it is the properties under plastic deformation that are of most interest from this test. At small strains, uncertainties in plastic strains will be large but should become smaller at larger plastic strains.




Compressive Strain	Compressive Stress (MPa)		
0.0000 0.0009	0.0317 3.6501		
0.0009	7.2030	Compressive	Compressive
0.0021	11.0594	Strain	Stress (MPa)
0.0033	14.9195	cont	cont
0.0048	18.8314	0.0592	83.2794
0.0030	22.6558	0.0592	84.2728
0.0070	26.4015	0.0037	85.1168
0.0095	29.9514	0.0723	85.8559
0.0108	33.4151	0.0768	86.4863
0.0120	36.7533	0.0834	87.0832
0.0123	39.9197	0.0920	87.6642
0.0146	43.0115	0.1051	88.1283
0.0158	45.8811	0.1031	88.5238
0.0171	48.6312	0.1117	88.9418
0.0183	51.2853	0.1102	89.3115
0.0196	53.7570	0.1313	89.6151
0.0208	56.1216	0.1379	89.9774
0.0221	58.3276	0.1445	90.2428
0.0234	60.4476	0.1510	90.4387
0.0247	62.4127	0.1576	90.6490
0.0266	65.0851	0.1642	90.8581
0.0298	69.0216	0.1707	91.0556
0.0330	72.2359	0.1772	91.1761
0.0362	74.8374	0.1837	91.2902
0.0395	76.9510	0.1902	91.3778
0.0428	78.6097	0.1968	91.4686
0.0460	79.9529	0.2033	91.5018
0.0526	81.9421	0.2098	91.4905
		0.2163	91.3706

Compression Data

Here are typical tensile data for a rubber-toughened epoxy.

The data are shown in tabular and graphical form.

Compression stress-strain curve for a rubber-toughened epoxy





Compression Data Calculations

The required compression data are obtained from the equations below.

True Compressive Stress (MPa)	$\sigma_{\rm C} = \frac{\sigma_{\rm C}'}{\left(1 - \nu' \varepsilon_{\rm C}'\right)^2}$
True Compressive Strain	$\varepsilon_{\rm C} = \ln\left(1 + \varepsilon_{\rm C}'\right)$
True Compressive Plastic Strain	$\varepsilon_{\rm C}^{\rm P} = \varepsilon_{\rm C}^{'} - \frac{\sigma_{\rm C}}{\rm E}$


The definition of each symbol is given below:

 $\sigma_{C}^{'}$, $\epsilon_{C}^{'}$, $\nu^{'}$, E

nominal (engineering) values of compressive stress, compressive strain, Poisson's ratio and Young's modulus respectively. The compressive stress and strain are negative values.

 $\sigma_{\rm C}$, $\varepsilon_{\rm C}$, $\varepsilon_{\rm C}^{\rm P}$

true values of compressive stress, compressive strain and compressive plastic strain respectively. The compressive stress and strain are negative values.



Plot showing tensile, effective shear and compressive hardening data.

The above data are used along with tensile and effective shear data to calculate the Cavitation model parameters. A plot with data from all tests is shown above. To calculate the parameters, stress values from effective shear (σ_0) , tensile (σ_T) and compression (σ_C) tests must be calculated at the same effective plastic strain. These are calculated as before e.g.

$$\sigma_{\rm S} \, \epsilon_{\rm S}^{\rm P} = \sigma_{\rm C} \, \epsilon_{\rm C}^{\rm P}$$



CAVITATION MODEL PARAMETERS

The following Cavitation model parameters are calculated from tensile, shear and compression data. For more details about these parameters please click here.

μ	hydrostatic stress sensitivity parameter	
k	defines influence of rubber on yield stress	
q	cavity interaction parameter	
V_{R0}	volume fraction of rubber	
μ'	flow parameter	
ε _{1ν}	critical volumetric strain	
ϵ_{2v}	mean volumetric strain	
β	defines the distribution of strains for cavitation	
σ_{0u}	Parameters used to	
σ_{0r}	fit shear data to produce an effective shear hardening curve	
β_0		
g o		

CAVITATION MODEL INFORMATION

TYPICAL CAVITATION MODEL PARAMETERS

BACK HOME TYPICAL PREDICTIONS NEXT



CAVITATION MODEL PARAMETERS

	0/(VII/(III0) III0) III0 III0		
$\mu = 3 \left(1 - \frac{\sigma_0}{\sigma_C} \right)$	The hydrostatic stress sensitivity parameter μ is determined from measurements of yield stress under two different stress states		
$\left(\begin{array}{c} \mu - 3 \\ \sigma_{c} \end{array} \right)$	for which no cavities are present (shear and compression). This is calculated from the equation shown, where σ_0 , from the		
	shear stress, and σ_c , the compressive stress, are at the same effective plastic strains.		
k	k is a parameter defining the influence of rubber on yield stress and q is the cavity interaction parameter. k and q are taken to		
	have typical values which have been determined from additional tests on rubber toughened thermoplastics. For a rubber-toughened epoxy k=1.35 and q=1.6.		
V_{R0}	Volume fraction of rubber. If possible obtain a value for the volume fraction of rubber from the adhesive supplier. Note that the		
	effective value for this parameter may be higher than this if sources other than rubber, such as filler, act as cavity nucleation		
	sites. Otherwise, the volume fraction of rubber can be determined by substituting equation (i) below into the yield equation (ii)		
	(σ_{o1}) is the effective shear stress of the adhesive when all the rubber particles have cavitated, and σ_T is a tensile yield stress)		
	and solving for V _{R0}		
	σ^2 σ^2 σ^2		
	$Eq (ii) \sigma_{ol} = \sigma_{0} / \left(1 - kv_{R0} \right) \qquad \qquad Eq (ii) \frac{\sigma_{e}^2}{\sigma_{M}^2} - \left(q_1 f \right)^2 + 2q_1 f \cosh \frac{3\sigma_{m}}{2\sigma_{M}} = \left(1 - \frac{\mu \sigma_{m}}{\sigma_{M}} \right)^2$		
μ'	A value for the flow parameter μ' is determined from Poisson's ratio measurements under tension out to strain levels for which cavity nucleation is complete. An experimental value for ν^p is obtained and μ' is determined using the equation below. If μ' is not equal to μ then flow is non-associated. $v^P = \frac{\left[\frac{\sigma_T}{\sigma_{ol}} - q v_{Ro} \sinh\left(\frac{\sigma_T}{2\sigma_{ol}}\right) - \frac{2\mu'}{3}\left(1 - \frac{\mu'\sigma_T}{3\sigma_{ol}}\right)\right]}{\frac{2\sigma_T}{\sigma_{ol}} + q v_{Ro} \sinh\left(\frac{\sigma_T}{2\sigma_{ol}}\right) + \frac{2\mu'}{3}\left(1 - \frac{\mu'\sigma_T}{3\sigma_{ol}}\right)}$		
	ratio measurements under tension out to strain levels for which $\frac{1}{\sigma} - q v_{Ro} \sinh \left(\frac{1}{2\sigma} \right) - \frac{1}{3} \left(\frac{1}{3\sigma} \right) \right]$		
	cavity nucleation is complete. An experimental value for v^p is $v^p = \frac{\begin{bmatrix} 0 & 0 \\ 20 & 0 \end{bmatrix}}{\begin{bmatrix} 20 & 0 \\ 01 \end{bmatrix}}$		
	obtained and μ ' is determined using the equation below. If μ ' is $2\sigma_T + \sigma_T = \sinh(\sigma_T) + 2\mu'(1 + \mu'\sigma_T)$		
	not equal to μ then flow is non-associated. $\frac{1}{\sigma} + q v_{Ro} \sin \left(\frac{1}{2\sigma} \right) + \frac{1}{3} \left(\frac{1}{3\sigma} \right)$		
	These cavity nucleation parameters are obtained by an iterative process to achieve satisfactory predictions of the shape of the		
	tensile stress-strain curve and the Poisson's ratio vs strain curve in the strain range associated with cavity nucleation. This		
ϵ_{1v}	requires a method for obtaining solutions for the case of uniaxial tension for comparison with experiment. A routine has been		
ϵ_{2v}	coded which allows the effects of changes to these parameters on curve shapes to be rapidly explored for the determination of		
β	optimum values. ε_{1y} and ε_{2y} are the critical volumetric strain and the mean volumetric strain respectively. β is a parameter		
	defining the distribution of strains for cavitation		
	These parameters are used to fit the shear data to produce an effective shear hardening curve which characterises hardening		
	behaviour in the Cavitation model. In the Cavitation model the hardening curve can be input as an equation rather than in		
	tabular form. The hardening curve is modelled using the function below. Although this function can describe tension or shear, it		
$\sigma_{0u}, \sigma_{0r}, \beta_{0}, g_0$	is the shear curve that is modelled for the Cavitation model i.e. σ_S replaces σ_T		
	$\sigma_{\mathrm{T}} = \left[\sigma_{\mathrm{0u}} + (\sigma_{\mathrm{0r}} - \sigma_{\mathrm{0u}}) \left(1 - \exp - \left(\varepsilon_{\mathrm{T}}^{\mathrm{P}} / \varepsilon_{\mathrm{oS}}\right)^{\theta_{\mathrm{0}}}\right)\right] \left(1 + g_{\mathrm{0}} \varepsilon_{\mathrm{T}}^{\mathrm{P}}\right)$		



CAVITATION MODEL

The linear Drucker-Prager yield criterion, $\sigma_e = \sigma_o - \mu \sigma_m$, is modified as follows to give a yield function Φ that includes the effect of cavitation of the rubber on yield stresses for the adhesive:

$$\Phi = \frac{\sigma_e^2}{\sigma_M^2} - (q_1 f)^2 + 2q_1 f \cosh \frac{3\sigma_m}{2\sigma_M} - \left(1 - \frac{\mu \sigma_m}{\sigma_M}\right)^2 = 0$$

Here f is the effective volume fraction of cavities, which at small strains is zero but increases rapidly over some characteristic strain region responsible for cavity nucleation. The parameter q has been included to account for the effect of void interactions on the stress distribution in the matrix between cavities. The yield stress σ_M is $\sqrt{3}$ x the shear yield stress for the matrix material between voids. It is assumed that a cavity is nucleated in a rubber particle at some critical volumetric strain that decreases with increasing particle diameter. For a distribution of particle sizes, the void nucleation should then occur over a range of total volumetric strain ϵ_V related to the critical volumetric strain range for the rubber particles. Various mathematical functions relating f and ϵ_V have been considered and, based on tensile and shear results for the rubber-toughened adhesive and some rubber-toughened thermoplastics, the most suitable takes the form

$$f = 0$$
 for $\varepsilon_{v} \le \varepsilon_{1v}$ $f = v_{Ro} \left\{ 1 - \exp \left[-\left(\frac{\varepsilon_{v} - \varepsilon_{1v}}{\varepsilon_{2v}} \right)^{\beta} \right] \right\}$ for $\varepsilon_{v} > \varepsilon_{1v}$

These expressions imply that cavities start to nucleate when the volumetric strain exceeds a critical value ϵ_{1v} after which the volume fraction f rises from zero to the value v_{Ro} , for the volume fraction of rubber, over a range of volumetric strain determined by the parameters ϵ_{2v} and β . Furthermore, for stress states such as compression and shear that do not generate a significant volumetric strain, f=0 and the yield function above is identical to the linear Drucker-Prager yield criterion. $\sigma_o\left(\epsilon_o^P\right)$ is the hardening function and is obtained from stress/strain data obtained in a shear test using the equation

$$\sigma_{\rm o} = \sqrt{3} \, \sigma_{\rm S}$$



CAVITATION MODEL PARAMETERS

The materials model parameters shown below are those required by the NPL cavitation model user subroutine, which is read into the ABAQUS finite element software. The parameters are for a typical rubber-toughened epoxy.

```
***material
 *integration theta method a 1.0 1e-8 1500
***behaviour prefd2ng explicit auto_step
**elasticity isotropic
                 2.970 GPa
young
                 0.35
poisson
**isotropic
npl_polymer
sig0u
                 0.0200 GPa
sig0r
                 0.0748 GPa
                 0.0062
eps0s
beta0
                 0.72
**model coef
                 1.6
q
                 0.300
mu
                 0.1700
mup0
                 1.35
k
                 0.16
v_ro
                 0.0030
eps1v
eps2v
                 0.0040
                 0.900
betav
                 0.005 GPa
crit str
***return
```

NOTE: In the cavitation model, the units used are GPa, this means predicted stresses are also output as GPa.



TYPICAL PREDICTIONS

To	investigate	the	effe	ct of	using	g diffe	rent	materials	s models	on	joint	predi	ictions	please	select	a	joint	geometry	. For	each	geon	netry	the
ex	perimental	curve	is p	orese	nted a	along	with	the corr	espondir	ig pi	redicti	ions (obtaine	d using	the v	on	Mise	s, linear	Druck	er-Pra	ger, e	expon	en
Dr	ucker-Prag	er and	d Cav	vitatio	n mo	dels. C	Conto	our plots	of maxim	um բ	orincip	oal str	ess in	the adh	esive a	re a	also a	vailable.					

Scarf joint

Lap joint

Tpeel joint

Butt joint

NOTE: The predictions shown are only valid for these materials and joint geometries. The best choice of model will depend on the adhesive used.

HOME


CALCULATION OF PARAMETERS

FAILURE CRITERIA



SCARF JOINT

The scarf joint was bonded with a rubber-toughened epoxy and tested. FEA predictions were obtained from analyses using each of the four material models, von Mises, linear and exponent Drucker-Prager and cavitation model. The force-extension predictions are shown below. In this example, the linear Drucker-Prager and cavitation model produce similar predictions.




Scarf joint with aluminium acherends 12 10 Force (kN) 6 – experimental data 🕶 von Mises --- line ar Drucker-Prager --- exponent Drucker-Prager -- Cavitation model 2 0 0.01 0.02 0.03 0.04 0.05 0.06 0.07 0.08 gauge extension (mm)

Scarf joint experimental curve with force-extension predictions from all four models



SCARF JOINT - Predictions of stress using different models

The values of stress and strain predicted in an analysis are very dependent on the material model used. To illustrate this, the maximum principal stress (SP3) is obtained for the scarf joint analyses at an extension of 0.0458 mm, the extension at which the scarf joint begins to fail. Contour plots were obtained for all four material models.



Photograph of failed scarf joint.

Crack initiated at an extension of 0.046 mm


Contour plots were obtained for all four models at an extension of 0.0458 mm (the point of crack initiation). The contour plots are available here.

The predicted values of maximum principal stress are given in the table below

von Mises	105 MPa					
linear Drucker-Prager	68.8 MPa					
exponent Drucker-Prager	62.2 MPa					
Cavitation model	67.6 MPa (6.76E-2GPa in contour plot)					




SCARF JOINT - Predictions of stress using different models





LAP JOINT

The lap joint was bonded with a rubber-toughened epoxy and tested. FEA predictions were obtained from analyses using each of the four material models, von Mises, linear and exponent Drucker-Prager and cavitation model. The force-extension predictions are shown below. It should be noted that the degree to which the predicted force-extension curves fit the experimental behaviour is only of interest up to the point where failure initiates in the joint. After this point the experimental data will be lower than the predicted data due to the presence of a growing crack. In the lap joint, crack initiation is observed to occur at about 0.1 mm. At this extension the force-extension predictions are comparable for all four material models.



Lap joint schematic

Lap joint experimental curve with force-extension predictions from all four models

BACK


HOME

Effect of model on predicted stresses



LAP JOINT - Predictions of stress using different models

The values of stress and strain predicted in an analysis are very dependent on the material model used. To illustrate this, the maximum principal stress (SP3) is obtained for the lap joint analyses at an extension of 0.09 mm. This is the extension at which a crack is observed to initiate in the adhesive layer of the joint. At this extension the force-extension predictions are comparable for all four material models.



Photograph of failed lap joint.

Crack initiated at an extension of 0.09 mm


Contour plots were obtained for all four models at an extension of 0.09 mm (the point of crack initiation). The contour plots are available <u>here</u>.

The predicted peak values of maximum principal stress are given in the table below. These peaks are found to occur in the region of crack initiation


von Mises	95.4 MPa
linear Drucker-Prager	68.3 MPa
exponent Drucker-Prager	60.7 MPa
Cavitation model	61.4 MPa (6.14E-2GPa in contour plot)




LAP JOINT - Predictions of stress using different models




Von MIses



Exponent Drucker-Prager



Linear Drucker-Prager




Cavitation




TPEEL JOINT

The tpeel joint was bonded with a rubber-toughened epoxy and tested. FEA predictions were obtained from analyses using two material models, exponent Drucker-Prager and cavitation model. The force-extension predictions are shown below.



Tpeel joint schematic



Tpeel joint experimental curve with force-extension predictions from two models

BACK


<u>HOME</u>


Effect of model on predicted stresses




TPEEL JOINT - Predictions of stress using different models

Contour plots of maximum principal stress at an extension of 0.24 mm are shown below. This is the extension at which crack initiation is observed. The locations of the peak stresses in the contour plots tie-up with the experimentally observed crack initiation location.





Exponent Drucker-Prager





Cavitation



BUTT JOINT

The butt joint was bonded with a rubber-toughened epoxy and tested. FEA predictions were obtained from analyses using three material models, von Mises, linear Drucker-Prager and exponent Drucker-Prager. The elastic-plastic materials models differ in the way they account for the influence of hydrostatic stress on yield behaviour. The stress state in the adhesive in a butt-joint specimen loaded in tension contains a high component of hydrostatic stress. Hence experimental data from this test is useful for determining the applicability of different yield criteria for the adhesive to be assessed. The force-extension predictions are shown below.





Butt joint schematic

Butt joint experimental curve with force-extension predictions from three models



THE PREDICTION OF FAILURE IN ADHESIVE JOINTS

A feasible approach to predicting when an adhesive joint will start to fail involves a finite element analysis to determine stress and strain distributions in the adhesive layer coupled with a criterion for failure based on achieving a critical level of some component of stress or strain sufficient to promote the initiation of a crack. In research studies on this subject, distributions of stress and strain components are calculated at loads or extensions where failure is believed to initiate in joint specimens of different geometry and dimensions. The aim is to explore whether there is a critical level of stress or strain that is common at failure initiation in these different types of joint. Stress and strain components that are commonly considered are:

- Maximum principal stress
- Hydrostatic stress
- Effective shear (Mises) stress
- Maximum principal strain
- Volumetric strain

The success of this work clearly relies on the ability to make accurate predictions of stress and strain distributions based on finite element analyses. Although, at present, no conclusions can be drawn regarding a generalised failure criterion, some relevant comments can be made.

With tough adhesives, there is a significant phase of plastic deformation in which the stress, for example in bulk specimens, changes little with strain. This would suggest that criteria based on a critical level of strain are likely to be more realistic than those based on a critical stress. However, in an adhesive joint, failure initiation often occurs at sites of high hydrostatic stress and at levels that are not generated in bulk specimens. It is possible therefore, that different criteria apply for failure in joints and bulk material.

It has been observed that failure strains can be high in tests on butt-joint specimens under torsion, even for adhesives that have relatively low tensile failure strains. The stress and strain states in this test are predominantly shear and dilatational components are minimal, which suggests that shear components are not major factors in determining failure initiation. In this context, it should be noted that high levels of maximum principal stress or strain can be generated under shear, and so criteria based on critical values of either of these components are unlikely to be valid unless the criterion includes an associated significant level of hydrostatic stress or strain.

Criteria for failure based on a critical level of hydrostatic stress or volumetric strain therefore deserve further investigation involving comparisons of measured and predicted deformation of joint specimens to failure.