




IN104

IN105

IN106

A23

A24

A25

A26

A27

A28

SERIAL PORT 1

1

2

3

4

5

N/C

7

8

IRIG-B

+

-

SERIAL PORT 2

1

9

SERIAL PORT 3

1

9

MA

0

E

IN

C

S

A

OUT201

OUT202

OUT203

B01

B02

B03

B04

B05

B06

OUT204

OUT205

OUT206

B07

B08

B09

B10

B11

B12

OUT207

OUT208

OUT209

B13

B14

B15

B16

B17

B18

OUT210

OUT211

OUT212

B19

B20

B21

B22

B23

B24

IN201

IN202

IN203

IN204

B25

B26

B27

B28

B29

B30

B31

B32

IN205

IN206

IN207

IN208

B33

B34

B35

B36

B37

B38

B39

B40

IA

IB

IC

Z01

Z02

Z03

Z04

Z05

Z06

VAX

VBX

VCX

Z13

Z14

Z15

VNX

Z16

VAY

VBY

VCY

Z19

Z20

Z21

VNY

Z22

POWER

+

Z25

-

Z26

GND

+

Z27

!

DANGER

CONTACT WITH INSTRUMENT
TERMINALS MAY CAUSE
ELECTRICAL SHOCK WHICH CAN
RESULT IN INJURY OR DEATH

PORT 1 EIA-485	PORT 2 EIA-232	PORT 3,4 EIA-232
PIN 1 +TX	PIN 1 N/C OR +5Vdc	PIN 1 N/C OR +5Vdc
2 -TX	2 RXD	2 RXD
3 +RX	3 TXD	3 TXD
4 -RX	4 +IRIG-B	4 N/C
5 SHIELD	5,9 GND	5,9 GND
6 N/C	6 -IRIG-B	6 N/C
7 +IRIG-B	7 RTS	7 RTS
8 -IRIG-B	8 CTS	8 CTS

196-0207