

DIGIT:

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

CONNECTOR

ETHERNET

MOUNTING

CHASSIS

POSITION

B

C

D

E

0

4

8

7

B

1

-

-

-

2

X

-

X

-

X

NOTES:

- IF YOU ARE NOT FAMILIAR WITH MASTER CONFIGURABLE DRAWINGS, PLEASE SEE INSTRUCTIONS LOCATED ON THE SEL WEBSITE IN THE DRAWINGS.
- THIS DRAWING IS FOR THE 487B 9U HORIZONTAL ONLY.
- USE LAYERS TO UPDATE VIEWS. SOME COMBINATIONS MAY NOT BE AVAILABLE. VERIFY OPTIONS USING SEL WEBSITE.
- ONLY SELECT ONE OPTION PER SECTION.
- DRAWINGS ARE UPDATED FREQUENTLY. PLEASE USE CURRENT LINK FROM SEL WEBSITE.
- DASHED SLOTS DO NOT AFFECT PRODUCT GRAPHICS AND ARE NOT SHOWN AS CONFIGURABLE OPTIONS.

400

D 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 D

500

E 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 E

100

OUT01 OUT02 OUT03 OUT04 OUT05 OUT06 OUT07 OUT08 IN01 IN02 IN03 IN04 IN05 IN06 IN07

A 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 A

IRIG-B IN OUT

EIA-232 PORTS PORT 1 PORT 2 PORT 3

PORT 5A PORT 5B PORT 5C PORT 5D

LINK = YELLOW
ACTIVITY = GREEN

200

B 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 B

300

C 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 C

101 102 103 104 105 106 107 108 109

Y 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 Y

MONITOR Vdc 1

POWER Vdc 1

25 26 27 28 29 30

GND 31

110 111 112 113 114 115 116 117 118 119 120 121

Z 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 Z

i7094d