# **Knock Sensor KS4-P**

www.bosch-motorsport.com





- ► Engine vibration measurements
- ▶ Measurement range 3 to 25 kHz
- ► Robust design
- ► Integrated series connector

This sensor is used for detecting structural born vibrations in spark ignition engines due to uncontrolled combustion. This sensor is suitable for operation in extreme conditions.

Due to the inertia of the seismic mass, the sensor moves in correlation to the engine block vibration; this motion results in a compressive force which is converted into a voltage signal via a piezoceramic sensor element. As a result, upper and lower voltage thresholds can be defined directly correlating to an acceleration magnitude.

The main benefits of this sensor are its robust mechanical design, compact housing and precise determination of structure-related noise. The small packaging is accomplished by integrating the connector directly to the sensor.

Application	
Application	3 to 25 kHz
Operating temperature range	-40 to 150°C
Storage temperature range	-30 to 60°C
Max. vibration	≤ 800 m/s²

Mechanical Data	
Male thread (for cast)	M8x25
Male thread (for AI)	M8x30
Installation torque	20±5 Nm
Weight w/o wire	48 g
Protection	IP X9K
Electrical Data	
Range of frequency	3 to 25 kHz
Sensitivity at 5 kHz	26 ± 8 mV/g
Max. sensitivity changing (life-time)	-17 %
Linearity between 5 to 15 kHz (from 5 kHz value)	-10 to 10 %
Linearity between 15 to 20 kHz (linear increasing with freq)	20 to 50 %
Main resonance frequency	30 kHz
Impedance	> 1 MΩ

# 2 | Knock Sensor KS4-P

Temperature dependence of sensitivity	0.04 mV/g°C
Capacity field	1,150 ± 200 pF
Connectors and Wires	
Mating connector 2-pole	2-Pin RB-Kp.1 (F 02U B00 966-01) Or 2-Pin Jetronic (D 261 205 288-01)
Pin 1	Sig+
Pin 2	Sig-

# **Installation Notes**

The KS4-P can be connected to all Bosch Motorsport ECUs featuring knock control

The sensor must rest directly on the brass compression sleeve during operation.

To ensure low-resonance coupling of the sensor to the measurement location, the contact surface must be clean and properly machined to provide a secure flush mounting.

Please route the sensor wire in a way that prevents resonance vibration.

Please find further application hints in the offer drawing at our homepage.

#### **Safety Note**

The sensor is not intended to be used for safety related applications without appropriate measures for signal validation in the application system.

### **Ordering Information**


## Knock Sensor KS4-P


Mating Connector: 2-Pin RB-Kp.1 Order number 0 261 231 173

# Knock Sensor KS4-P

Mating Connector: 2-Pin Jetronic Order number **0 261 231 188** 

#### **Dimensions**





#### Represented by:

Europe:
Bosch Engineering GmbH
Motorsport
Robert-Bosch-Allee 1
74232 Abstatt
Germany
Tel.: +49 7062 911 9101
Fax: +49 7062 911 79104
motorsport@bosch.com
www.bosch-motorsport.de

North America:
Bosch Engineering North America
Motorsport
38000 Hills Tech Drive
Farmington Hills, MI 48331-3417
United States of America
Tel.: +1 248 876 2977
Fax: +1 248 876 7373
motorsport@bosch.com
www.bosch-motorsport.com

Latin America:
Robert Bosch Ltda
Motorsport
Av Juscellino Kubitscheck de
Oliweira 11800
Zip code 81460-900
Curitiba - Parana
Brasilia
Tel.: +55 41 3341 2057
Fax: +55 41 3341 2779

Asia-Pacific:
Bosch Engineering Japan K.K.
Motorsport
18F Queen's Tower C, 2-3-5 Minato Mirai
Nishi-ku, Yokohama-shi
Kanagawa 220-6218
Japan
Tel.: +81 45 650 5610
Fax: +81 45 650 5611
www.bosch-motorsport.jp

Australia, New Zealand and South Africa: Robert Bosch Pty. Ltd Motorsport 1555 Centre Road Clayton, Victoria, 3168 Australia Tel.: +61 (3) 9541 3901

motor.sport@au.bosch.com