




USB Entry




PWR SELECTION




3.3V LDO




INDICATORS




JST ESC Entry





5V BUCK



Gyro/Accel, Barometer, Magnetometer



RESET AND BOOT PINS



Sheet: /
File: flight_controller.kicad_sch

Title:

Size: A3
KiCad E.D.A. 10.0.4

Date:

Rev:
Id: 1/1